

E1 AND E2 USER'S GUIDE

Form 1563-161014—October 2016

OPTO 22
Automation made simple.

43044 Business Park Drive • Temecula • CA 92590-3614
Phone: 800-321-OPTO (6786) or 951-695-3000
Fax: 800-832-OPTO (6786) or 951-695-2712
www.opto22.com

Product Support Services

800-TEK-OPTO (835-6786) or 951-695-3080
Fax: 951-695-3017
Email: support@opto22.com
Web: support.opto22.com

E1 and E2 User's Guide
Form 1563-161014—October 2016
Copyright © 2005–2016 Opto 22.
All rights reserved.
Printed in the United States of America.

The information in this manual has been checked carefully and is believed to be accurate; however, Opto 22 assumes no responsibility for possible inaccuracies or omissions. Specifications are subject to change without notice.

Opto 22 warrants all of its products to be free from defects in material or workmanship for 30 months from the manufacturing date code. This warranty is limited to the original cost of the unit only and does not cover installation, labor, or any other contingent costs. Opto 22 I/O modules and solid-state relays with date codes of 1/96 or newer are guaranteed for life. This lifetime warranty excludes reed relay, SNAP serial communication modules, SNAP PID modules, and modules that contain mechanical contacts or switches. Opto 22 does not warrant any product, components, or parts not manufactured by Opto 22; for these items, the warranty from the original manufacturer applies. Refer to Opto 22 form 1042 for complete warranty information.

Wired+Wireless controllers and brains are licensed under one or more of the following patents: U.S. Patent No(s). 5282222, RE37802, 6963617; Canadian Patent No. 2064975; European Patent No. 1142245; French Patent No. 1142245; British Patent No. 1142245; Japanese Patent No. 2002535925A; German Patent No. 60011224.

Opto 22 FactoryFloor, *groov*, Optomux, and Pamux are registered trademarks of Opto 22. Generation 4, *groov* Server, ioControl, ioDisplay, ioManager, ioProject, ioUtilities, *mistic*, Nvio, Nvio.net Web Portal, OptoConnect, OptoControl, OptoDataLink, OptoDisplay, OptoEMU, OptoEMU Sensor, OptoEMU Server, OptoOPCServer, OptoScript, OptoServer, OptoTerminal, OptoUtilities, PAC Control, PAC Display, PAC Manager, PAC Project, PAC Project Basic, PAC Project Professional, SNAP Ethernet I/O, SNAP I/O, SNAP OEM I/O, SNAP PAC System, SNAP Simple I/O, SNAP Ultimate I/O, and Wired+Wireless are trademarks of Opto 22.

ActiveX, JScript, Microsoft, MS-DOS, VBScript, Visual Basic, Visual C++, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. Linux is a registered trademark of Linus Torvalds. ARCNET is a registered trademark of Datapoint Corporation. Modbus is a registered trademark of Schneider Electric, licensed to the Modbus Organization, Inc. Wiegand is a registered trademark of Sensor Engineering Corporation. Allen-Bradley, CompactLogix, ControlLogix, MicroLogix, SLC, and RSLogix are either registered trademarks or trademarks of Rockwell Automation. CIP and EtherNet/IP are trademarks of ODVA.

groov includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org>)

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

Opto 22
Automation Made Simple.

Table of Contents

Chapter 1: Introduction	1
E1 Brain Board	1
E2 Brain Board	2
About this Guide	2
Other Documents You May Need	3
For Help	4
E1 and E2 Features and Specifications	5
E1 Brain Board Features	5
E2 Brain Board Features	6
Specifications	8
Dimensional Drawings	9
E1 Dimensions	9
E2 Dimensions	9
LED Descriptions	10
E1 LED Descriptions	10
E2 LED Descriptions	10
LED Blink Codes	11
Chapter 2: Installation	13
What You Will Need	13
Installing Software	13
Mounting the Brain Board	14
Connecting the Power Supply	15
Connecting the E1 and E2 to Earth Ground	16
Installing I/O Modules	17
Connecting to a Serial Network	17
Wiring Serial Communications and Power	17
Setting Jumpers (Serial Only)	19
Connecting to an Ethernet Network	22
Security	22
System Components	23
I/O Modules and Mounting Racks	23
Cable	23
Power Supply	24

Chapter 3: Architecture and Communication	25
Communication Options	25
Accessing E1 and E2 Brain Boards Over the Internet	26
System Architecture	26
Typical Control System Using Optomux	27
Optomux Over Ethernet	27
Optomux Over Serial	27
Control System Plus Data Acquisition via OPC	28
Communicating with Modbus/TCP Clients	29
PAC Project Control System	29
Building Custom Applications with the OptoMMP Protocol	31
Migration Options	32
Acquiring Data Using OPC	33
Adding Modbus/TCP Communication	34
Chapter 4: Maintaining the E1 and E2	35
Assigning or Viewing the IP Address	35
Resetting the Brain Board to Factory Defaults	35
Loading New Firmware	37
Chapter 5: Using Modbus/TCP	41
Introduction	41
Overview of Modbus/TCP Communication	41
Understanding Opto 22 and Modbus/TCP Differences	41
Function Codes Supported	42
Communication Packet	43
Exception Errors	43
Referencing I/O Points for E1 and E2 Brain Boards	45
Configuring I/O Points	46
Using Digital Point Features	46
Latches	46
Counters	46
Using Analog Point Features	47
Scaling	47
Maximum and Minimum Values (Peaks and Valleys)	47
Offset and Gain	47
Modbus/TCP Memory Map for E1 and E2 Brain Boards	48
Coils	48
Inputs	48
Input Registers	49
Holding Registers	49
Using Input and Holding Registers	51
Chapter 6: Troubleshooting	53
Troubleshooting Ethernet Communications	53
Pinging the Brain Board	54

Accessing the Brain Board with PAC Manager	54
Solving Network Problems	56
Create a Network Diagram	56
Analyze Communication Packets	56
Have Your Network Certified	56
Troubleshooting Serial Communications	56
Solving Common Communications Errors	56
Power Tips	56
Jumper Tips	57
Communication Wiring Tips	58
Other Tips:	58
Error Codes When Using Opto 22 Optomux Driver	59
Errors Returned by the Brain Board	59
Driver Errors	60
Other Error Codes	60
General Troubleshooting	60
Serial Communications Questions and Answers	62
Appendix A: Serial-to-Ethernet Routing	63
Creating a Routing Table	65
Sample Routing Table	66
Enabling Serial-to-Ethernet Routing	66
Disabling Serial-to-Ethernet Routing	68
Appendix B: Using the OmuxSettings File	69
About the OmuxSettings File	69
Changing the OmuxSettings File	69
Appendix C: Licensing Information	73
Software Licenses Used in E1 and E2 Brain Boards	73
Opto 22 License Agreement for Embedded Software	73
GNU General Public License	73
GNU Lesser General Public License	74
Berkeley Software Distribution License	74
Opto 22 License Agreement for Embedded Software	75
GNU General Public License	76
GNU Lesser General Public License	80
Index	87



1: Introduction

The E1 digital and E2 analog brain boards are intelligent I/O (input/output) processors that communicate with a host computer and also perform control functions at each point of I/O.

Designed as drop-in replacements for Opto 22's B1 and B2 brain boards, the E1 and E2 have the same Optomux and serial network capabilities, but they offer significant new features: Ethernet support, additional protocol support, and migration and expansion opportunities. For example, you can use PAC Project™ software applications with E1 or E2 I/O systems to control, monitor, and acquire data.

E1 and E2 brain boards can communicate using Optomux over serial and Ethernet, and using Opto 22's OptoMMP™ protocol over Ethernet. OLE for Process Control (OPC) and Modbus/TCP clients can readily obtain data from the system over Ethernet. For detailed information on protocols and system architecture, see [Chapter 3](#).

E1 Brain Board

The E1 brain board is a digital-only processor that can be used with a variety of input/output (I/O) modules and mounting racks. The E1 supports up to 16 I/O modules.

In addition to On/Off control, the E1 brain board provides the following digital functions:

- Read/write to point
- Input latches
- Counters
- Pulse duration measurement
- Pulse generation
- Time delays
- Watchdog timer

For detailed descriptions of E1 features, see “[E1 and E2 Features and Specifications](#)” on page 5.



E1 Brain Board


E2 Brain Board

The E2 brain board is an analog-only processor used with G1 (Standard) analog modules and G1-series mounting racks.

In addition to simple input and output, the E2 brain board provides the following analog functions:

- Read/write to point in Engineering units
- Read/write to point in counts
- Input averaging
- Minimum/maximum values (peak/valley recording)
- High/low limit testing
- Offset and gain calculation
- Waveform generation
- Watchdog timer

For detailed descriptions of E2 features, see [E1 and E2 Features and Specifications](#) on page 5.



E2 Brain Board

About this Guide

This guide shows you how to install and use E1 and E2 brain boards. This guide assumes that you have some familiarity with TCP/IP, UDP/IP, and Ethernet networking. If you are not familiar with these subjects, we strongly suggest you consult commercially available resources to learn about them before attempting to install or use these products.

If you are using Modbus/TCP for communicating with E1 and E2 brain boards, this guide assumes that you are already familiar with Modbus/TCP.

The following chapters are included in this user's guide:

Chapter 1: Introduction—Provides a brief description of the E1 and E2 brain boards, the contents of this guide, a list of other important documents, and how to reach Opto 22 Product Support.

Chapter 2: Installation—Details what you need to install E1 and E2 brain boards, how to mount the brain board, and how to connect to a serial or Ethernet network.

Chapter 3: Architecture and Communication—Describes how E1 and E2 brain boards fit into your system architecture and how to communicate with them.

Chapter 4: Maintaining the E1 and E2—Describes assigning and changing IP addresses, resetting the brain board to factory defaults, and upgrading firmware.

Chapter 5: Using Modbus/TCP—Provides configuration information for those communicating with the E1 and E2 using Modbus/TCP.

Chapter 6: Troubleshooting—Provides tips for resolving difficulties you may encounter while working with E1 and E2 brain boards.

Appendix A: Serial-to-Ethernet Routing—Presents how to set up the E1 and E2 to route data between serial and Ethernet networks.

Appendix B: Using the OmuxSettings File—Describes how to set Optomux network settings using the OmuxSettings file.

Appendix C: Licensing Information—Presents licensing information for software components.

Other Documents You May Need

See the following additional guides for the information listed. Most guides are available on our website, www.opto22.com; some are included on the CD that came with the brain board.

For this information	See this guide	Form #
Writing custom applications using the Optomux protocol over Ethernet or serial. (Combines previous forms 92 and 203 into new form number.)	Optomux Protocol Guide	1572
Configuring E1s and E2s to use with PAC Project software, Modbus/TCP applications, and custom OptoMMP	For minimum E1/E2 firmware R1.2a, PAC firmware 9.5, and PAC Project 9.5:	1710
	<ul style="list-style-type: none"> • PAC Control User's Guide, Legacy Edition • PAC Manager User's Guide, Legacy Edition For older firmware or software: I/O Configuration for E1 and E2 Brain Boards	1714 1576
Writing custom applications using the OptoMMP protocol over Ethernet	OptoMMP Protocol Guide	1465
Providing reliable power to Opto 22 equipment	Using Power Supplies with Opto 22 Systems	1271
Programming Opto 22 SNAP PAC controllers	PAC Control User's Guide, Legacy Edition	1710
	PAC Control Command Reference, Legacy Edition	1711
B1/B2 system architecture, features, specifications, installation and wiring, and jumpers	Optomux 16-Channel Digital and Analog Brain Board Data Sheet (B1/B2)	463
E1/E2 protocol support, comparison of B1/B2 and E1/E2, detailed description	E1 and E2 Brain Board Data Sheet	1546

For Help

If you have problems installing or using E1 and E2 brain boards and cannot find the help you need in this guide or on our website, contact Opto 22 Product Support.

Phone: 800-TEK-OPTO (800-835-6786
toll-free in the U.S. and Canada)
951-695-3080
Monday through Friday,
7 a.m. to 5 p.m. Pacific Time

NOTE: Email messages and phone calls to Opto 22 Product Support are grouped together and answered in the order received.

Fax: 951-695-3017

Email: support@opto22.com

Opto 22 website: www.opto22.com

When calling for technical support, you can help us help you *faster* if you can provide the following information to the Product Support engineer:

- Opto 22 hardware part numbers or models that you're working with
- Software version (available by clicking Help > About in the application's menu bar)
- Firmware version
- Specific error messages you saw
- Version of your computer's operating system

E1 and E2 Features and Specifications

E1 Brain Board Features

The following table shows features available on an E1 digital I/O unit depending on the protocol used.

Feature	Optomux	OptoMMP ¹	Modbus/TCP
Read/write to point	●	●	●
Input latches	● ²	● ³	● ³
Counters ⁴	●	●	●
Pulse duration measurement	●		
Pulse generation	●		
Time delays (10 ms resolution)	●		
Watchdog timer	●	●	●
Networks			
Serial (RS-422/485)	●		
Ethernet	●	●	●

¹ This protocol is also used with all PAC Project applications.

² One latch per point is available; it can be configured as on-to-off or off-to-on.

³ Two latches per point are always available; no configuration is needed.

⁴ Maximum counter frequency is 400 Hz. Counters roll over at 65,535.

NOTE: You can configure E1 and E2 brain boards like any other I/O unit if you have E1/E2 firmware R1.2a (and higher) and PAC Project 9.5000 (and higher). Also, if a SNAP PAC controller communicates with the E1 or E2, the controller must have PAC firmware R9.5a (or higher) to use this simplified configuration method.

If you are not using these firmware and software versions (or if you prefer to use the previous method to reconfigure existing E1s or E2s), see Opto 22 form 1576, I/O Configuration for Blue and E2 Brain Boards.

Each E1 feature is described below.

Read/Write to Point—The E1 can read the value of any input or output point and turn digital output points on or off.

Input Latches—When the value of a digital input point changes from off to on, an on-latch can be set. While the value of the point may return to off, the on-latch remains set until cleared, as a record of the change. Similarly, an off-latch can be set when the value of a digital point changes from on to off, and it remains set until cleared. See note 2 in the table above.

Latching is different on an E1 depending on the protocol used with the brain board. When the E1 is used with the Optomux protocol, only one latch is available and you must configure it to be an off-to-on latch or on-to-off latch. When you use an E1 with OptoMMP or Modbus/TCP, however, both types of latches are automatically available for each point, and no configuration is required.

Counters—Digital input can be used as a counter, counting the number of times the input changes from off to on.

Pulse Duration Measurement (using the Optomux protocol)—Any or all of the input points can function as pulse duration timers. Either on or off pulses can be timed with a resolution of 10 milliseconds.

Pulse Generation (using the Optomux protocol)—The E1 can be instructed to output a specific number of pulses (with programmable period) at any output point. Continuous square waves can also be generated.

Time Delays (using the Optomux protocol)—Any or all output points can function in time delay mode. Outputs can be set to operate with four types of delays:

- Delay before turning off
- Delay before turning on
- Pulse on
- Pulse off

Time delays are programmable with a resolution of 10 milliseconds.

Watchdog Timer—You can set a watchdog timer to monitor communication with the PC or other host device. If the watchdog timer is set via the serial port, then any serial activity will trigger the watchdog (including communications to other devices). If it is set via the Ethernet port, then only Ethernet activity directed to the respective E1 or E2 will trigger the watchdog. If the watchdog isn't triggered for the length of time set, the brain board automatically sets designated I/O points to the values you have determined. This action makes sure the process is brought to a safe state if communication fails.

E2 Brain Board Features

The following table shows features available on an E2 I/O unit depending on the protocol used.

Feature	Optomux	OptoMMP ¹	Modbus/TCP
Read/write to point in Engineering units		●	●
Read/write to point in counts	●	●	
Input averaging	●		
Minimum/maximum values (peak/valley recording) ²	●	●	●
High/low range testing	●		
Offset and gain calculation	●	●	●
Waveform generation	●		
Watchdog timer	●	●	
Networks			
Serial (RS-422/485)	●		
Ethernet	●	●	●
1 This protocol is also used with all PAC Project applications. 2 If an ICTD or thermocouple module is used, minimum and maximum values are returned as counts.			

NOTE: You can configure E1 and E2 brain boards like any other I/O unit if you have E1/E2 firmware R1.2a (and higher) and PAC Project 9.5000 (and higher). Also, if a SNAP PAC controller communicates with the E1 or E2, the controller must have PAC firmware R9.5a (or higher) to use this simplified configuration method.

If you are not using these firmware and software versions (or if you prefer to use the previous method to reconfigure existing E1s or E2s), see Opto 22 form 1576, I/O Configuration for E1 and E2 Brain Boards.

Each E2 feature is described below.

Read/Write to Point in Engineering Units (using OptoMMP)—The E2 can read the value of an input point and send a value to an output point in engineering units, such as millivolts or milliamps.

Read/Write to Point in Counts—The E2 can read the value of an input point and send a value to an output point in 12-bit counts. This is especially useful when integrating with existing Optomux systems. The Optomux protocol will return counts in a range of 0–4095.

The OptoMMP protocol returns counts based on how the E2 was configured:

- Modules configured directly as G1 modules (new method; requires E2 firmware R1.2a or higher and PAC Project 9.5 or higher) will report counts as G1 counts (0–4095 nominal range).
- Modules configured as similar SNAP modules (old method using form 1576) will report counts as 0–25000 or -25000 to +25000.

Input Averaging (using the Optomux protocol)—The E2 can be instructed to average the values of successive readings.

Minimum/Maximum Values (peak/valley recording)—The E2 automatically keeps track of minimum and maximum count values for each input. You can read these values at any time, and you can reset min/max values.

NOTE: The values returned for temperature modules will be counts, not linearized temperature values. See Read/Write to Point in Counts, above, for count values.

High/Low Range Testing—The E2 tests for the high and low limits (range) for the specified input points, and sets a flag if values exceed the specified range

Offset and Gain Calculations—The brain board can calculate offset and gain for analog input points. If a 0 VDC to +5 VDC input receives signals that are slightly off (not exactly 0 VDC at the lowest point, for example), the offset and gain can be calculated so that values will appear accurately.

NOTE: To calibrate analog points, use PAC Manager. See form #1714, the Legacy Edition PAC Manager User's Guide.

Waveform Generation (using Optomux)—Square waves, triangle waves, and ramps can be generated at any output point with programmable rates.

Watchdog Timer—You can set a watchdog timer to monitor communication with the PC or other host device. If the watchdog timer is set via the serial port, then any serial activity will trigger the watchdog (including communications to other devices). If it is set via the Ethernet port, then only Ethernet activity directed to the respective E1 or E2 will trigger the watchdog. If the watchdog isn't triggered for the length of time set, the brain board automatically sets designated I/O points to the values you have determined. This action makes sure the process is brought to a safe state if communication fails.


Specifications

Power Requirements	5.0–5.2 VDC @ 0.5 amps (excludes digital and analog module power requirements) *
Ethernet Network Interface: Type Connector Rate Supported Protocols Maximum Segment Length	IEEE 802.3 network, 10Base-T/100Base-TX RJ-45 10/100 Mbps, half or full duplex Optomux over Ethernet, Modbus/TCP, OptoMMP (Opto 22's IEEE 1394-based memory-mapped protocol) 100 m (328 ft.) with Category 5 or superior UTP
Serial Network Interface: Type Connector Data Rates Supported Protocols Network Range	RS-422/485 serial link E1: Terminal block; E2: Terminal block (on mounting rack) 300, 600, 1200, 2400, 4800, 9600, 19200, and 38400 baud Optomux Up to 32 Optomux stations configured for multidrop can be used on a serial network of up to 1524 m (5000 ft.) total length. Up to 256 Optomux stations and longer line lengths can be used by installing network repeaters. Up to 256 Optomux stations configured for repeat mode can exist on a network.
Optomux I/O Functions	Digital I/O (E1): Read Point, Write Point, Latch Point (On/Off), Count, Pulse Duration, Time Delay, Pulse Generation, Watchdog Timer Analog I/O (E2): Read Point, Write Point, Input Averaging, Min/Max Recording (peak and valley), High/Low Range Testing, Offset and Gain Calculation, Waveform Generation, Watchdog Timer
Modbus/TCP, OptoMMP, and OPC I/O Functions	With these protocols, the following brain-based features are not available: • No pulsing or time delay (E1) • No pulse measurement • No input averaging or waveform generation (E2)
LED Indicators	Status, Link, Activity, Full duplex, Transmit (serial), Receive (serial)
Jumper-selectable Serial Options	Group A: Multidrop or repeat mode, RS-485 termination and biasing Group B: Serial address (0 to 255), baud rate, 2- or 4-pass protocol
Operating Temperature	0 °C to 70 °C
Storage Temperature	–40 °C to 85 °C
Humidity	0–95% humidity, non-condensing
Agency Approvals	CE, RoHS, DFARS
Warranty	30 months


* ±15 VDC ±0.25 V is required for the analog modules. Current depends on the number and types of modules installed. A 24 VDC power supply is required for analog modules that need a current loop source.

Dimensional Drawings

E1 Dimensions




E2 Dimensions



LED Descriptions


E1 LED Descriptions

LED	Description	Link Type
FD	Full Duplex Mode	Ethernet
ACT	Network Activity	Ethernet
LINK	Link	Ethernet
STAT	Status	n/a
REC	Data Receive	Serial
XMT	Data Transmit	Serial



E2 LED Descriptions


LED	Description	Link Type
LINK	Network Link	Ethernet
ACT	Network Activity	Ethernet
FDPX	Full Duplex Mode	Ethernet
STAT	Status	n/a
XMT	Data Transmit	Serial
RCV	Data Receive	Serial




LED Blink Codes

The Status LED (STAT) on E1 and E2 brain boards provides both event and status information.

Code	Type	Meaning	Comments
3 short blinks	Event	The brain board is beginning to start up.	The LED starts to blink after the E1 or E2 is turned on or a reboot command is sent to the device.
6 short blinks	Event	The brain board is entering loader mode.	The LED starts to blink after the E1 or E2 is turned on or a reboot command is sent to the device with the Loader Mode Jumper installed.
LED on	Status	The brain board is running.	Once the brain board has started, the LED turns on and stays on. This should occur shortly after a series of 3 short blinks. Note that the color of the LED doesn't matter; as long as the LED is On and not blinking, the brain board is functioning normally.
LED flashing	Status	The brain board is restoring the factory defaults or updating the firmware.	CAUTION: DO NOT turn off power to the device while the LED is flashing, even if it takes a very long time. Turning off power might corrupt the firmware and the brain board will not be able to start up. For more information, see "Resetting the Brain Board to Factory Defaults" on page 35 and "Loading New Firmware" on page 37.



E1 Brain Board



E2 Brain Board

2: Installation

Use this chapter to install E1 and E2 brain boards. If you need more information on how to integrate E1s and E2s with your system, see [Chapter 3: Architecture and Communication](#).

What You Will Need

To install an E1 or E2, you need the following items:

- PC running Microsoft® Windows® 2000 or higher, with a 10/100 MB Ethernet adapter card, the TCP/IP protocol installed, and a valid IP address. The PC must be on the same subnet as the brain board.
- Serial cable for a serial network. For an Ethernet network, use Category 5 Ethernet cable. (For more information on cables, see [page 23](#).)
- E1 or E2 brain board
- I/O modules and mounting racks (See compatible I/O modules and mounting racks on [page 23](#).)
- Power supply (See [page 24](#).)
- Voltmeter
- Screwdriver

Installing Software

Insert the CD that came with the brain board into your CD-ROM drive. The installation wizard should start automatically. If it doesn't, use Windows Explorer to navigate to your CD-ROM drive and then double-click setup.exe.

Mounting the Brain Board

Racks vary in shape and design. The combination of rack, modules, and brain board (called the *I/O unit*) can be mounted in any attitude on any flat surface.


To ensure reliable and trouble-free communications, the following is recommended:

- Use twisted-pair wires for the serial communications wiring. See [page 23](#).
- Keep communication and DC power wiring separate from any high-voltage field wiring.


Steps for mounting:

1. If you are replacing an existing B1 or B2 brain board, turn off the power to the rack and carefully remove the B1 or B2 from the rack.
2. Carefully plug the E1 or E2 brain board into the mounting rack using the 50-pin connector.

E1 brain board/rack combination. As shown in the G1/Standard example below, the brain board extends out past the end of the rack when used with G4, G1, and Quad Pak I/O racks. For integral racks, which have permanent I/O circuitry built in, the brain board is inserted in the other direction, covering the rack.




E2 brain board/rack combination



3. Place the I/O unit as close as possible to the controlled device to minimize wiring costs and noise for analog modules. When installing units next to each other, leave sufficient space between units for wiring.
4. For maximum physical strength, secure the brain board's permanently attached standoffs. Also secure standoffs on the rack, if available.

Connecting the Power Supply



- Using size 14 AWG or larger wire, connect 5-volt power to the + 5V and GND connectors on the mounting rack. If the + 5-volt supply is used by more than one unit or by other devices, make sure the voltage at each rack is 5.1–5.2 VDC. Use a consistent color code from the power supply to all brain boards to prevent wiring errors. See Opto 22 form #1271, *Using Power Supplies with Opto 22 Systems*, for more information on power wiring and voltage adjustments.

EXCEPTION: If an Opto 22 PBSA/B/C power supply is used with digital racks, the + 5 VDC logic connection is made by the supply when it is screwed to the rack. In this case, the only connection required is the 120 VAC (220 VAC or 10–28 VDC depending on supply type) connection to the PBSA (or PBSB or PBSC) supply.

- You can use either separate or combined 5.1–5.2 VDC and ± 15 VDC (± 0.25 VDC) supplies to provide power to analog racks. If you use a multiple-output supply, make sure that the 5 VDC RETURN line is separate from the 15-volt COMMON line to maintain module isolation.
- Route the +5-volt and ± 15 -volt wires away from any high-voltage field wires. Make sure there is only one earth ground connection per network, typically at the host site.


If the ground connection is at the host site, make sure none of the power supplies is grounded. This method prevents ground loop problems due to offset voltages appearing between multiple ground points.

- IMPORTANT:** Check polarities of all power supply connections before applying power. Incorrect polarity can damage the brain board and I/O modules.

NOTE: If the brain board is connected to an Ethernet network, before powering up see the section about assigning an IP address in form #1714, the Legacy Edition PAC Manager User's Guide.

Connecting the E1 and E2 to Earth Ground

In installations where electrical noise is a concern, the E1 and E2 each provide a grounding point to improve noise immunity. Using 18 AWG, connect the insulated wire from the grounding PEM to the point where the earth ground is connected. Each brain should have a separate wire to connect to ground. Each grounding point should be tied to a single point earth ground.



Installing I/O Modules

1. Turn off all power to the unit and to the field devices.
IMPORTANT: All power must be turned off before installing or removing I/O modules.
2. Install input and output modules in any rack position. Compatible modules are shown in the table on [page 23](#). For specifications and wiring information on modules, see the module's data sheet.
3. Depending on the networks you are using, continue with the following:
 - “[Connecting to a Serial Network](#),” below
 - “[Connecting to an Ethernet Network](#)” on [page 22](#)

NOTE: You can use both serial and Ethernet networks simultaneously. E1 and E2 brain boards are set by default to communicate on both networks.

Connecting to a Serial Network


Wiring Serial Communications and Power

A complete connection at each brain board consists of 10 wires as well as an overall cable shield: two twisted pairs and a common coming from the computer or previous brain board, and two twisted pairs and a common going to the next brain board. To ensure reliable communications, we recommend the following:

- Use shielded twisted-pair wires for the communications wiring. (See recommended cables on [page 23](#).)
- Route the communication and DC power wiring separately from any high-voltage field wiring or AC power wiring.
- Make sure the communications COM terminals on each rack are connected.

The following graphic shows standard and alternate wiring diagrams. When wiring a series of brain boards, always think of the previous brain board as the host.

STANDARD CONFIGURATION




NOTE: In this example, the cable shield is NOT electrically connected to the RS-485 com (common) terminals

TO = TO OPTOMUX
FO = FROM OPTOMUX
TH = TO HOST
FH = FROM HOST

* E2 communications wiring connections are made to the rack, not to the brain board. On the rack, the com connector is at the other end of the connector strip.

**Do not connect any com point to earth ground.

ALTERNATE CONFIGURATION



NOTE: In this example, the cable shield is connected to the RS-485 com (common) terminals, but the shield is NOT earth grounded

In order to meet published specifications, the RS-485 serial link requires two terminations, one at each end of the serial link. Star configuration is not allowed. In order to use a star configuration, use Opto 22 part number AC30A/B.

SHIELD DRAIN WIRE.
NOTE: DO NOT tie to earth ground.

Setting Jumpers (Serial Only)


Jumpers in groups A and B are set during initial configuration:

- Group A jumpers set repeat or multidrop mode, and termination.
- Group B jumpers set baud rate, 2-pass or 4-pass message, and address.


For information on using jumpers to reset the brain board, see [“Resetting the Brain Board to Factory Defaults” on page 35.](#)

Also see [“Jumper Tips” on page 57.](#)

NOTE: When the E1 or E2 is powered up, it periodically reads the jumpers. You can change the jumpers at any time and the firmware will detect the change and reconfigure accordingly.



1. Set the jumpers in Group A for repeat or multidrop mode, and proper termination and biasing.




Multidrop—When wiring a multidrop communications cable, keep in mind that the cable is a high-speed data-transmission line. To reduce reflections, make sure the line is terminated properly at both ends and that all stubs are less than three inches long.

Repeat—In this configuration, each brain board acts as a repeater, allowing up to 5,000 feet between units. Since a power failure at any unit breaks the communications link, battery backup is recommended.

NOTE: You cannot mix units operating in repeat mode and units operating in multidrop mode on the same network.

2. Set the Group B jumpers, including baud rate, message protocol, and address.



- a. Select the **baud rate** using jumpers 8, 9, and 11 in Group B. Make sure to set all brain boards on the same network at the same baud rate.

Baud Rate	Jumper			
	11	10	9	8
38.4 kBaud	■	□	■	■
19.2 kBaud	□	□	■	■
9600 Baud	□	□	■	□
4800 Baud	■	□	■	□
2400 Baud	■	□	□	■
1200 Baud	□	□	□	■
600 Baud	■	□	□	□
300 Baud	□	□	□	□

■ = JUMPER INSTALLED □ = NO JUMPER

- b. Set the **message protocol** using jumper 10 in Group B for 2-pass or 4-pass. Make sure all brain boards on the same network use the same message protocol.

Protocol	Jumper
	10
2-PASS	■ (Recommended)
4-PASS	□

■ = JUMPER INSTALLED □ = NO JUMPER

Use 2-pass for normal operation. It provides more efficient and faster communications. For a detailed description of 2-pass and 4-pass modes, see form # 1572, the *Optomux Protocol Guide*.

- c. Set the **address** using jumpers 0–7 on Group B, according to the following chart. Each brain board on the same network must have a unique address. Addresses do not need to be sequential.



Connecting to an Ethernet Network

To connect to an Ethernet network, see form #1714, the *PAC Manager User's Guide, Legacy Edition*.

IMPORTANT: If you are communicating only on an Ethernet network (no serial connections), make sure that Group A jumpers on E1 and E2 brains are set for multidrop mode/middle of link (see diagram below). If jumpers are not set in this way, the RS-485 communication lines may cause interference.

Group A Jumpers
Set for Multidrop Mode/
Middle of Link

0	Out
1	In
2	In
3	In
4	In
5	Out
6	Out
7	Out
8	Out
9	Out
10	In



Security

When designing your Ethernet network, be sure to consider security as required for your application. You can use PAC Manager to limit access to Ethernet-based I/O units, either by allowing access only from specific computers or other devices on the network (IP filtering), or by limiting access to specific protocols that are used with the I/O unit (port access). See form #1714, the *Legacy Edition PAC Manager User's Guide*, for more information on security.

System Components

This section gives additional information on some items listed in “What You Will Need” on page 13.

I/O Modules and Mounting Racks

The brain board plus the mounting rack and modules are often referred to as the *I/O unit*. Choose compatible I/O modules and mounting racks from the following tables.

E1 (Digital)	
I/O modules	Digital mounting racks
G4 Digital I/O	G4PB8H G4PB16H G4PB16HC
Quad Pak	PB16HQ
Standard (G1) I/O	PB4H PB8H PB16H PB16HC
Combination I/O and rack (Integral racks)	
G4PB16J/K/L PB16J/K/L	

E2 (Analog)	
I/O modules	Analog mounting racks
Standard (G1)	PB4AH PB8AH PB16AH

Cable

For serial (RS-422/485) communications, the following cables are recommended. Cables listed are 24-gauge, 7x32 stranded, with 100-ohm nominal impedance and a capacitance of 12.5 pF/ft. If you use other cables, they should have a nominal impedance of 100–120 Ohms and a capacitance of less than 15 pF/ft.

We also recommend that you choose a cable with one more pair than your application requires, so you can use one of the extra wires, rather than the shield, for the signal common.

Four-pair	Three-pair
<ul style="list-style-type: none"> • Belden P/N 8104 (with overall shield) • Belden P/N 9728 (individually shielded) • Belden P/N 8164 (individually shielded with overall shield) • Manhattan P/N M3477 (individually shielded with overall shield) • Manhattan P/N M39251 (individually shielded with overall shield) 	<ul style="list-style-type: none"> • Belden P/N 8103 (with overall shield) • Belden P/N 9730 (individually shielded) • Belden P/N 8163 (individually shielded with overall shield) • Manhattan P/N M3476 (individually shielded with overall shield) • Manhattan P/N M39250 (individually shielded with overall shield)

For Ethernet communications, use a Category 5 Ethernet connection to a standard 10BASE-T or 100BASE-TX Ethernet network. If you need a direct connection to a PC, use an Ethernet crossover cable.

Power Supply

Choose the power supply appropriate for the rack. E1 and E2 brain boards require 5.0–5.2 VDC at 0.5 amps (see note). Although it is possible to distribute DC from a common power supply to several locations, better noise immunity is obtained by having separate power supplies for each I/O unit. For more information, see Opto 22 form #1271, *Using Power Supplies with Opto 22 Systems Technical Note*.

NOTE: For all Opto 22 products that require 5 VDC, we recommend adjusting the power supply so that the Opto 22 products are receiving 5.10–5.20 VDC. This recommendation is based on years of experience and will eliminate many startup and maintenance issues.

Analog racks also require +15 VDC and -15 VDC (± 0.25 VDC) to power the analog I/O modules. The amount of power required depends on the type and number of analog I/O modules that are plugged into the rack. Power requirements for each of the analog modules are included in the module specifications.

Analog racks also provide terminals for a separate +24 volt supply that can be used for powering 4–20 mA current loops using 4–20 mA analog I/O modules. For this type of application, the +24 volt supply is required in addition to the supplies mentioned above. Refer to the module data sheets for information on wiring 4–20 mA modules with a loop supply.

The current requirements given for the output modules are only for the modules. To determine what size power supply is needed, add the load requirements for each module to determine total power supply requirements.

NOTE: Use only isolated supplies. Isolated supplies reduce the risk of ground loops in the communication wiring. Do not connect the power supply's DC common to earth ground. Linear power supplies are recommended. See Opto 22 form #1271, for more information.

3: Architecture and Communication

This chapter describes the options you have for communicating with E1 and E2 brain boards, illustrates system architecture for the E1 and E2, and discusses options to change from serial B1 or B2 systems to E1 or E2 Ethernet systems.

It includes the following topics:

Communication Options	(below)
System Architecture	page 26
Migration Options	page 32

Communication Options

Each E1 and E2 can communicate with a host through its serial port, its Ethernet port, or both, using a variety of protocols. The Optomux protocol can be used on both serial and Ethernet networks; other protocols are also available on Ethernet. You can use all of the Ethernet and serial protocols shown in the table below simultaneously.

The protocols and networks have specific advantages and disadvantages, summarized below.

Protocol & Network	Advantages	Disadvantages	See
Optomux over Ethernet	All possible brain board features are available. Ethernet network allows multiple hosts and more than 256 I/O units.		page 27
OPC over Ethernet	OPC clients communicate to E1 and E2 via OptoOPCServer . Can be used simultaneously with Optomux control software running over Ethernet or serial.	Brain board features are somewhat limited.*	page 28
Modbus/TCP over Ethernet	E1 and E2 become part of a Modbus/TCP system. Can be used simultaneously with Optomux control software running over Ethernet or serial.	Brain board features are somewhat limited.*	page 29

Protocol & Network	Advantages	Disadvantages	See
OptoMMP over Ethernet	E1 and E2 can be part of an PAC Project control system. Custom applications can be built for E1, E2, and other Opto 22 memory-mapped devices, such as SNAP PAC brains. Ethernet network allows multiple hosts and more than 256 I/O units.	Brain board features are somewhat limited.*	PAC Project: page 29 OptoMMP: page 31
Optomux over serial	All Optomux protocol features are available.	Limited to one host and 256 I/O units. Host must be on the serial network.	page 32

* No pulsing or time delay on E1; no input averaging or waveform generation on E2.

Accessing E1 and E2 Brain Boards Over the Internet

Since E1 and E2 brain boards operate like any other device on an Ethernet network, you can access them over the Internet in exactly the same way you would access a computer. Remote monitoring, data acquisition, and control applications can communicate with the brain boards over the Internet. The details of doing so depend on your network and Internet connection. Consult your system or network administrator or your Internet Service Provider (ISP) for more information.

System Architecture

E1 and E2 brain boards provide processing power for Opto 22 input/output (I/O) modules. E1 brain boards support digital I/O modules, and E2 brain boards support analog modules.

Digital—The E1 can be used with single-point G4 or G1 modules, four-point Quad Pak modules, or integral racks (digital I/O built into the rack).

Analog—The E2 can be used with single-point G1 modules.


The combination of brain board, I/O modules, and mounting rack is often referred to as an *I/O unit*.

Because E1 and E2 brain boards communicate over both serial and Ethernet networks, you can use them for remote monitoring, data acquisition, and industrial control using Optomux, OptoOPCServer, Modbus/TCP, and software applications built with Opto 22's PAC Project software suite (requires an Opto 22 SNAP PAC industrial controller). OPC and PAC Project applications use Opto 22's memory-mapped protocol, OptoMMP. The following sections include information and architectural diagrams illustrating these uses.

Typical Control System Using Optomux

Optomux Over Ethernet

A control system using the Optomux protocol and running over an Ethernet network is a typical use for E1 and E2 brain boards. E1s and E2s use UDP for Ethernet communication. Here is an example of such a system:




Optomux Over Serial

Since E1 and E2 brain boards also support RS-422/485 serial networks, they can communicate using the Optomux protocol over serial. Programming information for this use is in Opto 22 form #1572, the *Optomux Protocol Guide*.

Control System Plus Data Acquisition via OPC


Use [OptoOPCServer](#) to provide communication between E1 and E2 brain boards and OPC clients. OptoOPCServer is a fast, efficient OLE for Process Control (OPC) 2.0-compliant server available for purchase through Opto 22's distributors or on Opto 22's website, www.opto22.com. Documentation for the server is included.

A control system that's also serving data to OPC clients might look like this:



Communicating with Modbus/TCP Clients

Complete information to communicate with Modbus/TCP clients is in [Chapter 5: Using Modbus/TCP](#). Here is an example of system architecture:



PAC Project Control System

E1 and E2 brain boards can be used as part of a complete SNAP PAC System, with an Opto 22 SNAP PAC programmable automation controller, SNAP I/O units, and control and HMI applications you have built using the PAC Project Software Suite. The suite comes in two forms: PAC Project Basic™ and PAC Project Professional™.

[PAC Project Basic](#) is free from our website, www.opto22.com, and includes:


- **PAC Control™**, a flowchart-based programming tool for machine control and process applications. You build the control strategy, download it to a SNAP PAC industrial controller, and it runs independently on the controller.
- **PAC Display™**, an HMI package for building operator interfaces for your Microsoft® Windows®-based clients. PAC Display includes alarming, trending, security, and a built-in library of industrial graphics.
- **PAC Manager™**, a utility application used to assign IP addresses, configure I/O points and I/O unit features, and inspect, read from, or write to I/O units.

[PAC Project Professional](#) is available for purchase from our distributors or on Opto 22's website. The Pro version adds:

- **OptoOPCServer™**, a fast, efficient OPC 2.0-compliant server.
- **OptoDataLink™**, for exchanging data with common databases such as Microsoft SQL Server® and MySQL®.
- Support for legacy mistic I/O units, redundant controllers, and complex networks.

Complete documentation is included with the software suite. For E1s and E2s, use the Legacy Editions of all guides; for example, *PAC Control User's Guide, Legacy Edition* (form #1710); *PAC Control Command Reference, Legacy Edition* (form #1711); and *PAC Manager User's Guide, Legacy Edition* (form #1714).

An example of a SNAP PAC System incorporating E1s and E2s is shown below.



Building Custom Applications with the OptoMMP Protocol

If you do not want to use Optomux and are not using an Opto 22 controller, you can communicate with the E1 and E2 over Ethernet using custom applications you have written with OptoMMP, Opto 22's memory-mapped protocol. This protocol is open and documented, and [two free software development kits \(SDKs\)](#) are available on our website, one for C++ and one for .NET.

NOTE: Some E1 and E2 features are available only using Optomux. For details, see "E1 and E2 Features and Specifications" on page 5.

OptoMMP is the same protocol used with all current Opto 22 Ethernet-based hardware and software. Therefore, custom applications you build using OptoMMP can consolidate E1s and E2s with SNAP Ethernet-based systems, and applications you may have already built for SNAP Ethernet-based systems can be easily expanded to include E1s and E2s.

Documentation for each SDK is included in the kit. Opto 22 form #1465, the *OptoMMP Protocol Guide*, provides complete documentation of the memory map.

Migration Options

E1 and E2 brain boards provide processing power for I/O just like their predecessors, the B1 and B2 brain boards. Designed as drop-in replacement boards for the B1 and B2, the E1 and E2 have the same Optomux and serial network capabilities, but also add significant features: Ethernet support, additional protocol support, and migration and expansion opportunities.

Since the E1 and E2 were designed to be interchangeable with existing B1s and B2s, you can simply remove an older brain board from the rack and replace it with an E1 or E2. Your Optomux application will run on the E1 or E2 without any software changes.

With its additional capabilities, however, the E1 or E2 is ideal for migrating to newer networks, hardware, and software applications, as it has the flexibility to work with both older and newer networks and protocols.

If you are using E1 or E2 brain boards to migrate from an existing Optomux system using B1 or B2 brain boards, the protocol and network you choose are determined by your goals for the system. The following table shows how to accomplish specific migration goals with the E1 and E2 and refers you to sources for more information.


Your goal	Hardware and network changes	Software changes	See
Keep existing software running over serial. Add Ethernet capability so you can acquire data from the system using OPC.	Replace B1s and B2s with E1s and E2s, keeping same racks and I/O. Keep serial network; add Ethernet network and OPC host computer.	Existing software continues to run over serial. Use OptoOPCServer to acquire system data from E1s or E2s over Ethernet.	Architecture: page 33 Programming: <i>OptoOPCServer User's Guide</i> (form #1439)
Keep existing software running over serial. Add Ethernet capability so that Modbus/TCP clients can communicate with the system.	Replace B1s and B2s with E1s and E2s, keeping same racks and I/O. Keep serial network; add Ethernet network.	Existing software continues to run over serial. Use Modbus/TCP to communicate with E1s or E2s over Ethernet.	Architecture: page 33 Programming: Chapter 5 in this guide
Keep existing software running over serial. Add Ethernet capability so you can extend the system beyond serial network physical limitations.	Replace B1s and B2s with E1s and E2s, keeping same racks and I/O. Retire serial network except for first link; add Ethernet network.	Existing software continues to run over serial. Configure first E1 or E2 as a serial-to-Ethernet router.	Architecture and Programming: See "A: Serial-to-Ethernet Routing" on page 63 .
Replace serial network with Ethernet network, but continue using Optomux protocol.	Replace B1s and B2s with E1s and E2s, keeping same racks and I/O. Replace network.	Modify or replace current software using the Optomux Protocol Driver.	Architecture: page 27 Programming: <i>Optomux Protocol Guide</i> , form #1572
Replace serial network with Ethernet network. Use PAC Project with an Opto 22 industrial controller to control the system.	Replace B1s and B2s with E1s and E2s, keeping same racks and I/O. Replace network. Add SNAP PAC controller. (Optional) Expand system to include SNAP hardware.	Replace current control software with software built using PAC Control™. (Optional) Add an HMI or OPC support using other PAC Project software applications.	Architecture: page 29 Programming: <i>PAC Control User's Guide</i> (form #1710) and <i>Command Reference</i> (#1711)

Acquiring Data Using OPC

You can use OPC to acquire data from E1 and E2 brain boards without disturbing your existing software. OptoOPCServer can serve data from E1s and E2s over Ethernet separately from the software running over the serial network.

As shown below, simply replace the existing B1s and B2s with E1s and E2s, keeping the same racks and I/O, and link the E1s and E2s to the Ethernet network. Because the new brain boards have a serial port, they work exactly like the old ones over serial, and your existing Optomux software application needs no changes.

Use OptoOPCServer (sold separately) to acquire system data from E1 and E2s over the Ethernet link, and to read and write data to E1 and E2s. See the *OptoOPCServer User's Guide* (form #1439) for more information.




Adding Modbus/TCP Communication

You can communicate with the E1 and E2 using Modbus/TCP over Ethernet without disturbing the existing software running over serial.

Replace the existing B1s and B2s with E1s and E2s as shown below, keeping the same racks and I/O, and attach the new brain boards to the Ethernet network. Because the E1s and E2s have a serial port with the same capabilities as the B1 and B2, your existing Optomux software application does not need to be changed.

Modbus/TCP clients can read and write to E1 and E2s over the Ethernet network. For more information, see [Chapter 5: Using Modbus/TCP](#).



4: Maintaining the E1 and E2

This chapter describes how to maintain E1 and E2 brain boards. It includes the following topics:

Assigning or Viewing the IP Address	(below)
Resetting the Brain Board to Factory Defaults	page 35
Loading New Firmware	page 37

Assigning or Viewing the IP Address

Any E1 or E2 used with PAC Project software (PAC Control, PAC Display, or OptoOPCServer) or applications built with the OptoMMP Communication Toolkit or the Optomux Driver Toolkit must be assigned a static IP address, because you will use the IP address to communicate with the device. For more information about IP addresses and instructions to assign them, see the *Legacy Edition PAC Manager User's Guide*, form #1714.

Resetting the Brain Board to Factory Defaults


If you need to reset an E1 or E2 brain board to factory default settings, you can do so using a jumper. *When you reset the brain board, any files and configuration settings are erased.* If you only need to reset points to their defaults, see the instructions in the *PAC Manager User's Guide*.

NOTE: Other jumpers on the E1 and E2 (groups A and B) are used to configure the brain board. For information on setting the Group A and Group B jumpers, see "Setting Jumpers (Serial Only)" on page 19. Also see "Jumper Tips" on page 57.


To reset the brain board to factory defaults:

1. Turn off power to the brain board and remove the Ethernet connector.
2. Using needle-nosed pliers, install a jumper as follows:

- For the E1 brain board, use pins 3 and 4 on jumper block J5.



- For the E2 brain board, use pins 3 and 4 on jumper block J3.




3. Turn on power to the brain board.
The Status LED starts blinking. The Status LED is labeled STAT on the board and is shown in the graphic above.
CAUTION: Do not turn off power to the brain board while the STAT LED is flashing! Doing so may corrupt the brain board firmware. In most cases, you will need to wait about 5 minutes or less. However, if your brain board has version R1.1e firmware, you may need to wait a very long time, even overnight. Be patient and wait till the STAT LED stops flashing.
4. Wait until the light stops blinking and is solidly on (in approximately 30 seconds), and then turn off power to the brain board.
For more information on LEDs and blink codes, see [“LED Descriptions” on page 10](#).
5. Remove the Reset to Factory Defaults jumper, and reconnect the Ethernet cable.
6. Before turning on power to the brain board, follow the steps in form #1714, the *Legacy Edition PAC Manager User’s Guide*, to assign a new IP address.

Loading New Firmware


Each E1 and E2 brain board contains firmware (sometimes referred to as the *kernel*), which is similar to an operating system. If the firmware should become damaged, or if a new version of the firmware is released, you can load new firmware to the E1 or E2 device using PAC Manager.


1. Before beginning, make sure you have the IP address(es) of the E1s and E2s that will receive the new firmware.
2. Choose Start > Programs > Opto 22 > PAC Project Software > PAC Manager.


The PAC Manager main window opens:




3. Click the Maintenance icon .



4. If you have files on the E1 or E2 that you want to preserve, download them now.
For example, if you are using the Optomux routing capabilities and have uploaded the OmuxSettings and OmuxRoutes files to the brain, you may want to copy these files to your computer. For a description of how to do this, see [step 3](#) on [page 67](#).
5. Make sure Install Firmware is highlighted in the Command list.
6. If you do not have the new firmware file, click Get Latest Firmware to go to the Opto 22 website. In the Search Downloads field, type `E1` for E1 firmware or `E2` for E2 firmware. Click the links to download the firmware file and save it to your computer.
If you have any difficulty obtaining new firmware, contact Opto 22 Product Support.
7. Click the Browse button . From the drop-down list for Files of Type, select E1/E2 Firmware (*.bin). Locate the firmware file you downloaded from our website, and then double-click the filename.
The Filename appears in the Filename field.
8. If the IP address(es) of the target E1 and E2 devices appear in the IP Addresses list, skip to [step 10](#). (Or, if you have previously saved a list of IP addresses, click Load to load the saved list.) If the address(es) you need don't appear in the list, click Add.



9. Enter the address or a range of consecutive addresses, and then click OK.
The address(es) you entered appear in the I/O Unit Maintenance dialog box.
10. In the I/O Unit Maintenance dialog box, highlight the IP addresses to send firmware to.



CAUTION: If you mistakenly enter the address of some other E1 or E2, you will erase the current firmware in that device, and there is no undo. Make certain you have the correct IP addresses and that you want to download new firmware.

11. Click the Execute button.

The file is loaded to the brain boards, and progress is shown in the Results area. When the file is loaded and the brain boards are automatically rebooted, a “Success” message appears.

CAUTION: Do not turn off power to the brain board while the STAT LED is flashing! Doing so may corrupt the brain board firmware. In most cases, you will need to wait about 5 minutes or less. However, if your brain board has version R1.1e firmware before the update, you may need to wait a very long time, even overnight. Be patient and wait till the STAT LED stops flashing.

12. After installing new firmware, reconfigure all of the I/O and reset the calibration settings (offset and gain).

Also, if you are using the routing capabilities, you need to replace the OmuxSettings and OmuxRoutes files. For a description of how to do this, see [Appendix A: Serial-to-Ethernet Routing](#).

5: Using Modbus/TCP

Introduction

This chapter includes instructions for using Modbus/TCP to communicate with E1 and E2 brain boards. It includes information on Modbus communication and working with I/O points, and it includes the Modbus memory map for the brain boards.

The following topics are included in this chapter:

Overview of Modbus/TCP Communication	(below)
Referencing I/O Points for E1 and E2 Brain Boards	page 45
Configuring I/O Points	page 46
Modbus/TCP Memory Map for E1 and E2 Brain Boards	page 48

This chapter assumes that you already have an understanding of Modbus/TCP programming and communications. Use this chapter in conjunction with the *Open Modbus/TCP Specification* and the *Modicon Modbus Protocol Reference Guide*, both available from Modicon, Inc., Industrial Automation Systems.

Overview of Modbus/TCP Communication

Communicating with E1 and E2 brain boards using Modbus/TCP requires four basic steps: connect, configure, read/write, and disconnect. When opening a TCP/IP connection to an E1 or E2 system, you normally use port 502.

Up to eight Modbus masters or clients can be simultaneously handled by E1 and E2 brain boards. When communicating with a master, use a slave address (Unit ID) of 1 or 0 for the brain board.

Understanding Opto 22 and Modbus/TCP Differences

Notice that Opto 22 module position numbers start numbering at 0 (zero), while Modbus coil, input, and register numbers start at 1; so Modbus coil 1, input 1, or register 1 refers to the module in

position 0 on the rack. To reduce confusion, use the I/O reference diagrams starting on [page 45](#) when working with Modbus.

Also notice the differences in Opto 22 and Modbus terms:

Modbus Term	Opto 22 Term	Modbus Term	Opto 22 Term
Coils	Digital outputs	Register inputs	Analog inputs
Inputs	Digital inputs	Holding registers	Analog outputs and miscellaneous

Function Codes Supported

E1 and E2 brain boards use the Modbus register number and function code to access the appropriate memory map location on the brain board.

The following table shows supported Modbus function codes:

Modbus Command (Hex)	Definition	Opto 22 Equivalent
01	Read coil status	Read digital output
02	Read input status	Read digital input
03	Read holding registers	Read analog output and miscellaneous
04	Read input registers	Read analog input
05	Force single coil	Turn on/off one digital output
06	Preset single register	Write one analog output or miscellaneous
0F	Force multiple coils	Turn on/off multiple digital outputs
10	Preset multiple registers	Write multiple analog outputs or miscellaneous
11	Report slave ID	Report hardware and firmware revision levels

NOTE: Command 0x11, Report slave ID, returns data bytes as shown in the following table. Bytes 1 and 2 are always in the formats shown. The 0x22 in byte 1 indicates an Opto 22 brain board; 0xFF appears in byte 2 because, since the brain board is a slave, it is always running.

The data in the following table is in hex.

Byte 1	Byte 2	Bytes 3–6				Bytes 7–10				Bytes 11–14			
Slave ID	Run Indicator	Hardware Version				Firmware Version				Loader Version			
		Month	Day	Year		Month	Day	Year		Month	Day	Year	
22	FF	01	01	01	01	01	01	01	01	01	01	01	01

Communication Packet

As the Modbus/TCP specification requires, E1 and E2 brain boards use a Modbus RTU packet inside TCP/IP. The Modbus checksum is not used; instead, the Ethernet TCP/IP link layer checksum guarantees data. The size of the packet is limited to 256 bytes. The packet follows the standard Modbus format and contains the following:

Byte 0	Identifier, copied by responder (usually 0)
Byte 1	Identifier, copied by responder (usually 0)
Byte 2	Protocol identifier = 0
Byte 3	Protocol identifier = 0
Byte 4	Length field (upper byte) = 0, since all messages are smaller than 256
Byte 5	Length field (lower byte) = number of bytes following
Byte 6	Unit identifier (slave address, normally 1)
Byte 7	Modbus function code (See table on page 42.)
Byte 8 and following	Data as needed

NOTE: You can read a maximum of 125 input or holding registers in one command 03 or 04.

Exception Errors

If an error occurs, standard Modbus exception codes are returned in the Modbus packet. See the Modicon documentation for more information.

The following table, reprinted from the *Modicon Modbus Protocol Reference Guide*, shows the Modbus exception codes:

Code	Name	Meaning
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the slave.
02	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the slave.
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for the slave.
04	SLAVE DEVICE FAILURE	An unrecoverable error occurred while the slave was attempting to perform the requested action.
05	ACKNOWLEDGE	The slave has accepted the request and is processing it, but a long duration of time will be required to do so. This response is returned to prevent a timeout error from occurring in the master. The master can next issue a Poll Program Complete message to determine if processing is completed.
06	SLAVE DEVICE BUSY	The slave is engaged in processing a long-duration program command. The master should retransmit the message later when the slave is free.

Code	Name	Meaning
07	NEGATIVE ACKNOWLEDGE	The slave cannot perform the program function received in the query. This code is returned for an unsuccessful programming request using function code 13 or 14 decimal. The master should request diagnostic or error information from the slave.
08	MEMORY PARITY ERROR	The slave attempted to read extended memory, but detected a parity error in the memory. The master can retry the request, but service may be required on the slave device.


Referencing I/O Points for E1 and E2 Brain Boards

E1 brain boards can be used with a variety of digital module families; E2s are used with G1 analog modules only. However, the maximum number of points for either an E1 or an E2 brain board is 16 on the largest rack. When you use Modbus/TCP, point numbers are shown in the following examples. The largest rack is shown in each case.

E1 shown with G4 modules

Points on G1s and integral racks are numbered the same.

Module position on rack	Point numbers
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8
8	9
9	10
10	11
11	12
12	13
13	14
14	15
15	16



E2 with G1 modules


Module position on rack	Point numbers
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8
8	9
9	10
10	11
11	12
12	13
13	14
14	15
15	16



E1 with Quad Pak modules

Quad Pak modules have four input or four output points.

Module position on rack	Point numbers			
0	1	2	3	4
1	5	6	7	8
2	9	10	11	12
3	13	14	15	16



Configuring I/O Points

Before you can read or write to I/O points, you must configure point types and point features. See instructions in form #1576, *I/O Configuration for E1 and E2 Brain Boards*.

Using Digital Point Features

For explanations of digital point features, see “E1 Brain Board Features” on page 5.

Latches

Latches are a digital point feature available on E1 brain boards. They do not require configuration. Read and clear latches as shown in the following table and the Modbus memory maps beginning on page 48:

To do this	Use these addresses
Read the on-latch state	Read inputs 65–80
Read the off-latch state	Read inputs 129–144
Clear on-latches	Write to coils 129–144
Clear off-latches	Write to coils 193–208

Counters

Using counters involves three steps: configure the counter (holding registers 769-800), activate the counter (coils 65-80), and read data (input registers 385-416). See “Modbus/TCP Memory Map for E1 and E2 Brain Boards” on page 48 to find the addresses mentioned.

To do this	Use these addresses				
Configure a counter	Write to holding registers 769–800. Remember that you use two consecutive registers for each point, since the data is in the form of a 32-bit integer but the registers are 16 bits each. For example, to configure point #1 as a counter, you would write 01 to registers 769-770. To these registers: <table style="display: inline-table; border-collapse: collapse; vertical-align: middle;"> <tr> <td style="border-right: 1px solid black; padding: 0 5px;">769</td> <td style="padding: 0 5px;">770</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 0 5px;">Write this: 0</td> <td style="padding: 0 5px;">1</td> </tr> </table>	769	770	Write this: 0	1
769	770				
Write this: 0	1				
Activate a counter	Write to coils 65-80. For example, to activate the counter for point #1, you would write to coil number 65.				
Read counter data	Read input registers 385–416. Read two consecutive registers per point.				
Clear a counter	Write to coils 257–272. For example, to clear the counter on point #1, you would write a 1 to coil 257.				

Using Analog Point Features

For explanations of analog point features, see “E2 Brain Board Features” on page 6.

Analog point features generally require that you read or write two consecutive registers for each point, since the data is in the form of a 32-bit IEEE float. Data is in Big Endian format. You can change the word order if you wish, using Holding Register 1029, which is described in the table on page 50. If you change word order, be sure to store configuration information to flash (Holding Register 1026) so it will be saved when power to the brain board is cycled.

Scaling

You must scale analog points when you configure I/O. For instructions, see form #1576, *I/O Configuration for E1 and E2 Brain Boards*.

Maximum and Minimum Values (Peaks and Valleys)

Minimum and maximum values are analog point features. The brain board automatically keeps track of minimum and maximum values. For example, you can read the values at any time to record minimum and maximum pressures. You can also clear them.

NOTE: The E2 does not maintain minimum and maximum values for temperature.

- To read min/max values, read input registers 129–160 (min) and 257–288 (max). Read two consecutive addresses per point.
- To clear min/max values, write 1 bit to coils 321–336 (min) and 385–400 (max).

Offset and Gain

You can monitor current values for offset and gain using holding registers 129–160 and 257–288. To perform calibration on analog points, use PAC Manager. See form #1714, *Legacy Edition PAC Manager User's Guide*.

Modbus/TCP Memory Map for E1 and E2 Brain Boards

Coils

For digital I/O counter activation and clearing of latches, and analog minimum/maximum values: Each address contains the data for one point. Data is either 0 or 1.

Coil Numbers	E1	E2	Action	Notes
1–16 (available) 17–64 (unavailable)	●		Read or Write Digital Outputs	1 = On, 0 = Off
65–80 (available) 81–128 (unavailable)	●		Activate Counters (digital modules)	1 = On, 0 = Off. Configure as a point feature first. See "Counters" on page 46 .
129–144 (available) 144–192 (unavailable)	●		Clear On-latch (digital modules)	1 = clear latches; 0 = do nothing
193–208 (available) 208–256 (unavailable)	●		Clear Off-latch (digital modules)	1 = clear latches; 0 = do nothing
257–272 (available) 272–320 (unavailable)	●		Clear Counters (digital modules)	1 = clear counters; 0 = do nothing
321–336 (available) 336–384 (unavailable)		●	Clear Analog Minimum Values	1 = clear minimum values; 0 = do nothing
385–400 (available) 400–448 (unavailable)		●	Clear Analog Maximum Values	1 = clear maximum values; 0 = do nothing

Inputs

Digital inputs, latch states, and counter states: Each address contains the data for one point. Data is either 0 or 1. Digital inputs are available only on an E1.

Input Numbers	E1	E2	Action	Notes
1–16 (available) 17–64 (unavailable)	●		Read Digital Inputs	1 = On, 0 = Off
65–80 (available) 81–128 (unavailable)	●		Read State of On-latches (digital modules)	1 = On, 0 = Off
129–144 (available) 145–192 (unavailable)	●		Read State of Off-latches (digital modules)	1 = On, 0 = Off
193–208 (available) 209–256 (unavailable)	●		Read Counter Active State (digital modules)	1 = Active, 0 = Inactive

Input Registers

Analog input values and digital counter values. Register data is in the form of 32-bit floats or 32-bit integers. Because Modbus registers contain only 16 bits, you must use two consecutive registers to read the data for one point, starting with an odd-numbered register. See the example on [page 51](#).

Register Numbers	E1	E2	Action	Notes
1–32 (available) 33–128 (unavailable)		●	Read Analog Values	IEEE 32-bit float
129–160 (available) 161–256 (unavailable)		●	Read Analog Minimum Values (Inputs only)	IEEE 32-bit float
257–288 (available) 289–384 (unavailable)		●	Read Analog Maximum Values (Inputs only)	IEEE 32-bit float
385–416 (available) 417–512 (unavailable)	●		Read Digital Counter Data (digital modules)	32-bit integer

You can read a maximum of 125 registers in one command.

Holding Registers

Analog output values, point and feature configuration, and miscellaneous. Most of this data is also in the form of 32-bit integers or 32-bit floats. For these formats, you must use two consecutive registers to read or write the data for one point, starting with an odd-numbered register. See the example on [page 51](#).

Holding Register Numbers	E1	E2	Action	Notes
1–32 (available) 33–128 (unavailable)		●	Read or Write Analog Outputs (Engineering Units)	IEEE 32-bit float
129–160 (available) 161–256 (unavailable)		●	Analog Offset	IEEE 32-bit float
257–288 (available) 289–384 (unavailable)		●	Analog Gain	IEEE 32-bit float
385–416 (available) 417–512 (unavailable)		●	Set Point Low Scale Value	IEEE 32-bit float
513–544 (available) 545–640 (unavailable)		●	Set Point High Scale Value	IEEE 32-bit float
641–672 (available) 673–768 (unavailable)	●	●	Configure Points	32-bit integer (For information on configuring points, see form #1576, <i>I/O Configuration for E1 and E2 Brain Boards</i> .)
769–800 (available) 801–896 (unavailable)	●		Configure counters on digital input modules	32-bit integer (See page 46 for information on using counters.)
897–1024			Reserved	Reserved
1025		●	Set Degrees in F or C	16-bit integer. 1 sets degrees in F; 0 sets degrees in C.

Holding Register Numbers	E1	E2	Action	Notes
1026	●	●	Store Configuration to Flash	16-bit integer. Any non-zero value stores configuration to flash, so it is restored when the brain board is turned on. 0 = no action. Stores the contents of Status Write, Point Config, and IP Security Config. Also stores IP information, including IP address, subnet mask, gateway address, and DNS address.
1027	●	●	Reset Points to Default	16-bit integer. Any non-zero value resets the brain board to defaults as follows: <ul style="list-style-type: none"> • Clears offsets and gains, counters, latches, and min/max data. • Turns off digital outputs. • Sets analog outputs to zero scale (0 counts). • (1027 is equivalent to 1028 followed by 1030. See 1030 below.)
1028	●	●	Erase Configuration in Flash	16-bit integer. Any non-zero value clears flash.
1029	●	●	Set 32-bit Float Format	16-bit integer. 0 = Big Endian; 1 = Word-swapped Big Endian.
1030	●	●	Hardware Reset	Using Modbus Command 06 (Preset Single Register), write any non-zero value to reset hardware, which is just like cycling power to the brain board. If point configuration information has not been stored to flash or flash has been cleared (1028), points are reset to defaults. Reading always returns 0.

You can read a maximum of 125 registers in one command.

Using Input and Holding Registers

An example may help clarify how to use input and holding registers. Holding registers 1–31 are used to read or write analog values for 16 possible points. The first point is located in the first two registers, 1 (the low register) and 2 (the high register).

To figure out the Modbus register numbers for a specific analog point, use the following formula:

$$\text{Modbus low register number} = (\text{analog point number} * 2) - 1$$

Remember that modules on the rack start with position 0, but that I/O points for Modbus start with point 1. For example, to read point #1 (position 0) and point #9 (position 8):

For point #1:

$$\begin{aligned}(1 \times 2) - 1 &= 1 \text{ for low register} \\ &= 2 \text{ for high register}\end{aligned}$$

For point #9:

$$\begin{aligned}(9 \times 2) - 1 &= 17 \text{ for low register} \\ &= 18 \text{ for high register}\end{aligned}$$

Since the first register is odd-numbered, a read should always begin with an odd-numbered register. You can read a maximum of 125 registers in one command.

6: Troubleshooting

If you are having difficulty using an E1 or E2 brain board, here are some suggestions that might help. If you cannot find the answers you need in this book, contact Opto 22 Product Support. Contact information is on [page 4](#).

This chapter includes the following topics:

Troubleshooting Ethernet Communications	below
Troubleshooting Serial Communications	page 56
General Troubleshooting	page 60

Troubleshooting Ethernet Communications

If you attempt to connect to the brain board using its IP address and you cannot, first check the following:

- Make sure the brain board has been turned on and the Status LED is on. (See [“LED Descriptions” on page 10](#).)
- Make sure the brain board is firmly attached to the rack.
- Verify that you typed in the correct address for the brain board. Check the small white area next to the Ethernet port on the brain board, where the IP address should be written.
- Make sure the brain board has been assigned a valid IP address and subnet mask. E1 and E2 brain boards come from the factory with a default IP address of 0.0.0.0, which is invalid. The default subnet mask is 255.255.255.0. To assign the IP address and subnet mask, see form #1714, the *Legacy Edition PAC Manager User's Guide*.
- If you are communicating only on an Ethernet network (no serial connections), make sure that only jumpers A1-A4 and A10 are installed on the brain. If any other jumper configuration is used, the RS-485 communication lines may cause interference. See [page 22](#) for more information.
- Make sure you have up-to-date drivers installed on your computer's Network Interface Card (NIC). Contact your system administrator or the manufacturer of the card for help.
- Make sure you have Administrator privileges on your computer and that any firewall in the computer (such as the built-in firewall in Windows XP) is temporarily disabled before you try to

assign or change IP addresses, load firmware using PAC Manager's Maintenance window, or FTP files to the brain board. DHCP and FTP cannot function through a firewall in the PC. Firewalls in a router are less likely to be a problem unless certain ports (such as FTP client) have been blocked, either by default or on purpose.

Pinging the Brain Board

If you still cannot communicate with the brain board after you have checked these items, try to reach it using the PING protocol.

1. Open an MS-DOS command prompt window.
2. At the prompt, type: `ping [brain board's IP address]`

For example, type: `ping 10.192.54.40`

If the brain board responds, go to ["Accessing the Brain Board with PAC Manager" on page 54](#).

If the PING command cannot be found, choose Start > Control Panel > Network. Make sure TCP/IP is configured as a protocol and that an IP address and subnet mask are assigned.

If you see the message "Destination host route not defined," the brain board probably has an inappropriate IP address and subnet mask. Make sure the IP address and subnet mask on the brain board are compatible with those on the computer. Follow the directions beginning on [page 35](#) to check the IP address and subnet mask on the brain board, and change them if necessary.

If you see the message "No response from host," check the following:

- Are the computer and brain board correctly connected? Is the brain board turned on?
- Are the IP address and subnet mask on the brain board compatible with those on the computer?
- Is the brain board in reset mode? (Check for a blinking STAT LED. STAT LED blink codes are shown on [page 11](#).)


If you still cannot ping the brain board, contact Opto 22 Product Support. (See [page 4](#).)


Accessing the Brain Board with PAC Manager

Once you know you can ping the brain board, try to access it using PAC Manager. You will need to know the brain board's IP address.


1. If PAC Manager is not already open, choose Start > Programs > Opto 22 > PAC Manager.

The PAC Manager main window opens:



2. In the PAC Manager main window, click the Inspect button .
3. In the IP Address field, type the IP address of the brain board (or choose it from the drop-down list).
4. Click Status Read.

Information from the brain board is displayed in the window:



Date and time data was last read

Click to update data

If information does not appear and an error is indicated in the Status field, contact Product Support. (See [page 4](#).)

Solving Network Problems

If problems in communicating with the E1 and E2 recur, check your network. The wires, switches, and so on in your Ethernet network are not part of the Opto 22 hardware, but any problems in your network may affect communication with Opto 22 products.

Create a Network Diagram

First, create a network diagram and verify the following:

- Cable connectors are firmly inserted.
- The switch has power. Switch LEDs indicate that the connection is up.
- Neither the PC nor the I/O unit uses the switch's uplink port.
- The brain board's Link LED is lit.

Analyze Communication Packets

If it appears that you have network problems, you can use a network sniffer utility, such as Wireshark (<http://www.wireshark.org/>) to log and analyze network communication packets.

Have Your Network Certified

If you suspect network problems, you may need to have your network professionally certified. Opto 22 does not offer network validation or certification services, but many network hardware manufacturers do. Contact the manufacturer of your Ethernet network hardware to have them diagnose, fix, and certify your network.

If you continue to have problems communicating with the E1 and E2 after your network is certified, contact Opto 22 Product Support. (See [page 4](#).)

Troubleshooting Serial Communications

Solving Common Communications Errors

Use this section to diagnose the most common causes of communication problems:

- 5 VDC power adjusted too low at brain boards
- Incorrect jumper settings
- Wiring problems

For error codes that might appear when using Optomux, see [page 59](#).

Power Tips

1. Ensure that the 5 VDC power supply wiring *connections* are secure.
2. Ensure that the *voltage* is 5.1-5.2 VDC as measured on the brain board. Check voltage at all the Optomux brain boards by measuring across a capacitor on the brain board itself, not across the power supply terminals. For more information, see form #1271, *Using Power Supplies*.

3. Ensure that the power supply has no ripple. If possible, inspect the power supply voltage with an oscilloscope, instead of using only a multimeter. Multimeters sometimes do not catch fast AC signals and transients.
4. Make certain that the power supplies are *floating*; that is, do *not* connect the power supply common (5 VDC return) to chassis/earth ground.
5. Make sure that the 5 VDC power supply common is *not* connected to the +/- 15 VDC common terminal on analog mounting racks; this can cause unstable analog readings.

Jumper Tips

1. Make sure the jumpers are intact. The red jumpers provided with Optomux brain boards consist of a metal jumper on the inside covered by red plastic. Sometimes the metal portion of the jumper separates from the red plastic piece, causing incorrect jumper settings even though the jumpers seem to look correct.

For example, if a jumper is removed but the internal metal pieces stay attached to the brain board, the jumper will look like it is removed, but the brain will detect that it is installed.

On the other hand, the jumper can appear to be installed when it is not. This happens when the red plastic part is installed but is missing the metal internal piece. In this case, the brain board will detect that the jumper is removed.

2. Make certain that the addresses are set correctly. No two brain boards on the same network can have the same address. If two or more brains on the same network have the same address, they will respond at the same time, causing a garbled response received at the host.
3. Make certain that the baud rates are set correctly. The host device and all brain boards must be operating at the same baud rate. A brain board set for the wrong baud rate will not respond.
4. Make certain the last Optomux brain board on the communications link has the correct termination jumpers installed (jumpers A0 and A6 for brains set up in multi-drop mode).
5. Make sure the host RS-422/485 device is configured to provide the correct termination and biasing.
 - The host receive pair (FO) must provide both termination and biasing, because this part of the link is RS-485.
 - The host transmit pair (TO) must provide for termination and possibly biasing, depending on the interface device. Check the following to make sure it is set up correctly:
 - The RS-422 transmit pair must provide end-of-line termination resistor.
 - If the transmitter is actually an RS-485 transmitter, then biasing resistors are also necessary.

NOTE: An RS-485 transmitter will be disabled (tri-stated) when not transmitting, so the transmit pair will “float” and might allow fluctuations to be interpreted as data or errors. However, an RS-422 transmitter will remain enabled in either high or low state when not actively transmitting data, so it is not possible for fluctuations, and thus, biasing is not needed.

NOTE: Some non-Opto 22 RS-422/485 interface products do not provide an option for termination and/or biasing. If the interface product does not provide the necessary options, then it will have to be replaced with one that does. Termination resistors can be applied externally, but biasing resistors typically cannot.

Communication Wiring Tips

1. Make sure to use a shielded, twisted-pair RS-422/485 communication cable with at least three twisted pairs as detailed below. If you use a cable with four twisted pairs, you will have one extra pair.
 - Two pairs for data (a transmit pair and a receive pair), and
 - One pair to use for the signal common
 - The signal common requires only one insulated conductor, but it is hard to find a cable with two pairs plus an extra insulated wire that is separate from the shield drain wire.
 - For the signal common, you can use both wires from the pair tied together or just one of the wires.
2. Ensure that the signal common is connected from one brain board to the next and also to the host RS-422/485 device. This must be done with an insulated wire, which is typically one wire in the overall communication cable.
3. Make sure that the COM terminal (signal common) on the brain boards is *not* connected to chassis/earth ground.
4. Ensure that the overall cable shield drain wire is connected to chassis/earth ground at one location only. Do *not* connect the shield drain wire to the COM (signal common) terminal on any brain board.
5. Make sure the communications cable is daisy-chained from brain to brain; no “Ts” are allowed under the RS-422/485 specification.
6. Make sure the communications pairs are not crossed. In some types of cable, one wire from each pair is the same color. This makes it very easy to get those wires mixed up. If you strip back the jacket and shield far enough, it will become clear which wire belongs to which pair.
7. Check the polarity of the + and – communication wires throughout each twisted pair. If you have one or more receive LEDs stuck on, this may be the cause. Incorrect biasing might also cause this.
8. Power down each brain board in the link, and check the resistance of each twisted pair. One basic check of the communication wiring in a multidrop system is to measure the resistance across the + and – lines of each twisted pair. There should be a 220 ohm resistor across the + and – wires of each data pair (transmit and receive) at each end of the cable. If both ends are terminated properly, you should see about 110 ohms, because there should be termination (220 ohms) at both ends. Make certain that in a multidrop system, only the last physical brain board on the communication link has jumpers A0 and A6 installed.
9. If using an RS-232 to RS-422/485 converter at the host end of the system, make sure that CTS handshaking is disabled on the host. Otherwise, jumper RTS to CTS at the host end. If RTS/CTS handshaking is enabled (and not jumpered), the host will not transmit; no data will be allowed to go out the computer's RS-232 com port.

Other Tips:

1. **Diagnostic/Test Utilities:** Test the system using one of the Optomux utilities, such as OptoScan, which can trap errors. Often, the errors received can help determine the nature of the problem. If OptoScan works properly and there are no errors, the cause of the problem might be the host software.
2. **Baud Rate:** Try running the system at a lower baud rate. Lower baud rates are more forgiving in a noisy environment.

3. **LED Indicators:** If you see receive LEDs blinking on the brain boards, but not transmit LEDs, the cause of the problem could be incorrect address or baud rate settings on one or more brain boards. It can also be caused by wiring problems, low voltage, or noisy power.
4. **Computer Issues:** If you are using an ISA bus RS-422/485 card in the host computer, make sure that there are no I/O port or IRQ conflicts.
5. **Loopback test:** If the host device is a PC, it is possible to verify the operation of the RS-422/485 port by jumping TX+ to RX+, and TX- to RX- (these are TO and FO on Opto 22 brain boards) at the computer. A communication program such as Windows Terminal or Hyperterminal can be used to test the communications with the port.

Make sure the terminal test utility is set up with flow control set to None and that the local echo is turned off. Once started, anything typed on the keyboard should be displayed on the screen. If this does *not* happen, there may be a hardware or configuration problem with the communication port. Also remember that Opto 22 ISA bus serial adapter cards do not use standard Windows COM port settings (I/O port base address and IRQ) for COM3 and COM4. Make sure that the host software is using the correct I/O port base address and IRQ.

6. Call Opto 22 Product Support. Contact information is on [page 4](#).

Error Codes When Using Opto 22 Optomux Driver

This is a list of the most common driver error codes relating to problems with the RS-422/485 network or brain boards. For a complete list, see form #1572, the *Optomux Protocol Guide*.

Errors Returned by the Brain Board

The following error conditions are caught by (generated by) the brain board.

–1 Power Up Clear Expected.

Command Ignored. A command other than “A” (Power-Up Clear) was attempted after power-up or power failure. Once the error is received, it is not necessary to execute a Power-Up Clear command. The next command will be executed normally. **IMPORTANT:** If this error message is received, it means that the Optomux unit has gone through its power-up sequence and has reset all characteristics to defaults. The unit needs to be reinitialized.

The brain contains a voltage watchdog circuit. If the 5 VDC logic supply voltage falls below the reset voltage, the brain will automatically reset. Use a high-quality DVM (Digital Volt Memory) or a high-precision oscilloscope to examine the brain's supply voltage. Power supply selection or design, poor power distribution techniques, or loose power wiring may cause spurious power-up-clear alerts. For more information, see form #1271, *Using Power Supplies*.

–3 Checksum Error.

This error indicates that the checksum received by the brain board did not match the checksum calculated by the brain board. The command message was corrupted while being transferred over the wire. Data corruption can occur due to improper wiring, termination, and/or radio frequency or electromagnetic noise.

–5 The brain received a non-printable ASCII character.

Only characters from 21 Hex to 7F Hex are permitted within Optomux messages. This error is most likely caused by some kind of data corruption. The command is ignored. Data corruptions may occur due to improper wiring, termination, and/or spurious radio frequency or electromagnetic noise.

Driver Errors

These are error conditions caught by (generated by) the driver.

-29 Turnaround Time Out.

The brain board did not respond within the specified time interval or did not respond at all. Timeouts occur if the timeout interval is too short or the brain board is not available. Possible causes of a brain board not being available include power/voltage problems, the brain board's jumper settings being incorrect (address, baud rate, 2/4 pass mode, termination, etc.), or there is a problem with the communication wiring.

-31 Checksum Error.

The checksum of the message received by the Optomux driver does not match the checksum calculated by the driver. Data corruption can occur due to improper wiring, termination, and/or radio frequency or electromagnetic noise.

-33 Send Error.

This error indicates that the Optomux driver cannot send the message. The most likely cause is a problem with the serial port being in use by another application.

-34 Incorrect Command Echo In Four-Pass.

The command echo does not match the command sent. The addressed brain board is probably in the two-pass mode. This error can occur only when the driver is configured for 4-pass mode. 4-pass mode was originally intended for diagnostic purposes, but it is generally not used even for that purpose. It is best to always use 2-pass mode.

Other Error Codes

These are error codes returned from brain when not using Opto 22 driver:

00 Powerup Clear Expected - Command Ignored. See "[-1 Power Up Clear Expected](#)" on [page 59](#).

02 Checksum Error. See "[-3 Checksum Error](#)" on [page 59](#).

General Troubleshooting

I send a command to activate several outputs. The brain board responds with no error, but none of my outputs comes on.

If an output point does *not* turn on, check the following:

- Make sure you configured the output points correctly. On power-up, the unit defaults to all points configured as inputs.
- If power went out and came back on, the unit will have lost its configuration.
- Make sure you are using output modules with a 5 VDC logic voltage (OAC5, ODC5, etc.). Sometimes modules with a 15 VDC or 24 VDC logic voltage (ODC15, OAC24, etc.) are used by

mistake. The LED may turn on or be dim with the 15 VDC and 24 VDC modules, but there will be no output on the field side.

- If the output LED is on, but the load does not turn on, check the field voltage, wiring, and fuse. This could result in a field device *not* turning on.

I send a command to turn on output point 5 of a digital brain board and output point 4 goes on.

Points are numbered from 0 to 15; therefore the fifth bit in the bitmask is for point 4. Following are the bitmask values for each point, in hex:

Point	Bitmask (Hex)	Point	Bitmask (Hex)
0	0001	8	0100
1	0002	9	0200
2	0004	10	0400
3	0008	11	0800
4	0010	12	1000
5	0020	13	2000
6	0040	14	4000
7	0080	15	8000

I'm using OptoMMP, and the counts returned are very different from what I expect.

Check the configuration on your E2. The OptoMMP protocol returns counts differently, based on how the E2 was configured. (See “E2 Brain Board Features” on page 6.)

- Modules configured directly as G1 modules (new method; requires E2 firmware R1.2a or higher and PAC Project 9.5 or higher) will report counts as G1 counts (0–4095 nominal range).
- Modules configured as similar SNAP modules (old method using form 1576) will report counts as 0–25000 or -25000 to +25000.

When I read point 3 on an E2 Optomux unit via the Optomux protocol, I receive 0000 hex, which converts to a decimal -4096 value when I subtract the 1000 hex offset.

A -4096 decimal reading may indicate one of the following:

- You are reading a point where no input module is installed.
- You are reading a point on a thermocouple module that has no thermocouple installed, or the thermocouple probe is open.
- An ICTD module has the ICTD wired in reverse.
- A 4–20 mA module is wired with reverse polarity.
- The field connections are made to the wrong terminals. Field connections vary with each module. Refer to the module data sheet for information on wiring each module. In general, field connections made to the terminals on the rack are made to the terminals labeled UPPER (closest to module), and if the module has terminals on the top of the module, connections would be made there. Analog racks have the module positions labeled from 1 to 16. These points correspond to module positions 0 to 15, respectively.

- If all inputs on that brain board have the same -4096 reading, then check to make sure the unit has +15 and -15 VDC at the corresponding terminals (with reference to the terminal that is marked COMMON).

Does Opto 22 have any troubleshooting software for the Optomux system?

Yes. Opto 22 has the OptoScan (oswin32.exe) and OmuxUser (omuxuser.exe) utilities that can be used to troubleshoot an Optomux system attached to a PC. These are Visual Basic 6 applications and are included with the Optomux Protocol Drivers and Utilities download. Source code is included as an example of Opto 22's Optomux driver DLLs. These applications include the ability to manually configure and poll a digital or analog brain board. The toolkit is available on Opto 22's website, www.opto22.com. For MS-DOS and Windows for Workgroup (WFWG) versions of OptoScan, contact Opto 22 Product Support.

Serial Communications Questions and Answers

I send a command message to a brain board, and I get no response. However, the unit's LED flashes.

The receive LEDs on all the brain boards wired in a multidrop mode should blink whenever a command is sent from the host. Only the unit at the address that matches the command message address should respond. When a brain board responds, the XMT (transmit) LED blinks. At high baud rates, and for messages with only a short response, the blink will be so brief that it may be missed visually.

If the host receives no response, and no blink of the XMT light is visible (even at slower baud rates), then check the following:

- Make sure the address in the command message matches the unit's address. Check the jumpers. A common mistake is a reversal of jumpers. All address jumpers (B0 through B7) installed corresponds to address 0, and all address jumpers (B0 through B7) removed corresponds to address 255. See "[Setting Jumpers \(Serial Only\)](#)" on [page 19](#).
- Make sure the baud rate is correct between the host and the unit. All brain boards on the same link should be configured to the same baud rate.
- Make sure you have a solid 5.1–5.2 VDC (as measured on the brain) powering the brain board. If the voltage is too low, the RCV light may flash, but the unit will not be able to respond. Measure the voltage across one of the yellow capacitors on the brain board. See form #1271, *Using Power Supplies*.
- Check to make sure the communications link is wired with the correct polarity and that jumper group A is configured correctly.

I receive a large number of checksum errors when I send commands to Optomux brains.

Make sure that you are using twisted pair cable. See the cables recommended on [page 23](#). The RS-422/485 network is reliable only when the communications cable is twisted pair (+ and – lines of EACH pair twisted together). If there are two or more wires in the cable with the same color (such as a red/black pair, a white/black pair), sometimes the same-colored wires may be associated with the wrong mates. To make sure the wiring is correct, strip the jacket back far enough to properly identify the individual pairs.

Also check the Group A jumpers to make sure the termination jumpers are configured correctly.


A: Serial-to-Ethernet Routing

If you need to keep existing serial-based host Optomux software, you can extend your system beyond the physical limitations of an RS-422/485 link by using an E1 or E2 to route control coming through a serial network to remote locations over Ethernet.

To do so, replace existing B1s and B2s with E1s and E2s, keeping the same racks and I/O. Keep the serial link from the host to the first E1's or E2's serial port, and put all the E1s and E2s on an Ethernet network. With an Ethernet network, the I/O units can be literally anywhere in the world.

This scenario is shown in the diagram on the following page.

Your existing Optomux application continues to run over serial without needing any changes; the first E1 or E2 translates communications between the host and all other I/O units. You can acquire data over Ethernet via OPC or Modbus/TCP at the same time.



This figure shows an E1 used as a serial-to-Ethernet router.

The host communicates to the first E1 or E2 over serial, using Optomux. The first brain routes communication to other E1 and E2 I/O units on the Ethernet network.

In this scenario, existing software running on the host does not have to be changed.

Serial-to-Ethernet Routing uses a routing table that resides on the first E1 or E2, in which each entry associates an Optomux address with an Ethernet host name or IP address, a protocol (currently UDP only), and a port. When an Optomux packet is received from the serial port, the brain board compares the Optomux address in the packet to the Optomux addresses in the routing table. If there's a match, the packet is forwarded to the appropriate device (including itself) via UDP/IP.

When the response is received via UDP, it is forwarded to the serial network. The maximum number of Optomux devices that can be accessed through serial-to-Ethernet routing is 256, because an Optomux host can communicate with no more than 256 devices. The E1 or E2 doing serial-to-Ethernet routing also behaves as an Optomux device on the RS-422/485 link.

To use serial-to-Ethernet routing, you need to follow the steps below to create the OmuxRoutes routing table and then enable serial-to-Ethernet routing in the OmuxSettings file.

Creating a Routing Table

The routing table is a text file that you can create or edit in Notepad and then transfer to the E1 or E2 using PAC Manager. The OmuxRoutes table should reside only on the first E1 or E2.

NOTE: PAC Manager uses FTP to transfer files. FTP cannot be used through a firewall in the PC. Make sure any firewall in the computer (such as the built-in firewall in Windows XP) is disabled before you try to transfer the file to the brain board. (Firewalls in a router should not be a problem.)

1. Open Notepad or any simple text tool and create a new file.
2. In the file, type one line for each Optomux address, in the following format:

```
[Optomux_address] [type]:[host name or IP address]:[port]
```

The space between [Optomux address] and [type] can be one or more spaces. The value for [type] is currently `udp`. The default value for [port] is 5000. (Change it only if port 5000 on the Ethernet network is already being used for another purpose.) Each entry must end with a carriage return.

For example:

```
42 udp:valve_control:5000
112 udp:10.192.55.61:5000
```


Alternatively, you can use commas as follows:


```
42,udp,valve_control,5000
112,udp,10.192.55.61,5000
```


A sample routing table is shown on [page 66](#).

3. Save the file with the filename `OmuxRoutes`

NOTE: An example of an OmuxRoutes file is provided on the CD that came with the brain board.

4. If PAC Manager is not already open, choose Start > Programs > Opto 22 > PAC Manager.
5. In the PAC Manager main window, click the Maintenance button .



6. In the I/O Unit Maintenance window, do the following to copy the OmuxRoutes file to the first E1 or E2:
 - a. In the Command list, choose Upload File To I/O Unit.
 - b. In the Filename field, click the browse button .
 - c. In the Open dialog, browse to the OmuxRoutes file, and double-click it to open it. The path and filename appear in the Filename field.
 - d. In the Destination field, type the name `OmuxRoutes`.
 - e. If the IP Address for the E1 or E2 is listed under IP Addresses, go to the next step. If the IP address is not in the list, click the Add button and add it.
 - f. Highlight the IP address, and click Execute. The updated OmuxRoutes file is copied to the E1 or E2, and the new settings take effect right away.
7. Continue with “[Enabling Serial-to-Ethernet Routing](#),” below, to change the OmuxSettings file.

Sample Routing Table

Following is a sample OmuxRoutes file. (Text after a # on any line is a comment.)

```
# Routing Entries for the system.
# Note that port 5000 is the default
# E1 UDP port.


4      udp:10.0.0.8:5000    # comment
5      udp:10.0.0.9:5000
6      udp:10.0.0.10:5000


# The following entry uses hostname instead of IP
# address.


55     udp:my_e1_hostname:5000
```

Enabling Serial-to-Ethernet Routing


NOTE: PAC Manager uses FTP to transfer files. FTP cannot be used through a firewall in the PC. Make sure any firewall in the computer (such as the built-in firewall in Windows XP) is disabled before you try to transfer the file to the brain board. (Firewalls in a router should not be a problem.)

1. If PAC Manager is not already open, choose Start > Programs > Opto 22 > PAC Manager.
2. In the PAC Manager main window, click the Maintenance button .



3. In the I/O Unit Maintenance window, do the following to copy the OmuxSettings file to your computer:
 - a. In the Command list, choose Download File From I/O Unit.
 - b. In the Filename field, type `omuxSettings`.
 - c. In the Destination field, click the browse button . The Save As window opens.
 - d. Browse to a convenient directory on the computer. Type `omuxSettings` and click Save. The path and filename appear in the Destination field.
 - e. Click the Add button. The Add IP Address window opens.
 - f. Enter the IP address of the E1 or E2 and click Save. The IP address appears in the IP Addresses list.
 - g. Select the appropriate IP address, then click the Execute button. The OmuxSettings file is copied to your computer.
4. Open the OmuxSettings file in Notepad or another simple text tool.

NOTE: An example of an OmuxSettings file is provided on the CD that came with the brain board.

 5. Add the text `SerialToEthernetRouting`
 6. Save the file as `omuxSettings`
 7. In PAC Manager's I/O Unit Maintenance window, do the following to copy the OmuxSettings file to the E1 or E2:
 - a. In the Command list, choose Upload File To I/O Unit.
 - b. In the Filename field, click the browse button . The Open File dialog opens.

- c. Browse to the OmuxSettings file, then click Open.
The path and filename appear in the Filename field.
- d. In the Destination field, type the name `omuxSettings`
- e. If the IP Address for the E1 or E2 is listed under IP Addresses, go to the next step. If the IP address is not in the list, click the Add button and add it.
- f. Highlight the IP address, and click Execute.
The updated OmuxRoutes file is copied to the E1 or E2, and the new settings take effect right away.

Disabling Serial-to-Ethernet Routing

To stop serial-to-Ethernet routing:

1. Open the OmuxSettings file.
2. Remove the text: `SerialToEthernetRouting`
3. Save the file.
4. Send the OmuxSettings file to the E1 or E2. See [“Enabling Serial-to-Ethernet Routing” on page 66](#).

B: Using the OmuxSettings File

About the OmuxSettings File

In addition to jumper settings, E1 and E2 brain boards are configured in the OmuxSettings file, a text file located on the E1 and E2. This file determines whether the E1 and E2 listen on the serial link or the Ethernet link (or both), whether Serial-to-Ethernet routing is enabled, and what happens to troubleshooting log files. The brain board will function using the default settings unless you change them as described below.

The default settings for the OmuxSettings file are as follows:


Setting	Default	Description
EthernetPort	5000	The UDP port number the E1 or E2 responds to for communications.
EthernetServer	enabled	Listens for Optomux commands (UDP) on the UDP port specified by EthernetPort.
SerialServer	enabled	Listens for Optomux commands on the Serial port.
SerialToEthernetRouting	disabled	When enabled, E1 or E2 can serve as a serial-to-Ethernet router. See Appendix A: Serial-to-Ethernet Routing .


Changing the OmuxSettings File


NOTE: PAC Manager uses FTP to transfer files. FTP cannot be used through a firewall in the PC. Make sure any firewall in the computer (such as the built-in firewall in Windows XP) is disabled before you try to transfer the changed OmuxSettings file to the brain board. (Firewalls in a router should not be a problem.)

1. If PAC Manager is not already open, choose Start > Programs > Opto 22 > PAC Manager.


The PAC Manager main window opens:



2. In the PAC Manager main window, click the Maintenance button . The I/O Unit Maintenance window opens:



3. In the I/O Unit Maintenance window, do the following to copy the OmuxSettings file to your computer:
 - a. In the Command list, choose Download File From I/O Unit.
 - b. In the Filename field, type `omuxSettings`

- c. In the Destination field, click the browse button . The Save As window opens.
- d. Browse to a directory on the computer, type `omuxSettings` and click Save. The path and filename appear in the Destination field.
- e. Click the Add button. The Add IP Address window opens.
- f. Enter the IP address of the E1 or E2, and click Save. The IP address appears in the IP Addresses list.
- g. Select the appropriate IP address, then click the Execute button. The OmuxSettings file is copied to your computer.

NOTE: An example of an OmuxSettings file is provided on the CD that came with the E1 or E2.

- 4. Open the OmuxSettings file in Notepad or another simple text tool.
- 5. Add, change, or delete the following communication items, depending on your needs:

To do this	Add/change/delete this text
Change the Ethernet port number	Add: <code>EthernetPort=[port number]</code>
Listen on the Ethernet link	Add: <code>EthernetServer</code>
Stop listening on the serial link	Delete: <code>SerialServer</code>
Enable Serial To Ethernet Routing	Add: <code>SerialToEthernetRouting</code>

- 6. Save the file as `omuxSettings`
- 7. In PAC Manager I/O Unit Maintenance window, do the following to copy the OmuxSettings file to the E1 or E2:
 - a. In the Command list, choose Upload File To I/O Unit.
 - b. In the Filename field, click the browse button.
 - c. In the Open dialog, browse to the OmuxSettings file, then click Open. The path and filename appear in the Filename field.
 - d. In the Destination field, type the filename `omuxSettings`.
 - e. If the IP Address for the E1 or E2 is listed under IP Addresses, go to the next step. If the IP address is not in the list, click the Add button and add it.
 - f. Highlight the IP address, and click Execute. The updated OmuxSettings file is copied to the E1 or E2, and the new settings take effect.

C: Licensing Information

Software Licenses Used in E1 and E2 Brain Boards

Some software used by Opto 22 E1 and E2 brain boards is subject to various software licenses. This appendix explains software licensing in more detail.

Opto 22 License Agreement for Embedded Software

This product contains copyrighted Opto 22 software covered by the Opto 22 License Agreement for Embedded Software. This software uses the uClibc library. The uClibc library is subject to the GNU Lesser General Public License.

Please see [“Opto 22 License Agreement for Embedded Software” on page 75](#) for the exact terms and conditions of the Opto 22 License Agreement for Embedded Software.

Please see [“GNU Lesser General Public License” on page 80](#) for the exact terms and conditions of the GNU Lesser General Public License.

GNU General Public License

This product includes copyrighted third-party software licensed under the terms of the GNU General Public License.

Please see [“GNU General Public License” on page 76](#) for the exact terms and conditions of the GNU General Public License.

Please see the Open Source Software distribution for this product, available at www.opto22.com, for a list of the parts of this product subject to GNU General Public License.

All third-party software packages are copyrighted by their respective authors. Please see the source code for detailed information.

Full source code of the GPL licensed software, including any scripts to control compilation and installation of the object code, is available in the Open Source Software distribution for this product at www.opto22.com.

GNU Lesser General Public License

This product includes copyrighted third-party software licensed under the terms of the GNU Lesser General Public License.

Please see “[GNU Lesser General Public License](#)” on page 80 for the exact terms and conditions of the GNU Lesser General Public License.

Please see the Open Source Software distribution for this product, available at www.opto22.com, for a list of the parts of this product subject to GNU Lesser General Public License.

All third-party software packages are copyrighted by their respective authors. Please see the source code for detailed information.

Full source code of the LGPL licensed software, including any scripts to control compilation and installation of the object code is available in the Open Source Software distribution for this product at www.opto22.com.

Berkeley Software Distribution License

This product includes copyrighted third-party software licensed under the terms of the Berkeley Software Distribution License:

Copyright (c) 1988, 1993, 1994

The Regents of the University of California. All rights reserved.

This code is derived from software written by Ken Arnold and published in UNIX Review, Vol. 6, No. 8.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

This product includes software developed by the University of California, Berkeley and its contributors.

4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Opto 22 License Agreement for Embedded Software

NOTICE TO USER: THIS IS A CONTRACT. CAREFULLY READ THIS AGREEMENT BEFORE USING THE DEVICE IN WHICH THE SOFTWARE IS INCORPORATED. BY USING THE DEVICE, YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS, DO NOT USE THE DEVICE. YOU MAY, WITHIN FIFTEEN (15) DAYS OF PURCHASE, REQUEST A FULL REFUND.

GRANT. You have acquired a device ("Device") that includes software components created and copyrighted by Opto 22, Inc. ("Opto 22"). The installed software of Opto 22 origin ("Software") is protected by international intellectual property laws treaties, as well as other intellectual property laws and treaties. The Software is licensed, not sold.

Opto 22 hereby grants to you a non-exclusive license to: (i) use the Software on the Device in which it is incorporated; (ii) transfer the Software to a recipient on a permanent basis provided the recipient agrees to the terms and conditions of this Agreement.

You may not: (i) modify, translate, reverse engineer, decompile, or disassemble (except to the extent applicable laws specifically prohibit such restrictions, and as expressly set forth in the section "OPEN SOURCE SOFTWARE") or create derivative works based on the Software, or any portion thereof; (ii) copy the Software (except for backup purposes); or (iii) use Opto 22's or Opto 22's suppliers' name, logos, or trademarks in any manner including, without limitation, in your advertising or marketing materials, except as is necessary to affix the appropriate copyright notices as required herein.

OPEN SOURCE SOFTWARE. The Software uses other software components that are subject to the GNU Lesser General Public License ("LGPL"). In compliance with the terms of the LGPL, Opto 22 makes its modifications to LGPL software that Opto 22 uses, modifies and distributes pursuant to the LGPL available in source code form to the public at www.opto22.com. You are free to use, modify and distribute software that is subject to the LGPL as long as you comply with the terms of the LGPL (available in the product manual or at www.gnu.org/copyleft/lgpl.html).

In compliance with the terms of the LGPL, Opto 22 makes its Software that dynamically links to LGPL software available as an executable file. You may modify the executable file for your own use, and reverse engineer the executable file for debugging such modifications.

TITLE. Title, ownership rights, and intellectual property rights in and to the Software shall remain in Opto 22 and/or its suppliers. The Software is protected by the copyright laws of the United States and international copyright treaties. Title, ownership rights, and intellectual property rights in and to the content accessed through the Software is the property of the applicable content owner and may be protected by applicable copyright or other law. This License gives you no rights to such content.

LIMITED WARRANTY. Opto 22 warrants that: (i) the Software will substantially conform to the accompanying documentation. Opto 22's sole liability, and your sole remedy, for any breach of this warranty shall be, in Opto 22's sole discretion: (i) to replace your non-conforming Software; or (ii) if the above remedy is impracticable, to refund the license fee you paid for the Software. Replaced Software shall be covered by this limited warranty for the period remaining under the warranty that covered the original Software, or if longer, for thirty (30) days after the date of shipment to you of the replaced Software. Only if you inform Opto 22 of your problem with the Software during the applicable warranty period and provide evidence of the date you acquired the Software will Opto 22 be obligated to honor this warranty. Opto 22 will use reasonable commercial efforts to replace or refund pursuant to the foregoing warranty within thirty (30) days of being so notified.

THIS IS A LIMITED WARRANTY AND IT IS THE ONLY WARRANTY MADE BY OPTO 22. OPTO 22 MAKES NO OTHER WARRANTY, REPRESENTATION, OR CONDITION, EXPRESS OR IMPLIED, AND EXPRESSLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. THE DURATION OF IMPLIED WARRANTIES OR CONDITIONS, INCLUDING WITHOUT LIMITATION, WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE, IS LIMITED TO THE ABOVE LIMITED WARRANTY PERIOD; SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW

LONG AN IMPLIED WARRANTY OR CONDITION LASTS, SO LIMITATIONS MAY NOT APPLY TO YOU. NO OPTO 22 DEALER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATIONS, EXTENSIONS, OR ADDITIONS TO THIS WARRANTY. If any modifications are made to the Software by you during the warranty period or if you violate the terms of this Agreement, then this warranty shall immediately be terminated. This warranty shall not apply if the Software is used on or in conjunction with hardware or software other than the unmodified version of hardware and software with which the Software was designed to be used as described in the documentation.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER LEGAL RIGHTS THAT VARY FROM STATE TO STATE OR BY JURISDICTION.

LIMITATION OF LIABILITY. UNDER NO CIRCUMSTANCES AND UNDER NO LEGAL THEORY, TORT, CONTRACT, OR OTHERWISE, SHALL OPTO 22 OR ITS SUPPLIERS OR RESELLERS BE LIABLE TO YOU OR ANY OTHER PERSON FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY CHARACTER INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF GOODWILL, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, OR ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES, OR FOR ANY DAMAGES IN EXCESS OF OPTO 22'S LIST PRICE FOR THE DEVICE, EVEN IF OPTO 22 SHALL HAVE BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. THIS LIMITATION OF LIABILITY SHALL NOT APPLY TO LIABILITY FOR DEATH OR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH LIMITATION. FURTHERMORE, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THIS LIMITATION AND EXCLUSION MAY NOT APPLY TO YOU.

TERMINATION. This license will terminate automatically if you fail to comply with the limitations described above. On termination, you must destroy all copies of the Software and documentation.

MISCELLANEOUS/GENERAL. This Agreement represents the complete agreement concerning this license between the parties and supersedes all prior agreements and representations between them. It may be amended only by a writing executed by both parties. THE ACCEPTANCE OF ANY PURCHASE ORDER PLACED BY YOU IS EXPRESSLY MADE CONDITIONAL ON YOUR ASSENT TO THE TERMS SET FORTH HEREIN, AND NOT THOSE CONTAINED IN YOUR PURCHASE ORDER. If any provision of this Agreement is held to be unenforceable for any reason, such provision shall be reformed only to the extent necessary to make it enforceable. This Agreement shall be governed by and construed under California law as such law applies to agreements between California residents entered into and to be performed within California, except as governed by Federal law. The application of the United Nations Convention of Contracts for the International Sale of Goods is expressly excluded.

GNU General Public License

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of

Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights,

from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

GNU Lesser General Public License

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to

say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library.

b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

- b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly

through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

Numerics

2-pass and 4-pass, 20

A

AC power, 17

address, 20

analog features

high/low range testing, 7

minimum/maximum values, 7

offset and gain calculations, 7

read/write to point in counts, 7

read/write to point in EU, 7

watchdog timer, 7

waveform generation, 7

analog input averaging, 7

analog point, configuring, 46

analog/digital brain board

Modbus function codes supported, 42

assigning IP address, 35

B

baud rate, 20

biasing, 19

blink codes, 11

board dimensions, 9

C

cable, 23

COM terminals, 17

communicating with brain board

pinging the brain board, 54

communication

handling errors, 56

packet for Modbus/TCP, 43

configuring

analog point, 46

digital point, 46

I/O point, 46

connect

Ethernet, 22

serial, 17

counters

E1, 5

Modbus/TCP, 46

D

data

acquisition, 26, 28

Modbus float format, 47

DC power, 17

default settings

brain board, 35

OmuxSettings file, 69

digital features

counters, 5

input latches, 5

pulse duration, 6

pulse generation, 6

read/write to point, 5

time delays, 6

watchdog timer, 6

digital I/O modules, 26

digital point, configuring, 46

dimensions, 9

downloading

OmuxSettings, 67

see loading

driver toolkit, 31

E

- E1 brain board
 - description, 1
 - features, 5
 - LED descriptions, 10
 - mounting, 14
- E2 brain board
 - description, 2
 - features, 6
 - LED descriptions, 10
 - mounting, 14
- errors
 - codes, 59
 - Ethernet communications, 53
 - general troubleshooting, 60
 - Modbus/TCP exception errors, 43
 - serial communications, 56
 - troubleshooting communications, 56
- Ethernet network
 - cable specifications, 23
 - certification, 56
 - connecting, 22
 - migration options, 32
 - troubleshooting, 56
- exception code, Modbus/TCP, 43

F

- factory default settings, 35
- firmware, loading to brain board, 37
- float format, Modbus, 47
- format
 - of Modbus float, 47
 - of Modbus/TCP communication packet, 43
- FTP, 54, 66
- function codes, Modbus, 42

G

- gain, calculating, 7
- gain, Modbus/TCP, 47
- Group A jumpers, 19
- Group B jumpers, 20

H

- help
 - LED descriptions, 10
 - network problems, 56
 - Product Support, 4
- high/low range testing, 7
- holding registers (Modbus), 49

I

- I/O modules, installing, 17
- I/O point
 - configuring, 46
 - features, Modbus/TCP, 46
- input
 - averaging, 7
 - latches, 5
 - registers (Modbus), 49
- installing
 - brain board, 14
 - Ethernet, 22
 - I/O modules, 17
 - power supply, 15
 - serial connection, 17
 - software, 13
- ioManager, 54
- IP address
 - assigning, 35
 - resetting to factory default, 35
 - viewing, 35
- IP security, 22

J

- jumper settings, 19

K

- kernel, *see* firmware

L

- latches, Modbus/TCP, 46
- LEDs
 - blink codes, 11
 - description, 10
- licensing, 73
- loading new firmware, 37

M

- maximum value, Modbus/TCP, 47
- memory map, Modbus, analog/digital brain boards, 48
- message protocol, 20
- minimum /maximum values, 7
- minimum value, Modbus/TCP, 47
- Modbus float format, 47
- Modbus/TCP, 5, 34
 - communication packet, 43

- counters, 46
- exception errors, 43
- function codes supported, 42
- latches, 46
- memory map
 - analog/digital brain boards, 48
 - minimum/maximum values, 47
 - offset and gain, 47
 - packet, 43
 - scaling, 47
- mounting
 - brain board, 14
 - racks, 14, 23
- multidrop mode, 19

N

- network
 - certification, 56
 - OptoEnetSniff, 56
 - troubleshooting, 56

O

- offset and gain calculations, 7
- offset, Modbus/TCP, 47
- OLE, 28
- OmuxSettings file, 69
- OPC, 28, 33
- Opto 22 Product Support, 4
- OptoDataLink, 30
- OptoEnetSniff, 56
- OptoMMP, 5, 31
- Optomux, 5, 27
- OptoOPCServer, 28, 29, 33

P

- PAC Control, 29
- PAC Display, 29
- PAC Manager, 29
- PAC Project software suite, 29
- packet for Modbus/TCP, 43
- ping, 54
- power supply
 - analog racks, 24
 - connecting, 15
 - specifications, 24
- Product Support, 4
- pulse
 - duration, 6
 - generation, 6

Q

- Quad Pak modules, 26

R

- racks, 14, 23
- read/write to point
 - analog, 7
 - digital, 5
- reading IP address and subnet mask, 35
- registers (Modbus), 49
- remote access, 26
- remote monitoring, 26
- repeat mode, 19
- reset brain board, 35
- routing table, 65

S

- scaling, Modbus/TCP, 47
- security, 22
- serial wiring, 17
 - diagram, 17
 - migrate to Ethernet, 32
 - setting jumpers, 19
- SNAP digital modules, 26
- software, 13
- software licensing, 73
- specifications, 8
- subnet mask, 35

T

- technical support, 4
- termination, 19
- time delays, 6
- troubleshooting
 - Ethernet communications, 53
 - general errors, 60
 - LED descriptions, 10
 - Modbus exception errors, 43
 - network, 56
 - Product Support, 4
 - serial communications, 56
- twisted pair, 17

U

- UDP, 64
- uploading
 - OmuxRoutes file, 66

OmuxSettings file, 67
utilities
OptoEnetSniff, 56

W

watchdog timer, 6, 7
waveform generation, 7
wiring
 Ethernet, 22
 serial, 17