

# MISTICWARE MANUAL

Form 522-100823 — August 2010

## **OPTO 22**

43044 Business Park Drive, Temecula, CA 92590-3614  
Phone: 800-321-OPTO (6786) or 951-695-3000  
Fax: 800-832-OPTO (6786) or 951-695-2712  
[www.opto22.com](http://www.opto22.com)

**Product Support Services:**

800-TEK-OPTO (835-6786) or 951-695-3080  
Fax: 951-695-3017  
E-mail: [support@opto22.com](mailto:support@opto22.com)  
Web: [support.opto22.com](http://support.opto22.com)

---

## MisticWare Manual Form 522-100823—August 2010

All rights reserved.  
Printed in the United States of America.

The information in this manual has been checked carefully and is believed to be accurate; however, Opto 22 assumes no responsibility for possible inaccuracies or omissions. Specifications are subject to change without notice.

Opto 22 warrants all of its products to be free from defects in material or workmanship for 30 months from the manufacturing date code. This warranty is limited to the original cost of the unit only and does not cover installation, labor, or any other contingent costs. Opto 22 I/O modules and solid-state relays with date codes of 1/96 or later are guaranteed for life. This lifetime warranty excludes reed relay, SNAP serial communication modules, SNAP PID modules, and modules that contain mechanical contacts or switches. Opto 22 does not warrant any product, components, or parts not manufactured by Opto 22; for these items, the warranty from the original manufacturer applies. These products include, but are not limited to, the OptoTerminal-G70, OptoTerminal-G75, and Sony Ericsson GT-48; see the product data sheet for specific warranty information. Refer to Opto 22 form number 1042 for complete warranty information.

Opto 22 FactoryFloor, Cyrano, Optomux, and Pamux are registered trademarks of Opto 22. Generation 4, ioControl, ioDisplay, ioManager, ioProject, ioUtilities, mistic, Nvio, Nvio.net Web Portal, OptoConnect, OptoControl, OptoDisplay, OptoENETSniff, OptoOPCServer, OptoScript, OptoServer, OptoTerminal, OptoUtilities, SNAP Ethernet I/O, SNAP I/O, SNAP OEM I/O, SNAP Simple I/O, SNAP Ultimate I/O, and SNAP Wireless LAN I/O are trademarks of Opto 22.

ActiveX, JScript, Microsoft, MS-DOS, VBScript, Visual Basic, Visual C++, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries. Linux is a registered trademark of Linus Torvalds. Unicenter is a registered trademark of Computer Associates International, Inc. ARCNET is a registered trademark of Datapoint Corporation. Modbus is a registered trademark of Schneider Electric. Wiegand is a registered trademark of Sensor Engineering Corporation. Nokia, Nokia M2M Platform, Nokia M2M Gateway Software, and Nokia 31 GSM Connectivity Terminal are trademarks or registered trademarks of Nokia Corporation. Sony is a trademark of Sony Corporation. Ericsson is a trademark of Telefonaktiebolaget LM Ericsson.

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

# Table of Contents

<b>Welcome .....</b>	<b>9</b>
Overview .....	9
What's In This Manual? .....	10
Document Conventions .....	11
<b>Chapter 1: Getting Started .....</b>	<b>13</b>
Using The Driver .....	13
Driver Parameters .....	14
SEND Structure .....	14
RESPONSE Structure .....	14
Examples .....	14
Error Handling .....	15
Using The Driver With Microsoft C on DOS .....	15
Using The Driver With Other Languages on DOS .....	15
Mistic Driver Error Codes .....	16
Mistic I/O unit Generated Errors .....	16
I/O Driver Generated Errors .....	17
Mistic Controller PASS-THRU Errors .....	18
Additional Error Codes .....	20
<b>Chapter 2: MisticWare Commands – Sample .....</b>	<b>21</b>
<b>Chapter 3: Analog And Digital I/O Commands .....</b>	<b>23</b>
POWER UP CLEAR (A) .....	0 23
RESET (B) .....	1 24
SET SYSTEM OPTIONS (C) .....	2 25
STORE CONFIGURATION To EEPROM (E) .....	3 26
IDENTIFY I/O UNIT TYPE (F) .....	4 27
REPEAT LAST RESPONSE (*) .....	5 28
ROM REVISION/DATE (!) .....	6 29

CLEAR BUS ERROR FLAG MISTIC CONTROLLER (C) .....	7	30
SET RESPONSE DELAY (~) .....	8	31
CLEAR INTERRUPT REQUEST (ZB) .....	9	

#### **Chapter 4: Multichannel Digital Commands ..... 33**

SET I/O CONFIGURATION (G) .....	100	33
READ I/O CONFIGURATION (Y) .....	101	34
READ I/O STATUS (R) .....	102	35
SET OUTPUTS (J) .....	103	36
READ LATCHES WITHOUT CLEARING (S) .....	104	37
ENABLE COUNTERS (H) .....	105	38
DISABLE COUNTERS (H) .....	106	39
READ COUNTER ENABLE/DISABLE STATUS (U) .....	107	40
READ COUNTERS WITHOUT CLEARING (T) .....	108	41
READ AND CLEAR COUNTERS (U) .....	109	42
READ PULSE/PERIOD/TOTALIZER COMPLETE STATUS (V) .....	110	43
READ PULSE/PERIOD/TOTALIZER (W) .....	111	44
READ AND RESET PULSE/PERIOD/TOTALIZER (X) .....	112	45
READ FREQUENCY (Z) .....	113	46
SET WATCHDOG (D) .....	114	47
READ EVENT LATCHES (P) .....	115	48
READ AND CLEAR EVENT LATCHES (Q) .....	116	49
READ AND CLEAR POSITIVE LATCHES (S) .....	117	50
READ AND CLEAR NEGATIVE LATCHES (S) .....	118	51
READ AND CLEAR POSITIVE AND NEGATIVE LATCHES (S) .....	119	52
READ I/O STATUS MASK (R) .....	120	53

#### **Chapter 5: Single Channel Digital Commands ..... 55**

SET I/O CONFIGURATION (A) .....	200	55
CLEAR (DEACTIVATE) OUTPUT (E) .....	201	56
SET (ACTIVATE) OUTPUT (D) .....	202	57
ENABLE COUNTER INPUT (B) .....	203	58
DISABLE COUNTER INPUT (B) .....	204	59
CLEAR COUNTER INPUT (c) .....	205	60
READ COUNTER INPUT (32-BIT) (L) .....	206	61
READ AND CLEAR COUNTER INPUT (32 BIT) (N) .....	207	62
READ COUNTER INPUT (16 BIT) (M) .....	208	63
READ AND CLEAR COUNTER INPUT (16 BIT) (O) .....	209	64
READ PULSE/PERIOD/TOTALIZER MEASUREMENT INPUT (32-BIT) (P) .....	210	65
READ AND RESET PULSE/PERIOD/TOTALIZER MEASUREMENT (32 BIT)-(R) .....	211	66
READ PULSE/PERIOD/TOTALIZER MEASUREMENT INPUT (16-BIT) (O) .....	212	67

READ AND RESET PULSE/PERIOD/TOTALIZER MEASUREMENT (16-BIT) (S) .....	213	68
READ FREQUENCY (T) .....	214	69
START ON PULSE (F) .....	215	70
START OFF PULSE (G) .....	216	71
START CONTINUOUS SQUARE WAVE (H) .....	217	72
GENERATE N PULSES ( I ) .....	218	73
SET TPO PERIOD ( J ) .....	219	74
SET TPO PERCENT ( J ) .....	220	75
READ LATCHES (W) .....	221	76
READ LATCHES AND CLEAR POSITIVE LATCH (W) .....	222	77
READ LATCHES AND CLEAR NEGATIVE LATCH (W) .....	223	78
READ AND CLEAR LATCHES (W) .....	224	79
READ OUTPUT TIMER COUNTER (K) .....	225	80

## **Chapter 6: Multichannel Analog Commands ..... 81**

SET I/O CONFIGURATION (G) .....	300	81
READ I/O CONFIGURATION (Y) .....	301	82
READ I/O MODULE MAGNITUDES-COUNTS (R) .....	302-326	83
READ I/O MODULE MAGNITUDES-ENGINEERING UNITS (R) .....	307-331	84
READ AND CLEAR I/O MAGNITUDES-COUNTS (S) .....	312-336	85
READ AND CLEAR MAGNITUDES-ENGINEERING UNITS (S) .....	317-341	86
SET I/O MODULE MAGNITUDES-COUNTS (X) .....	342	87
SET I/O MODULE MAGNITUDES-ENGINEERING UNITS (W) .....	343	88
SET WATCHDOG TIME (D) .....	344	89
SET WATCHDOG DATA-ENGINEERING UNITS (H) .....	345	90

## **Chapter 7: Single Channel Analog Commands ..... 91**

SET I/O CHANNEL CONFIGURATION (A) .....	400	91
SET ANALOG TPO PERIOD ( J ) .....	401	92
READ I/O MODULE MAGNITUDE-COUNTS (R) .....	402-426	93
READ I/O MODULE MAGNITUDE-ENGINEERING UNITS (R) .....	407-431	94
READ AND CLEAR I/O MAGNITUDE-COUNTS (S) .....	412-436	95
READ AND CLEAR I/O MAGNITUDE-ENGINEERING UNITS (S) .....	417-441	96
SET I/O MODULE MAGNITUDE-COUNTS (X) .....	442	97
SET I/O MODULE MAGNITUDE-ENGINEERING UNITS (W) .....	443	98
SET SCALING PARAMETERS (F) .....	444	99
SET TOTALIZATION SAMPLE RATE (G) .....	445	100
SET AVERAGING SAMPLE WEIGHT (H) .....	446	101
CALCULATE AND SET OFFSET (D) .....	447	102
CALCULATE AND SET GAIN (E) .....	448	103
SET OFFSET (B) .....	449	104
SET GAIN (C) .....	450	105
RAMP OUTPUT TO ENDPOINT (Z) .....	451	106
DUMP CHANNEL DATA ( [ ) .....	452	107

<b>Chapter 8: Analog PID Commands .....</b>	<b>109</b>
INITIALIZE PID LOOP (i) .....	500 109
SET PID LOOP CONTROL OPTIONS ( J ) .....	501 110
SET PID LOOP SETPOINT (k) .....	502 111
SET PID LOOP GAIN (L) .....	503 112
SET PID LOOP INTEGRAL RESET RATE (M) .....	504 113
SET PID LOOP DERIVATIVE RATE (N) .....	505 114
SET PID LOOP SETPOINT MIN/MAX LIMITS (o) .....	506 115
READ ALL PID LOOP PARAMETERS (T) .....	507 116
READ LOOP CONTROL WORD (t) .....	508 117
READ SCAN RATE WORD (t) .....	509 118
READ OUTPUT COUNTS (t) .....	510 119
READ LOOP CHANNELS (t) .....	511 120
READ INPUT VALUE (PROCESS VARIABLE) (t) .....	512 121
READ SETPOINT VALUE (t) .....	513 122
READ OUTPUT VALUE (t) .....	514 123
READ GAIN TERM (t) .....	515 124
READ INTEGRAL TERM (t) .....	516 125
READ DERIVATIVE TERM (t) .....	517 126
READ MAXIMUM SETPOINT LIMIT (t) .....	518 127
READ MINIMUM SETPOINT LIMIT (t) .....	519 128
SET PID LOOP OUTPUT MIN/MAX LIMITS (P) .....	520 129
SET PID LOOP PROCESS VARIABLE (Q) .....	521 130
<b>Chapter 9: Digital Event/Reaction Commands .....</b>	<b>131</b>
CLEAR EVENT/REACTION TABLE ( _ ) .....	600 131
CLEAR EVENT TABLE ENTRY ( \ ) .....	601 132
READ EVENT ENTRY ENABLE/DISABLE STATUS (v) .....	602 133
READ ALL EVENT ENTRIES ENABLE/DISABLE STATUS (v) .....	603 134
ENABLE EVENT TABLE ENTRY (N) .....	604 135
DISABLE EVENT TABLE ENTRY (N) .....	605 136
ENABLE/DISABLE EVENT TABLE GROUP ( { ) .....	606 137
READ EVENT TABLE ENTRY (O) .....	608 138
READ EVENT LATCHES (P) .....	609 140
READ ALL EVENT LATCHES (P) .....	610 141
READ AND CLEAR EVENT LATCHES (Q) .....	611 142
READ AND CLEAR ALL EVENT LATCHES (Q) .....	612 143
ENABLE EVENT INTERRUPT (I) .....	613 144
DISABLE EVENT INTERRUPT (I) .....	614 145
SET EVENT ON COMM LINK WATCHDOG TIMEOUT (y) .....	615 146
SET EVENT ON MOMO MATCH (K) .....	616 147
SET EVENT ON COUNTER GREATER OR EQUAL (L) .....	617 148
CLEAR REACTION (M) .....	618 149
SET OUTPUT STATE REACTION (M) .....	619 150

SET ON PULSE REACTION (M) .....	620	151
SET OFF PULSE REACTION (M) .....	621	152
SET ENABLE/DISABLE COUNTER REACTION (M) .....	622	153
CLEAR COUNTER REACTION (M) .....	623	154
SET ENABLE/DISABLE EVENT ENTRY REACTION (M) .....	624	155
SET ENABLE/DISABLE EVENT GROUP REACTION (M) .....	625	156
READ AND HOLD COUNTER VALUE REACTION (M) .....	626	157
READ EVENT HOLD BUFFER (I) .....	627	158
SET EVENT ON COUNTER LESS OR EQUAL (}) .....	628	159
READ AND CLEAR EVENT LATCH - SINGLE CHANNEL (zA) .....	629	160

## **Chapter 10: Analog Event/Reaction Commands ..... 161**

CLEAR EVENT/REACTION TABLE (-) .....	700	161
CLEAR EVENT TABLE ENTRY (\) .....	701	162
READ EVENT ENTRY ENABLE/DISABLE STATUS (v) .....	702	163
READ ALL EVENT ENTRIES ENABLE/DISABLE STATUS (v) .....	703	164
ENABLE EVENT TABLE ENTRY (N) .....	704	165
DISABLE EVENT TABLE ENTRY (N) .....	705	166
ENABLE/DISABLE EVENT TABLE GROUP ( { ) .....	706	167
READ EVENT TABLE ENTRY (O) .....	708	168
READ EVENT LATCHES (P) .....	709	170
READ ALL EVENT LATCHES (P) .....	710	171
READ AND CLEAR EVENT LATCHES (Q) .....	711	172
READ AND CLEAR ALL EVENT LATCHES (Q) .....	712	173
ENABLE EVENT INTERRUPT (I) .....	713	174
DISABLE EVENT INTERRUPT (I) .....	714	175
SET EVENT ON COMM LINK WATCHDOG TIMEOUT (y) .....	715	176
SET EVENT ON INPUT/OUTPUT > = SETPOINT (K) .....	716-725	177
SET EVENT ON INPUT/OUTPUT <= SETPOINT (L) .....	726-735	178
CLEAR REACTION (M) .....	736	179
SET OUTPUT VALUE (COUNTS) REACTION (M) .....	737	180
SET OUTPUT VALUE (ENGINEERING UNITS) REACTION (M) .....	738	181
SET OUTPUT RAMP TO SETPOINT REACTION (M) .....	739	182
SET ENABLE/DISABLE EVENT ENTRY REACTION (M) .....	740	183
SET ENABLE/DISABLE EVENT GROUP REACTION (M) .....	741	184
SET PID SETPOINT VALUE REACTION (M) .....	742	185
SET PID MIN/MAX OUTPUT LIMITS REACTION (M) .....	743	186
SET PID ENABLE/DISABLE REACTION (M) .....	744	187
READ AND HOLD I/O VALUE REACTION (M) .....	745	188
READ EVENT HOLD BUFFER (I) .....	746	189
READ AND CLEAR EVENT LATCH - SINGLE CHANNEL (zA) .....	747	190

<b>Chapter 11: Driver COMMANDS .....</b>	<b>191</b>
SET TURNAROUND DELAY TIME .....	901 191
SET PORT AND BAUD RATE .....	902 192
SET NUMBER OF RETRIES .....	903 193
SET COMMUNICATIONS MODE .....	904 194
SET USER DEFINED PORT PARAMETERS .....	905 195
READ DRIVER VERSION .....	906 196
<b>Appendix A .....</b>	<b>197</b>
Channel Data Dump Structures .....	197
<b>Appendix B .....</b>	<b>205</b>
MisticWare Driver for Windows .....	205
Port Locking and Multiple Applications .....	205
Port types supported .....	205
Handles .....	205
Installation .....	206
API list .....	206
Simple Code Fragment Using These APIs .....	206
Visual Basic Functions .....	209
Status or Error Codes .....	210
Additional Error Codes .....	211
<b>Appendix C .....</b>	<b>213</b>
Using The Driver with Microsoft Basic/Quick Basic .....	213
Basic Compiler 7.0/7.1 .....	214
Quick Basic 4.0/4.5 .....	216
<b>Appendix D .....</b>	<b>219</b>
Using Opto 22 I/O in 32 bit Windows .....	219
Port Locking and Multiple Applications .....	219
Port types supported .....	219
Handles .....	219
Installation .....	220
Examples .....	220
API list .....	220
Visual Basic Functions .....	222
Status or error codes .....	222

## Index



# Welcome

## Overview

The MysticWare I/O driver is a software package designed to simplify communications with Mystic protocol I/O units.

The MysticWare driver provides the software interface between the Mystic I/O units and an application program written in a high-level language. The driver is a function call. Examples are provided to demonstrate how to use the driver from various languages.

The MysticWare driver was written for the IBM-PC family computers. Complete source code is included for your convenience.

The MysticWare I/O driver performs the following functions:

- Builds and transmits Mystic protocol I/O command messages
- Carries out all necessary handshaking and communications
- Converts the data returned by a Mystic I/O unit into a form that is easily manipulated by the application program
- Performs extensive error checking and returns diagnostic error codes.

This manual outlines the use and command structure of the driver.

For a complete description of each low-level Mystic protocol I/O command, please refer to Opto 22's *Mystic Protocol Guide* (Form 270).

This manual assumes you have read and understand Form 270.

To use the MysticWare I/O driver in an application program, you must know the following:

- How to call a "C" function from an application program
- How to use a linker to link a program
- How to tell the driver what command to send by assigning values to the proper parameters
- How to interpret the data passed back by the driver.

---

# What's In This Manual?

This manual includes the following sections:

- **Chapter 1: "Getting Started"**—installing and using the driver.
- **Chapter 2: "MisticWare Commands"**—index listing all of the MisticWare commands and their page members.
- **Chapter 3: "Analog and Digital I/O Commands"**—commands common to both analog and digital I/O units or "brain boards".
- **Chapter 4: "Multichannel Digital Commands"**—commands used to access banks or groups of digital channels.
- **Chapter 5: "Single Channel Digital Commands"**—commands used to access individual digital channels.
- **Chapter 6: "Multichannel Analog Commands"**—commands used to access groups of analog channels.
- **Chapter 7: "Single Channel Analog Commands"**—commands used to access individual analog channels.
- **Chapter 8: "Analog PID Commands"**—commands used to access PIDs on analog units.
- **Chapter 9: "Digital Event/Reaction Commands"**—commands for configuring event reactions on digital units.
- **Chapter 10: "Analog Event/Reaction Commands"**—commands for configuring event reactions on analog units.
- **Chapter 11: "Driver Commands"**—driver configuration commands.
- **Appendix A: "Channel Data Dump Structures"**—supplemental information for command 452.
- **Appendix B: "MisticWare Driver for Windows"**—information for use with 16-bit Windows.
- **Appendix C: "Using the Driver with Microsoft Basic/Quick Basic"**—information for use with Basic on DOS.
- **Appendix D: "Using Opto in 32-Bit Windows"**—describes how to access Opto I/O in Win 32.

---

# Document Conventions

- **Bold** typeface indicates text to be typed. Unless otherwise noted, such text may be entered in upper or lower case. (Example: "At the DOS prompt, type **cd\windows**.")
- *Italic* typeface indicates emphasis and is used for book titles. (Example: "See the *OptoControl User's Guide* for details.")
- File names appear in all capital letters. (Example: "Open the file TEST1.TXT.")
- Key names appear in small capital letters. (Example: "Press SHIFT.")
- Key press combinations are indicated by hyphens between two or more key names. For example, SHIFT F1 is the result of holding down the SHIFT key, then pressing and releasing the F1 key. Similarly, CTRL-ALT-DELETE is the result of pressing and holding the CTRL and ALT keys, then pressing and releasing the DELETE key.
- "Press" (or "click") means press and release when used in reference to a mouse button.
- Menu commands are sometimes referred to with the Menu→Command convention. For example, "Select File→Run" means to select the Run command from the File menu.
- Numbered lists indicate procedures to be followed sequentially. Bulleted lists (such as this one) provide general information.



# Getting Started

Before proceeding with this section, please make backup copies of the driver diskettes. Refer to your DOS manual for instructions on copying diskettes.

## Using The Driver

The MysticWare I/O driver is a "C" function. Two structures are used for passing parameter information. The SEND structure passes data to the driver, and the RESP structure passes data back. An application program must declare variables of these types, then pass a pointer to those variables when calling the driver. The function then returns an integer which corresponds to an error value. The value is zero if no error has occurred, otherwise it is a negative number representing an error code.

```
Function: int g4driver(struct SEND_OBJ *send, struct RESP_OBJ name
*response)
```

Inputs: \*send points to a structure of parameters to send

```
struct SEND_OBJ
{
    unsigned int address;    /*unit address */
    unsigned int command;   /*command number */
    unsigned int position[2]; /*position masks */
    long data[16];         /*data array */
};
```

Outputs: \*response points to a structure of where to put the data

```
struct RESP_OBJ
{
    int error;             /*return error */
    long data[16];        /*return data */
};
```

Return: 0 returned if no error, else error is returned.

# Driver Parameters

## Send Structure

### Address

This field contains the address of the I/O unit. The field is an integer value ranging from 0 to 255 decimal.

### Command

This parameter is an integer variable that contains the number of the desired driver command.

### Positions[0],Positions[1]

The POSITIONS array contains two integer parameters. For many of the multichannel commands, a positions mask (0000 to FFFF Hex) is placed in the POSITIONS array element specified by the command. For the single channel commands, a channel number (0 to 15 Decimal) is used. The majority of multichannel commands only use POSITIONS[0], although some commands use both POSITIONS[0] and POSITIONS[1].

### Data[0]...Data[15]

The DATA array parameter is made up of 16 long integer (4-byte) values. These are used to hold the data values necessary to execute the command.

## Response Structure

### Error

The ERROR parameter is an integer field which will contain a value on return from the driver. If no error has occurred, a value of zero (0) will be returned, otherwise a specific negative error code is returned. For a list of error codes, refer to the section, "Mistic Driver Error Codes." An application program should always inspect this parameter after calling the driver to verify that communications were successful and that the data was received correctly.

### Data[0]...Data[15]

The DATA array parameter is made up of 16 long integer (4-byte) values. These are used to hold the data values that are returned by the I/O unit.

## Examples

Several examples are provided on the disk to illustrate the use of the driver. The examples attempt to cover the wide range of features of both the digital and the analog I/O units. The examples start with simple initialization and error handling and progress to more advanced examples of using the event-reaction and PID commands.

## Error Handling

See the DOS example EXAMPLE2.C, which shows one method of processing errors that are detected by the I/O unit or the driver. This example uses the routine for driver initialization shown in the previous example, and also shows a typical method of initializing the I/O units.

The important concept to remember in error handling is to re-configure the I/O units after a power-up or watchdog condition. The extent of the re-configuration depends on what features were used and whether the configurations were stored in EEPROM.

## Using The Driver With Microsoft C on DOS

To use the Microsoft C version of the driver, you will need to change the define statement MSC to a true (1) in the file G4DRIVER.H before compilation. This statement changes certain function names to those recognized by the Microsoft C compiler. A simple example called G4MSC.C is provided on the disk to show how to interface to the driver. The make file for the project is also provided and is called GMSC.MAK.

## Using The Driver With Other Languages on DOS

Previous versions of the MysticWare driver provided a method for using the driver with the Microsoft BASIC compiler. This method, however, required the existence of the Microsoft "C" libraries during the linking process. In order to simplify the interface to the BASIC language (as well as other languages such as Turbo PASCAL), an alternate method is now used.

A program named LOADMD.EXE is provided and allows the MysticWare driver to function as a Terminate-Stay-Resident (TSR) program. The program is written in "C" and the source code is contained in the file LOADMD.C. Running this program prior to running the application loads the driver into memory where it becomes accessible using software interrupt 61 hex. Prior to an application issuing the interrupt, the CPU AX, BX, CX, and DX registers are setup with the addresses to the send and receive structures used by the application.

The language used must be able to support the following; structures (records) that contain the driver parameters, a method of deriving segment and offset addresses of those structures, a method of setting the CPU registers and issuing a software interrupt.

Sample programs are provided on the disk which have been tested with Microsoft QuickBASIC 4.0/4.5, the Microsoft BASIC Compiler 7.1, and Turbo PASCAL 4.0-6.0. Appendices in the back of this manual explain the details specific to each language.

If changes are made to the driver source code, LOADMD.EXE will need to be re-created by linking LOADMD.OBJ, G4DRIVER.OBJ, and G4COMM.OBJ together.

# Mistic Driver Error Codes

## Mistic I/O unit Generated Errors

### **-1 Undefined Command Error**

This error code indicates that the Mistic I/O unit received a command letter that it did not understand. This may indicate that a new command that was added to the driver is not supported by an older I/O unit or that a command for one type of I/O unit was actually sent to an I/O unit of a different type (analog command sent to a digital board).

### **-2 Mistic Protocol I/O Unit Detected A Checksum Error**

This error code indicates a problem with the communications link that caused a checksum error when a message from the host was sent to the I/O unit. Checksum errors often occur when the Local Bus or RS-485 network is not wired, terminated, or biased properly. Make sure of the following:

1. Twisted-pair cable with at least two twists per inch is used for remote I/O units.
2. The link is routed in a daisy-chain fashion, NOT a “star” type distribution.
3. The link is terminated at the end points and NOT in the middle.
4. The length of the cable does not exceed the length defined in the I/O unit specifications.

### **-3 Mistic I/O Unit's Buffer Was Overrun**

This error indicates that the I/O unit received more characters than were expected. This may occur because of improper biasing of remote links combined with an electrically noisy environment. See recommendations described for a -2 error.

### **-4 Device Lost Power Since Last Message**

This error indicates that a power failure occurred and the I/O unit went through a reset cycle. Configuration parameters may have been lost unless they were stored in the I/O units' EEPROM. This error can only be cleared by issuing a “Power Up Clear” (0) command. Remember to re-configure the unit and download PID parameters and Event/Reaction commands where necessary.

### **-5 Error In A Data Field**

This error occurs when the I/O unit receives a message that does not contain enough data characters for that command. This may be due to sending a digital command to an analog I/O unit or vice-versa. It also may indicate a driver version that does not match the firmware of an I/O unit because of a change to the command structure.



**-6 A Serial Watchdog Occurred Since Last Message**

This is a flag that indicates that the I/O unit went to a watchdog state because of inactivity on the communications link (local or remote) for a specified length of time. The command that was sent which received this response is not executed. Since the watchdog state may be different than what the host had previously setup, it may be necessary to rewrite those outputs. If you receive this error often, you may wish to change the timeout period using the watchdog command. Under normal operations, this error should only occur after a recovery from a disconnection to the host or the communications link.

**-7 Invalid Data-Limits Sent Are Out Of Range**

This error indicates that at least one of the data fields in the command message contains an illegal value. Make sure that the values sent are within the range allowed by the configuration for that channel or loop.

**-8 Reserved****-9 Invalid Module Type Was Specified**

This error occurs when a command is sent that requires a channel to be configured differently than it is presently. For example; a command to turn on an output on a channel that is configured as an input.

**-10 Invalid Event Type Was Specified**

This error occurs when an attempt is made to enable an event entry or define a reaction before the event has been defined (NULL entry).

**-11 Invalid Delay Specified**

This error occurs with digital I/O units when an attempt is made to start a square wave or generate N pulses, or a TPO, with a delay time less than 10 mS on more than eight output positions.

## I/O Driver Generated Errors

**-20 Invalid Command Error**

This error occurs when the command variable contains a value that is not supported by the driver.

**-22 Data Range Error**

This error indicates that an invalid data value was used with a 900 series driver command. Examples include invalid port numbers, baud rates, and timeout ranges.

**-25 Invalid Address Error**

This error occurs when the address variable contains a value that is less than 0 or greater than 255.

**-29 Driver Timeout Error**

This error indicates that a command was sent to an I/O unit and a response was NOT received within the delay period used by the driver. A -29 error may occur because of the following:

1. The address variable contains an address of an I/O unit that doesn't exist. Check variable and verify address jumpers on I/O unit.
2. No power or bad power to the I/O unit.
3. A problem with the communications cables. Check continuity and polarity. Make sure you use correct cable types with the proper termination and bias.
4. If both the transmit and receive LEDs flash on the I/O unit, then check for the following: Incorrect communications interrupt line selected or another adapter card using the same address/interrupt line.
5. Turn-Around Delay may be set too short for the baud rate and command selected. A Reset command (1) and a "Store Configuration To EEPROM" command (3) may take up to two seconds to execute.

**-31 Driver Detected A Checksum Error In The Response**

This error code indicates that a problem with the communications link caused a checksum error when a response from the I/O unit was received. See recommendations described for a -2 error.

**-33 Driver Send Error**

The driver had a problem transmitting a message. This may occur when there is a problem with the serial or local adapter card. Check the address and interrupt line for the adapter card and make sure it does not conflict with any other adapter in the PC.

**-36 General Mystic Controller Error**

This error code indicates that the Controller received a message it did not understand. Make sure that you are in pass-thru mode when sending commands to the I/O units through the Mystic Controller.

## Mystic Controller PASS-THRU Errors

**-41 Bad Port Number**

The Mystic Controller reports that the specified port number is illegal in the PASS-THRU preamble. This error should never occur, because driver command 904 checks for valid numbers.

**-42 Mystic Controller Detected A CRC Error**

This error code indicates that a problem with the communications link caused a CRC error when a message from the host was sent to the Controller. Checksum errors often occur when the RS-485 network is not wired, terminated, or biased properly. Make sure of the following:

1. Twisted-pair cable with at least two twists per inch is used for Mystic Controller RS-485 serial ports.
2. The link is routed in a daisy-chain fashion, NOT a “star” type distribution.
3. The link is terminated at the endpoints and NOT in the middle.
4. The length of the cable does not exceed the length defined in the G4LC specifications.

#### **-43 Mystic Controller Buffer Overrun-From I/O unit**

This error indicates that the Mystic Controller received more characters from the I/O unit than were expected. This may occur because of improper biasing of remote links combined with an electrically noisy environment. See recommendations described for a -42 error.

#### **-44 Mystic Controller Lost Power Since Last Message**

This error indicates that a power failure occurred and the Mystic Controller went through a reset cycle. This error can only be cleared by issuing a “Power Up Clear” (0) command to the Mystic Controller. **Remember to send this command in the binary mode, NOT in the PASS-THRU mode.**

#### **-45 Bad CRC Length Error**

This error indicates that the Mystic Controller received more or less characters than were expected when doing the CRC calculations. This may occur because of improper jumper settings for mode.

CDR/checksum on the Mystic I/O units. Verify that mode 2 (Command 904) is used with multifunction I/O units and mode 3 is used with local, simple I/O units.

#### **-46 Mystic Controller Buffer Overrun - From Host Computer**

This error indicates that the Mystic Controller received more characters from the host than were expected. This may occur because of improper biasing of remote links combined with an electrically noisy environment. See recommendations described for a -42 error.

#### **-47 Reserved**

#### **-48 Bus Error Occurred in Mystic Controller**

This error indicates that a BUS ERROR condition occurred in the Mystic controller. It is usually caused by a failure in the Mystic controller’s hardware. The failure may be due to a bad memory or port device. The error flag can only be cleared by issuing a “Bus Error Clear” (7) command to the Mystic Controller. **Remember to send this command in the binary mode, NOT in the PASS-THRU mode.** This error is a warning that there is something wrong with the Mystic Controller, and clearing the bus error flag will not solve the problem. If it occurs, make sure that all the cards in the controller are properly seated.

## Additional Error Codes

### **-100 Invalid Port Error**

This error occurs when a handle number for a port is specified and that port has not been assigned a driver or adapter type.

### **-102 Initialize Error**

This error occurs if the proper AC37 or AC39 adapter could not be found at the location specified in the `ConfigureAC37` or `ConfigureAC39` functions.

### **-104 Port Lock Error**

This error occurs when a call to the `SendMIO()` function is made while another command is being processed. The DLL allows multiple applications to share a port. If a port is in use and is accessed by a second application, the second application will wait a limited amount of time for the port to become available. If, after waiting, the port is still unavailable this error is returned.

### **-105 Driver Configuration Error**

This error occurs when the `SendMIO()` function is called prior to configuring a port with the `AssignPortDriver()` and `Configure` functions.

For other errors, see `Error.H` in `Win 16` or `OptoErr.RH` in `Win 32`

# MisticWare Commands

## Mistic Driver Commands

## Sample

---

SAMPLE COMMAND (LETTER REFERS  
TO MISTIC PROTOCOL GUIDE)

COMMAND #

---

**DESCRIPTION:**

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	#
<i>POSITION[0]:</i>	Bitmask or Channel Number
<i>POSITION[1]:</i>	Bitmask or Channel Number
<i>DATA[0]...DATA[15]:</i>	Send Data Fields

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
<i>DATA[0]...DATA[15]:</i>	Return Data Fields



# Analog And Digital I/O Commands

---

**POWER UP CLEAR (A)**

---

**0****DESCRIPTION:**

Prevents I/O Unit from returning a "Power Up Clear expected" error message in response to instructions following application of power or a RESET command.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 0

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**RESET (B)**

---

**1****DESCRIPTION:**

This command forces a hardware reset. The I/O unit is restored to the configuration stored in EEPROM. The factory default is used if nothing was previously saved to EEPROM.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 1

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



**SET SYSTEM OPTIONS (C)****2****DESCRIPTION:**

This command is used to set or clear the bits in the Option Control Byte (OCB) of the I/O unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 2

*DATA[0]:* Byte indicating bits to set (0-255)

*DATA[1]:* Byte indicating bits to clear (0-255)

The system options and controlling bits are:

- bit 0 : Frequency Range; 0 = 1 sec., 1 = .1 sec (Digital)
- bit 0 : 0 = Degrees C, 1 = Degrees F (Analog)
- bit 1 : Not Used
- bit 2 : Not Used
- bit 3 : Not Used
- bit 4 : CRC init value; 0 = 0000, 1 = FFFF
- bit 5 : CRC Method; 0 = reverse, 1 = classical
- bit 6 : CRC Polynomial; 0 = CRC16, 1 = CCITT
- bit 7 : Global Event Interrupt Enable; 0 = disabled, 1 = enabled

Factory default is 00

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* OCB Value (0-255)

---

**STORE CONFIGURATION TO EEPROM (E)**

---

**3****DESCRIPTION:**

This command saves the current system parameters to EEPROM.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 3

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

**IDENTIFY I/O UNIT TYPE (F)****4****DESCRIPTION:**

This command causes the I/O unit to send back a response that identifies the type of I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 4

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:*

- 16 = G4D16R — 16-channel remote multifunction digital I/O unit
- 17 = G4D32RS — 16-channel remote simple digital I/O unit
- 18 = G4A8R w/G4RAX — B200 16-channel remote analog I/O unit
- 19 = G4A8R — 8-channel remote analog I/O unit
- 22 = G4HDAR (no interface card)
- 23 = G4HDAR w/G4AITM
- 24 = G4HDAR w/G4AIVA
- 25 = G4HDAR w/G4AIRTD
- 26 = G4HDAR w/G4AOV
- 27 = G4HDAR w/G4AOA
- 32 = G4D16L — 16-channel local multifunction digital I/O unit
- 33 = G4D16LS — 16-channel local simple digital I/O unit
- 34 = G4A8L w/G4LAX — 16-channel local analog I/O unit
- 35 = G4A8L — 8-channel local analog I/O unit
- 38 = G4HDAL (no interface card)
- 39 = G4HDAL w/G4AITM
- 40 = G4HDAL w/G4AIVA
- 41 = G4HDAL w/G4AIRTD
- 42 = G4HDAL w/G4AOV
- 43 = G4HDAL w/G4AOA
- 72 = B3000 (digital address) multifunction I/O unit
- 80 = B3000 (analog address) multifunction I/O unit
- 288 = G4D16L (M4RTU local I/O unit)
- 291 = G4A8L (M4RTU local I/O unit)

---

**REPEAT LAST RESPONSE (^)**

---

**5****DESCRIPTION:**

This command causes the I/O Unit to repeat the response to the previous command.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 5

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**ROM REVISION/DATE (\*)**

---

**6****DESCRIPTION:**

This command returns the revision level and date of the I/O Unit's EPROM Firmware. The values returned must be converted to hex to have meaning.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 6

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Low Byte of Checksum (Hex)  
*DATA[1]:* High Byte of Checksum (Hex)  
*DATA[2]:* Year (Hex)  
*DATA[3]:* Day (Hex)  
*DATA[4]:* Month (Hex)  
*DATA[5]:* Revision Level Minor (Hex)  
*DATA[6]:* Revision Level Major (Hex)

---

**CLEAR BUS ERROR FLAG MISTIC CONTROLLER (C)**

---

**7****DESCRIPTION:**

Clears an existing BUS ERROR flag which will stop the Mystic controller from sending a BUS ERROR CLEAR EXPECTED ERROR (-48) message in response to instructions following a bus error occurrence. Make sure this instruction is sent directly to the Mystic Controller (in BINARY mode) and NOT while in PASS-THRU mode.

**SEND PARAMETERS:**

*ADDRESS:* Address of Mystic Controller

*COMMAND:* 7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or Mystic Controller Error

---

**SET RESPONSE DELAY (~)**

---

**8****DESCRIPTION:**

This command is used to set a delay time for command responses.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 8

*DATA[0]:* Delay Value in units of 10 mSec. Range 8-bit value (0-255).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**CLEAR INTERRUPT REQUEST (ZB)**

---

**9****DESCRIPTION:**

This command clears the interrupt line if the IRQ line is active.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 9

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



# Multichannel Digital Commands

---

**SET I/O CONFIGURATION (G)**

100

**DESCRIPTION:**

This command configures the channels on an I/O unit.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	100
<i>POSITION[0]:</i>	Group Mask (0000 to FFFF Hex)
<i>DATA[0]...DATA[15]:</i>	Configure Type. If bit n is set in <i>POSITION[0]</i> , type must be in Data[n]. eg. <i>POSITION[0]</i> : = 32, Data[6] = Type.
Types	Counter (default input) = 0 Positive Pulse Measurement = 1 Negative Pulse Measurement = 2 Period Measurement = 3 Frequency Measurement = 4 Quadrature Counter Input = 5 On Time Totalizer Input = 6 Off Time Totalizer Input = 7 Output = 128

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**READ I/O CONFIGURATION (Y)****101**

---

**DESCRIPTION:**

This command reads the I/O configuration of the I/O unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 101

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]...DATA[15]:* Configuration type.  
Data[0] = type for channel 0.  
Data[15] = type for channel 15.

Types

- 0 = Counter (default)
- 1 = Positive Pulse Measurement
- 2 = Negative Pulse Measurement
- 3 = Period Measurement
- 4 = Frequency Measurement
- 5 = Quadrature Counter Input
- 6 = On Time Totalizer Input
- 7 = Off Time Totalizer Input
- 128 = Output

---

**READ I/O STATUS (R)**

---

**102****DESCRIPTION:**

This command reads the status of all the digital channels (input or output).

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 102

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]...DATA[15]:* 0 if channel is in OFF state.  
1 if channel is in ON state.  
Data[0] = status of channel 0.  
Data[15] = status of channel 15.

---

**SET OUTPUTS (J)**

---

**103****DESCRIPTION:**

This command sets a group of output channels on an I/O Unit to an ON or an OFF state.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 103  
*POSITION[0]:* Bitmask of Modules to turn ON.  
*POSITION[1]:* Bitmask of Modules to turn OFF.  
Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

---

**READ LATCHES WITHOUT CLEARING (S)**

---

**104****DESCRIPTION:**

This command returns the state of the positive and negative latches but does not clear the latches.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 104

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]:* Bitmask of positive latches; bit set indicates latch set  
*DATA[1]:* Bitmask of negative latches; bit set indicates latch set  
Bitmask range is 0000 to FFFF Hex.

---

**ENABLE COUNTERS (H)**

---

**105****DESCRIPTION:**

This command enables a group of counters (standard or quadrature) on an I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 105  
*POSITION[0]:* Bitmask of counters to enable.  
A bit set enables that channel's counter.  
Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

---

**DISABLE COUNTERS (H)**

---

**106****DESCRIPTION:**

This command disables a group of counters (standard or quadrature) on an I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 106  
*POSITION[0]:* Bitmask of counters to disable.  
A bit set disables that channel's counter.  
Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

---

**READ COUNTER ENABLE/DISABLE STATUS (u)**

---

**107****DESCRIPTION:**

This command reads the enable/disable status of counters (standard or quadrature) on an I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 107

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]...DATA[15]:* 0 if counter is disabled, 1 if counter is enabled.  
Data[0] = status of counter 0.  
Data[15] = status of counter 15.



---

**READ COUNTERS WITHOUT CLEARING (T)**

---

**108****DESCRIPTION:**

This command reads a group of counters (standard or quadrature) on an I/O Unit. The counter values are not cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 108  
*POSITION[0]:* Bitmask of counters to read.  
A bit set reads that channel's counter.  
Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]...DATA[15]:* Counter Values. Range is 0 to 4,294,967,295 counts.  
Data[0] = Value of counter 0.  
Data[15] = Value of counter 15.

---

**READ AND CLEAR COUNTERS (U)**

---

**109****DESCRIPTION:**

This command reads a group of counters (standard or quadrature) on an I/O Unit. The counter values are cleared after they are read.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 109  
*POSITION[0]:* Bitmask of counters to read.  
A bit set reads and clears that channel's counter.  
Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]...DATA[15]:* Counter Values.  
Range is 0 to 4,294,967,295 counts.  
Data[0] = Value of counter 0.  
Data[15] = Value of counter 15.

---

**READ PULSE/PERIOD/TOTALIZER COMPLETE STATUS (V)**

---

**110****DESCRIPTION:**

This command reads the status of channels to indicate the channels which have measured one complete pulse, period, or totalizer.

**SEND PARAMETERS:**

*COMMAND:* 110

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

*DATA[0]:* Status Mask. Range: 0000 to FFFF Hex.  
A bit set in the status mask indicates that channel's measurement is complete.

---

**READ PULSE/PERIOD/TOTALIZER (W)**

---

**111****DESCRIPTION:**

This command reads the pulse or period measurement values from channels that have been configured as pulse, period, or totalizer measurement inputs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 111  
*POSITION[0]:* Bitmask of pulse/period channels to read. A bit set reads that channel's measurement. Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]...DATA[15]:* Pulse/Period Measurement Values.  
Range is 0 to 4,294,967,295 units.  
Units are 100 microseconds each.  
Data[0] = Value of channel 0.  
Data[15] = Value of channel 15.

---

**READ AND RESET PULSE/PERIOD/TOTALIZER (X)**

---

**112****DESCRIPTION:**

This command reads the pulse or period measurement values from channels that have been configured as pulse, period, or totalizer measurement inputs. The channels are then reset to 0 on the I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 112

*POSITION[0]:* Bitmask of pulse/period channels to read and reset. A bit set reads that channel's measurement. Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

*DATA[0]...DATA[15]:* Pulse/Period Measurement Values.  
Range is 0 to 4,294,967,295 units.  
Units are 100 microseconds each.  
Data[0] = Value of channel 0.  
Data[15] = Value of channel 15.

---

**READ FREQUENCY (Z)**

---

**113****DESCRIPTION:**

This command reads the frequency values from channels that have been configured for frequency measurement.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 113

*POSITION[0]:* Bitmask of frequency channels to read. A bit set reads that channel's measurement. Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

*DATA[0]...DATA[15]:* Frequency Measurement Values.  
Range is 0 to 65535 units, 1 or 10 Hz units depending on the SystemOptions Byte.  
Maximum frequency input is 25KHz.  
Data[0]= Value of channel 0.  
Data[15]= Value of channel 15.

---

**SET WATCHDOG (D)**

---

**114****DESCRIPTION:**

This command sets a group of output channels on an I/O Unit to go to an ON or an OFF state when a watchdog condition occurs. A watchdog condition occurs when a message is not received within the specified delay time.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 114  
*POSITION[0]:* Bitmask of Modules to turn ON.  
*POSITION[1]:* Bitmask of Modules to turn OFF. Bitmask range is 0000 to FFFF Hex.  
*DATA[0]:* Delay time in 10ms units. Range is 0 to 65535 units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

---

**READ EVENT LATCHES (P)**

---

**115****DESCRIPTION:**

This command reads the event latches of a group of 16 events out of a total of 256. Latches are set every time an event changes from a non-matching condition to a matching condition.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 115  
*POSITION[0]:* A group number ranging from 0 to 240 (F0 Hex) in multiples of 16.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]:* Status Mask. Range: 0000 to FFFF Hex.  
A bit set in the bitmask indicates that event latch is set.



---

**READ AND CLEAR EVENT LATCHES (Q)**

---

**116****DESCRIPTION:**

This command reads and then clears the event latches of a group of 16 events out of a total of 256. Latches are set every time an event changes from a non-matching condition to a matching condition.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 116  
*POSITION[0]:* A group number in the range of 0 to 240 (F0 Hex) in multiples of 16.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[0]:* Status Mask. Range: 0000 to FFFF Hex.  
A bit set in the bitmask indicates that event latch was set.

---

**READ AND CLEAR POSITIVE LATCHES (S)**

---

**117****DESCRIPTION:**

This command returns the state of the positive and negative latches, then clears the positive latches in the I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 117

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

*DATA[0]:* Bitmask of positive latches; bit set indicates latch set.

*DATA[1]:* Bitmask of negative latches; bit set indicates latch set.  
Bitmask range is 0000 to FFFF Hex.

---

**READ AND CLEAR NEGATIVE LATCHES (S)**

---

**118****DESCRIPTION:**

This command returns the state of the positive and negative latches, then clears the negative latches in the I/O Unit.

**SEND PARAMETERS:**

*COMMAND:* 118

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

*DATA[0]:* Bitmask of positive latches; bit set indicates latch set.

*DATA[1]:* Bitmask of negative latches; bit set indicates latch set.  
Bitmask range is 0000 to FFFF Hex.

---

**READ AND CLEAR POSITIVE AND NEGATIVE LATCHES (S)**

---

**119****DESCRIPTION:**

This command returns the state of the positive and negative latches, then clears all the latches in the I/O Unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 119

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error

*DATA[0]:* Bitmask of positive latches; bit set indicates latch set.

*DATA[1]:* Bitmask of negative latches; bit set indicates latch set.  
Bitmask range is 0000 to FFFF Hex.

---

**READ I/O STATUS MASK (R)**

---

**120****DESCRIPTION:**

This command reads the status of all the digital channels (input or output).  
The value is returned as a bit mask.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 120

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Bitmask of status; bit set indicates channel is in ON state.  
Bitmask range is 0000 to FFFF Hex.



# Single Channel Digital Commands

---

 SET I/O CONFIGURATION (a)
 

---

200

**DESCRIPTION:**

This command configures a channel on an I/O unit.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	200
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F Hex).
<i>DATA[0]:</i>	Configure
Types	Counter (default) = 0 Positive Pulse Measurement = 1 Negative Pulse Measurement = 2 Period Measurement = 3 Frequency Measurement = 4 Quadrature Counter Input = 5 On Time Totalizer Input = 6 Off Time Totalizer Input = 7 Output = 128 0522_MisticWare_Manual.ps

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**CLEAR (DEACTIVATE) OUTPUT (e)**

---

**201****DESCRIPTION:**

This command turns OFF a channel on an I/O unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 201

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**SET (ACTIVATE) OUTPUT (d)**

---

**202****DESCRIPTION:**

This command turns ON a channel on an I/O unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 202

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**ENABLE COUNTER INPUT (b)**

---

**203****DESCRIPTION:**

This command enables a channel that has been configured as a counter.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 203

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**DISABLE COUNTER INPUT (b)**

---

**204****DESCRIPTION:**

This command disables a channel that has been configured as a standard counter or quadrature counter.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 204

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**CLEAR COUNTER INPUT (c)**

---

**205****DESCRIPTION:**

This command clears the counter value of a channel that has been configured as a standard counter or a quadrature counter to 0.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 205  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ COUNTER INPUT (32-BIT) (I)**

---

**206****DESCRIPTION:**

This command reads the counter (standard or quadrature) value of a channel and returns a 32-bit value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 206  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Counter Value; n is the value specified in *POSITION[0]:* for channel number. Range is 0 to 4,294,967,295 counts.

---

**READ AND CLEAR COUNTER INPUT (32 BIT) (n)**

---

**207****DESCRIPTION:**

This command reads the counter (standard or quadrature) value of a channel, returns a 32-bit value, then clears the counter to 0.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 207  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Counter Value; n is the value specified in *POSITION[0]*; or channel number. Range is 0 to 4,294,967,295 counts.

---

**READ COUNTER INPUT (16 BIT) (m)**

---

**208****DESCRIPTION:**

This command reads the counter (standard or quadrature) value of a channel and returns a 16-bit value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 208  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Counter Value; n is the value specified in *POSITION[0]:* for channel number. Range is 0 to 65,535 counts.

---

**READ AND CLEAR COUNTER INPUT (16 BIT) (0)**

---

**209****DESCRIPTION:**

This command reads the counter (standard or quadrature) value of a channel, returns a 16-bit value, then clears the counter to 0.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 209  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Counter Value; n is the value specified in *POSITION[0]*; for channel number. Range is 0 to 65,535 counts.



---

**READ PULSE/PERIOD/TOTALIZER MEASUREMENT INPUT (32-BIT) (p)**

---

**210****DESCRIPTION:**

This command reads the pulse, period, or totalizer measurement value of a channel and returns a 32-bit value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 210  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Pulse/Period Measurement Value; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 4,294,967,295 units, where one unit is 100 microseconds.

---

**READ AND RESET PULSE/PERIOD/TOTALIZER MEASUREMENT (32 BIT) (r) 211**

---

**DESCRIPTION:**

This command reads the pulse, period, or totalizer measurement value, returns a 32-bit value, then resets the I/O Unit's value to 0.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 211  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Pulse/Period Measurement Value; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 4,294,967,295 units, where one unit is 100 microseconds.

---

**READ PULSE/PERIOD/TOTALIZER MEASUREMENT INPUT (16-BIT) (q)**

---

**212****DESCRIPTION:**

This command reads the pulse, period, or totalizer measurement value of a channel and returns a 16-bit value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 212  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Pulse/Period Measurement Value; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 65,535 units, where one unit is 100 microseconds.

---

**READ AND RESET PULSE/PERIOD/TOTALIZER MEASUREMENT (16-BIT) (s) 213**

---

**DESCRIPTION:**

This command reads the pulse, period, or totalizer measurement value, returns a 16-bit value, then resets the I/O Unit's value to 0.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 213  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Pulse/Period Measurement Value; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 65,535 units, where one unit is 100 microseconds.

---

**READ FREQUENCY (t)**

---

**214****DESCRIPTION:**

This command reads the frequency value of a channel that has been configured for frequency measurement.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 214  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[N]:* Frequency Measurement Value; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 65,535 units. One unit represents 1 Hz or 10 Hz depending on System Options Byte. Maximum frequency input is 25KHz.

---

**START ON PULSE (f)**

---

**215****DESCRIPTION:**

This command starts a retriggerable ON pulse with a specified duration for the specified output channel.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 215

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

*DATA[0]:* Pulse duration in units of 100 microseconds. Range is 5 to 4,294,967,295 units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**START OFF PULSE (g)**

---

**216****DESCRIPTION:**

This command starts a retriggerable OFF pulse with a specified duration for the specified output channel.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 216

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

*DATA[0]:* Pulse duration in units of 100 microseconds. Range is 5 to 4,294,967,295 units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**START CONTINUOUS SQUARE WAVE (h)**

---

**217****DESCRIPTION:**

This command is used to start a continuous square wave with specified ON and OFF times for the specified output channel.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	217
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F Hex).
<i>DATA[0]:</i>	ON Pulse Duration in units of 100 microseconds. Range is 10 to 4,294,967,295 units.
<i>DATA[1]:</i>	OFF Pulse Duration in units of 100 microseconds. Range is 10 to 4,294,967,295 units.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------



---

**GENERATE N PULSES ( i )**

---

**218****DESCRIPTION:**

This command is used to generate an output pulse stream with specified ON • and OFF pulse duration and a specified number of pulses for the specified output channel.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	218
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F Hex).
<i>DATA[0]:</i>	ON Pulse Duration in units of 100 microseconds. Range is 10 to 4,294,967,295 units.
<i>DATA[1]:</i>	OFF Pulse Duration in units of 100 microseconds. Range is 10 to 4,294,967,295 units.
<i>DATA[2]:</i>	Number of pulses. Range is 10 to 4,294,967,295 pulses.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET TPO PERIOD ( )**

---

**219****DESCRIPTION:**

This command is used to set the period of a time proportional output. This command must be executed before the "SET TPO PERCENT" command (220).

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 219  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).  
*DATA[0]:* Period Value in units of 100 microseconds. Range is 1000 to 4,294,967,295 units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET TPO PERCENT ( j )**

---

**220****DESCRIPTION:**

This command is used to set the percent ON time of a time proportional output. The "SET TPO PERIOD" (219) command must have been previously sent at least once before this command can be executed.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 220

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

*DATA[0]:* Percent Value in units of 1/65,536 of a percent. Range is 0 to 4,294,967,295 units. A value of 0 (0%) will turn the channel OFF, and a value of 6,553,600 (100%) or greater will turn the channel ON continuously.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ LATCHES (w)**

---

**221****DESCRIPTION:**

This command reads the latch values for a channel. It does not clear the latches.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 221  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[N]:* Latch Values; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 255 (FF Hex), with the following bits set:  
bit 0: State of Positive Latch  
bit 1: State of Negative Latch  
bit 2: State of Module  
bits 3-7 are reserved.  
If bit is set, latch is set or module is On.

---

**READ LATCHES AND CLEAR POSITIVE LATCH (w)**

---

**222****DESCRIPTION:**

This command reads the latch values for a channel, and clears the positive latch value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 222  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[N]:* Latch Values; n is the value specified in *POSITION[0]*: for channel number. Range is 0 to 255 (FF Hex), with the following bits set:  
bit 0: State of Positive Latch  
bit 1: State of Negative Latch  
bit 2: State of Module  
bits 3-7 are reserved.  
If bit is set, latch is set or module is On

---

**READ LATCHES AND CLEAR NEGATIVE LATCH (w)**

---

**223****DESCRIPTION:**

This command reads the latch values for a channel, and clears the negative latch value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 223  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[N]:* Latch Values; n is the value specified in *POSITION[0]*: for channel number. Rabbit 0:  
State of Positive Latch  
bit 1: State of Negative Latch  
bit 2: State of Module  
bits 3-7 are reserved.  
If bit is set, latch is set or module is On.

---

**READ AND CLEAR LATCHES (w)**

---

**224****DESCRIPTION:**

This command reads the latch values for a channel, and clears both the negative and positive latch values.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 224  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Unit Error  
*DATA[N]:* Latch Values; n is the value specified in *POSITION[0]*: for channel number.  
Range is 0 to 255 (FF Hex), with the following bits set:  
bit 0: State Of Positive Latch  
bit 1: State Of Negative Latch  
bit 2: State Of Module  
bits 3-7 are reserved  
If bit is set, latch is set or module is On.

---

**READ OUTPUT TIMER COUNTER (k)**

---

**225****DESCRIPTION:**

This command reads the current time delay value of an output channel which may have a delay in progress. The value returned is the time remaining for the delay.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 225  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[N]:* Time Delay Value in units of 100 microseconds; n is the value specified in *POSITION[0]:* for channel number.  
Range is 0 to 4,294,967,295 units.



# Multichannel Analog Commands

## SET I/O CONFIGURATION (G)

300

### DESCRIPTION:

This command configures the channels on an analog I/O unit.

### SEND PARAMETERS:

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	300
<i>POSITION[0]:</i>	Group Mask (0000 to FFFF Hex)
<i>DATA[0]...</i>	
<i>DATA[15]:</i>	Configure Type. If bit n is set in <i>POSITION[0]</i> , type must be in Data[n]. eg. <i>POSITION[0]</i> : = 32 Data[6] = Type

Generic Input (default) = 0	G4AD25 0 - 100 VAC/VDC = 25	-10 to + 10 VDC Input = 0C
G4AD3 4 - 20 mA = 3	Generic Output = 28	0 to 250 V RMS Input = 46
G4AD4 ICTD = 4	G4DA3 4 - 20 mA = 131	ICTD Input = 04
G4AD5 Type J Therm. = 5	G4DA4 0 - 5 VDC = 132	100 Ohm (-200° to 850° C) RTD = 0A
G4AD6 0 - 5 VDC = 6	G4DA5 0 - 10 VDC = 133	100 Ohm (-60° to 250° C) RTD = 2E
G4AD7 0 - 10 VDC = 7	G4DA6 - 5 to + 5 VDC = 134	120 Ohm (-80° to 260° C) RTD = 30
G4AD8 Type K Therm. = 8	G4DA7 - 10 to + 10 VDC = 135	Type E Therm. = 13
G4AD9 0 - 50 mV = 9	G4DA8 0 - 20 mA = 136	Type J Therm. = 05
G4AD10 100 Ohm RTD = 10	G4DA9 TPO = 137	Type K Therm. = 08
G4AD11 - 5 to + 5 VDC = 11	0-20mA Input = 02	Type B Therm. = 18
G4AD12 - 10 to + 10 VDC = 12	4 - 20 mA Input = 03	Type C Therm. = 20
G4AD13 0 - 100 mV = 13	-20mA to +20mA Input = 40	Type D Therm. = 21
G4AD16 0 - 5 Amps, AC/DC = 16	0 to 10 Amps RMS Input = 47	Type G Therm. = 1F
G4AD17 Type R Therm. = 17	-25 mV to +25mV Input = 43	Type N Therm. = 1E
G4AD18 Type T Therm. = 18	-50 mV to +50 mV Input = 09	Type R Therm. = 11
G4AD19 Type E Therm. = 19	-75 mV to +75mV Input = 44	Type S Therm. = 17
G4AD20 Rate = 20	-150 mV to +150mV Input = 42	Type T. Therm. = 12
G4AD22 0 - 1 VDC = 21	0 - 5 VDC Input = 06	0 to 25, 000 Hz Input = 45
G4AD23 Type S Therm. = 23	0 - 10 VDC Input = 07	4 - 20 mA Output = A3
G4AD24 Type B Therm. = 24	5 to + 5 VDC Input = 0B	0 - 10 VDC Output = A5
		-10 to + 10 VDC Output = A7

### RECEIVE PARAMETERS:

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**READ I/O CONFIGURATION (Y)**

---

**301****DESCRIPTION:**

This command reads the I/O configuration of an analog I/O unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 301

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:*

Configuration type.

Data[0] = type for channel 0.

Data[15] = type for channel 15.

See command 300 for type descriptions.

**READ I/O MODULE MAGNITUDES-COUNTS (R)****302-326****DESCRIPTION:**

This command reads the magnitudes of analog channels and returns the values in accordance with the command used.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 302 = Raw Counts  
 303 = Average Count  
 304 = Peak Counts  
 305 = Low Counts  
 306 = Totalized Counts  
 322 = Square Root Of Raw Counts  
 323 = Square Root Of Average Counts  
 324 = Square Root Of Peak Counts  
 325 = Square Root Of Low Counts  
 326 = Square Root Of Total Counts

*Positions[0]:* Bitmask of channels to read.  
 A bit set reads that channel's value.  
 Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]...*  
*DATA[15]:* Channel Values from the channels specified in the Positions array.  
 If *POSITION[0]* = 8001 Hex (Chan. 0 and 15)  
 Then Data[0] = Value of channel 0 and  
 Data[15] = Value of channel 15.

**READ I/O MODULE MAGNITUDES-ENGINEERING UNITS (R)****307-331****DESCRIPTION:**

This command reads the magnitude of analog channels and returns values in engineering units in accordance with the command used and each channel's scaling parameters.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 307 = Scaled Value  
 308 = Average Value  
 309 = Peak Value  
 310 = Low Value  
 311 = Totalized Value  
 327 = Square Root Of Scaled Value  
 328 = Square Root Of Average Value  
 329 = Square Root Of Peak Value  
 330 = Square Root Of Low Value  
 331 = Square Root Of Totalized Value

*Positions[0]:* Bitmask of channels to read.  
 A bit set reads that channel's value.  
 Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]...*  
*DATA[15]:* Channel Values from the channels specified in the Positions array.  
 If *POSITION[0]:* = 8001 Hex (Chan. 0 and 15)  
 Then Data[0] = Value of channel 0, and  
 Data[15] = Value of channel 15.  
 32-bit values in increments of 1/65,536 of the engineering units.

**READ AND CLEAR I/O MAGNITUDES-COUNTS (S)****312-336****DESCRIPTION:**

This command reads the magnitudes of analog channels, returns the count values in accordance with the command used, then clears the channels.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 312 = Raw Counts  
 313 = Average Count  
 314 = Peak Count  
 315 = Low Count  
 316 = Totalized Count  
 332 = Square Root Of Raw Count  
 333 = Square Root Of Average Count  
 334 = Square Root Of Peak Count  
 335 = Square Root Of Low Counts  
 336 = Square Root Of Total Counts

*POSITION[0]:* Bitmask of channels to read.  
 A bit set reads that channel's value.  
 Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]...*  
*DATA[15]:* Channel Values from the channels specified in the Positions Array.  
 If *POSITION[0]:* = 8001 Hex (Chan. 0 & 15)  
 Then Data[0] = Value of channel 0, and  
 Data[15] = Value of channel 15.

**READ AND CLEAR MAGNITUDES-ENGINEERING UNITS (S)****317-341****DESCRIPTION:**

This command reads the magnitudes of analog channels, returns values in engineering units in accordance with the command used and the channel's scaling parameters, then clears the channels.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	317 = Scaled Value 318 = Average Value 319 = Peak Value 320 = Low Value 321 = Totalized Value 337 = Square Root Of Scaled Value 338 = Square Root Of Average Value 339 = Square Root Of Peak Value 340 = Square Root Of Low Value 341 = Square Root Of Totalized Value
<i>Positions[0]:</i>	Bitmask of channels to read. A bit set reads that channel's value. Bitmask range is 0000 to FFFF Hex.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
<i>DATA[0]...</i> <i>DATA[15]:</i>	Channel Values from the channels specified in the Positions array. If <i>POSITION[0]:</i> = 8001 Hex (Chan. 0 & 15) Then Data[0] = Value of channel 0, and Data[15] = Value of channel 15. 32-bit values in increments of 1/65,536 of the engineering units.

---

**SET I/O MODULE MAGNITUDES-COUNTS (X)**

---

**342****DESCRIPTION:**

This command sets the magnitudes of analog channels configured as outputs.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	342
<i>POSITION[0]:</i>	Bitmask of channels to set. A bit set sets that channel's value. Bitmask range is 0000 to FFFF Hex.
<i>DATA[0]...</i> <i>DATA[15]:</i>	Channel Values to set for the channels specified in the Positions Array. Range: 0 to 4095. If <i>POSITION[0]</i> = 8001 Hex (Chan. 0 and 15) Then Data[0] = Value for channel 0, and Data[15] = Value for channel 15.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET I/O MODULE MAGNITUDES-ENGINEERING UNITS (W)**

---

**343****DESCRIPTION:**

This command sets the magnitudes of analog channels configured as outputs using scaled engineering units.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 343

*POSITION[0]:* Bitmask of channels to set. A bit set sets that channel's value.  
Bitmask range is 0000 to FFFF Hex.

*DATA[0]...*  
*DATA[15]:* Channel values to set for the channels specified in the Positions Array.  
Range: 32-bit values (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of the engineering units.  
If *POSITION[0]*: = 8001 Hex (Chan. 0 and 15)  
Then Data[0] = Value for channel 0, and  
Data[15] = Value for channel 15.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**SET WATCHDOG TIME (D)**

---

**344****DESCRIPTION:**

This command sets the communications line watchdog timeout period for the addressed I/O unit.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 344  
*DATA[0]:* Delay Value in units of 10 mS.  
Range: 20 to 4095 (200mS-40.95 Sec)  
Value of 0 Disables Watchdog

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

**SET WATCHDOG DATA-ENGINEERING UNITS (H)****345****DESCRIPTION:**

This command sets the desired output values for the specified analog modules upon a communications link watchdog timeout condition.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	345
<i>POSITION[0]:</i>	Bitmask of channels to set. A bit set sets that channel's value. Bitmask range is 0000 to FFFF Hex.
<i>DATA[0]...</i> <i>DATA[15]:</i>	Channel Values to set for the channels specified in the Positions Array. Range: 32-bit values (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of the engineering units. If <i>POSITION[0]</i> = 8001 Hex (Chan. 0 and 15) Then Data[0] = Value for channel 0, and Data[15] = Value for channel 15.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

# Single Channel Analog Commands

## SET I/O CHANNEL CONFIGURATION (a)

400

### DESCRIPTION:

This command configures a channel on an analog I/O unit.

### SEND PARAMETERS:

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 400  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).  
*DATA[0]:* Configure Type.

[Decimal]	G4AD25 0 - 100 VAC/VDC = 25	-10 to + 10 VDC Input = 0C
Generic Input (default or scalable) = 0	Generic Output = (default or scalable) 128	0 to 250 V RMS Input = 46
G4AD3 4 - 20 mA = 3	G4DA3 4 - 20 mA = 131	ICTD Input = 04
G4AD4 ICTD = 4	G4DA4 0 - 5 VDC = 132	100 Ohm (-200° to 850° C) RTD = 0A
G4AD5 Type J Therm. = 5	G4DA5 0 - 10 VDC = 133	100 Ohm (-60° to 250° C) RTD = 2E
G4AD6 0 - 5 VDC = 6	G4DA6 - 5 to + 5 VDC = 134	120 Ohm (-80° to 260° C) RTD = 30
G4AD7 0 - 10 VDC = 7	G4DA7 - 10 to + 10 VDC = 135	Type E Therm. = 13
G4AD8 Type K Therm. = 8	G4DA8 0 - 20 mA = 136	Type J Therm. = 05
G4AD9 0 - 50 mV = 9	G4DA9 TPO = 137	Type K Therm. = 08
G4AD10 100 Ohm RTD = 10	[Hex]	Type B Therm. = 18
G4AD11 - 5 to + 5 VDC = 11	0-20mA Input = 02	Type C Therm. = 20
G4AD12 - 10 to + 10 VDC = 12	4 - 20 mA Input = 03	Type D Therm. = 21
G4AD13 0 - 100 mV = 13	-20mA to +20mA Input = 40	Type G Therm. = 1F
G4AD16 0 - 5 Amps, AC/DC = 16	0 to 10 Amps RMS Input = 47	Type N Therm. = 1E
G4AD17 Type R Therm. = 17	-25 mV to +25mV Input = 43	Type R Therm. = 11
G4AD18 Type T Therm. = 18	-50 mV to +50 mV Input = 09	Type S Therm. = 17
G4AD19 Type E Therm. = 19	-75 mV to +75mV Input = 44	Type T. Therm. = 12
G4AD20 Rate = 20	-150 mV to +150mV Input = 42	0 to 25, 000 Hz Input = 45
G4AD22 0 - 1 VDC = 21	0 - 5 VDC Input = 06	4 - 20 mA Output = A3
G4AD23 Type S Therm. = 23	0 - 10 VDC Input = 07	0 - 10 VDC Output = A5
G4AD24 Type B Therm. = 24	5 to + 5 VDC Input = 0B	-10 to + 10 VDC Output = A7
		SNAP-AOD-29 = A9

### RECEIVE PARAMETERS:

*ERROR:* Driver or I/O Error

**SET ANALOG TPO PERIOD ( )****401****DESCRIPTION:**

This command sets the period prescale value for the G4DA9 or the SNAP-AOD-29 analog TPO module.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	401
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F Hex)
<i>Data [0]:</i>	Resolution Setting. Range: 8-bit value (1-255).

**For the G4DA9**, it equals the resolution in 500us units. The period of the TPO module is calculated as follows:

$TPO\ Period = Resolution\ Setting * 500\ microseconds * 4,096.$

The default Resolution Setting is 2, yielding a resolution of 1 millisecond and a TPO period of 4.096 second.

**For the SNAP-AOD-29**, calculate the period as follows:

$TPO\ Period = (Resolution\ Setting + 1) * 251\ ms$

For example, a setting of zero yields 251 ms; a setting of one yields 502 ms, etc.

**IMPORTANT:** After using this command, set the TPO percentage using the command Set I/O Mode Magnitude - Engineering Units (443). For example, set a percentage such as 50%, where the actual value for Data[0] is  $50(65536) = 3,276,800$

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**READ I/O MODULE MAGNITUDE-COUNTS (r)**

---

**402-426****DESCRIPTION:**

This command reads the magnitude of an analog channel and returns a value in accordance with the command used.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 402 = Raw Counts  
403 = Average Counts  
404 = Peak Counts  
405 = Low Counts  
406 = Totalized Counts  
422 = Square Root Of Raw Counts  
423 = Square Root Of Average Counts  
424 = Square Root Of Peak Counts  
425 = Square Root Of Low Counts  
426 = Square Root Of Total Counts

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Channel Value

**READ I/O MODULE MAGNITUDE-ENGINEERING UNITS (r)****407-431****DESCRIPTION:**

This command reads the magnitude of an analog channel and returns a value in engineering units in accordance with the command used and the channel's scaling parameters.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 407 = Scaled Value  
408 = Average Value  
409 = Peak Value  
410 = Low Value  
411 = Totalized Value  
427 = Square Root Of Scaled Value  
428 = Square Root Of Average Value  
429 = Square Root Of Peak Value  
430 = Square Root Of Low Value  
431 = Square Root Of Totalized Value

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Channel Value. 32-bit value in increments of 1/65,536 of the engineering units.

---

**READ AND CLEAR I/O MAGNITUDE-COUNTS (s)**

---

**412-436****DESCRIPTION:**

This command reads the magnitudes of an analog channel, returns the counts value in accordance with the command used, then clears the channel.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	412 = Raw Counts 413 = Average Counts 414 = Peak Counts 415 = Low Counts 416 = Totalized Counts 432 = Square Root Of Raw Counts 433 = Square Root Of Average Counts 434 = Square Root Of Peak Counts 435 = Square Root Of Low Counts 436 = Square Root Of Total Counts
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F Hex). Receive Parameters:
<i>ERROR:</i>	Driver or I/O Error
<i>DATA[0]:</i>	Channel Value

**READ AND CLEAR I/O MAGNITUDE-ENGINEERING UNITS (s)****417-441****DESCRIPTION:**

This command reads the magnitude of an analog channel, returns the value in engineering units in accordance with the command used and the channel's scaling parameters, then clears the channel.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 417 = Scaled Value  
418 = Average Value  
419 = Peak Value  
420 = Low Value  
421 = Totalized Value  
437 = Square Root Of Scaled Value  
438 = Square Root Of Average Value  
439 = Square Root Of Peak Value  
440 = Square Root Of Low Value  
441 = Square Root Of Totalized Value

*POSITION[0]:* Channel Number 0-15 (00-0F Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Channel Value.  
32-bit value in increments of 1/65,536 of the engineering units.



---

**SET I/O MODULE MAGNITUDE-COUNTS (x)**

---

**442****DESCRIPTION:**

This command sets the magnitude of an analog channel configured as an output.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 442  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).  
*DATA[0]:* Channel Value.  
Range: 0 to 4,095.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET I/O MODULE MAGNITUDE-ENGINEERING UNITS (w)**

---

**443****DESCRIPTION:**

This command sets the magnitude of an analog channel configured as an output using scaled engineering units.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 443  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).  
*DATA[0]:* Channel Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of the engineering units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET SCALING PARAMETERS (f)**

---

**444****DESCRIPTION:**

This command sets the zero scale and full scale parameters of an analog channel (input or output).

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	444
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F Hex).
<i>DATA [0]:</i>	Full Scale Value. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of the engineering units.
<i>DATA [1]:</i>	Zero Scale Value. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of the engineering units.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET TOTALIZATION SAMPLE RATE (g)**

---

**445****DESCRIPTION:**

This command initiates totalization on an input or output channel by setting the sample rate in 100 mSec units.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 445  
*POSITION[0]:* Channel Number 0-15 (00-0F Hex).  
*DATA[0]:* Sample Rate.  
Range: 0 to 65,535 in units of 100 mSec (0 - 6,553.5 Sec.)

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET AVERAGING SAMPLE WEIGHT (h)**

---

**446****DESCRIPTION:**

This command initiates averaging (digital filtering) on an input channel by setting the sample weight using the following formulas:

$$\text{New Average} = (\text{Current} - \text{Old}) / \text{Sample Weight} + \text{Old}$$

$$\text{Sample Weight} = (100\text{mSec} + \text{TC}) / 100\text{mSec}$$

Where TC is the desired filter time constant.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	446
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F-Hex)
<i>DATA[0]:</i>	Sample Weight. Range: 0 to 65,535.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**CALCULATE AND SET OFFSET (d)**

---

**447****DESCRIPTION:**

This command instructs the addressed I/O unit to use the current value of the specified input channel as the zero scale value. This reading is multiplied by -1 and is used as an offset. The offset value is returned.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 447  
*POSITION[0]:* Channel Number 0-15 (00-0F-Hex)

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Offset Counts.  
Range: 0 to 65,535.

**Note:** *The input must be at a zero or minimum value when this command is issued.*

---

**CALCULATE AND SET GAIN (e)**

---

**448****DESCRIPTION:**

This command instructs the addressed I/O unit to use the current value of the specified input channel as the full scale value. This reading is divided by 4,096 and is used as a gain coefficient. The input reading value is returned.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 448  
*POSITION[0]:* Channel Number 0-15 (00-0F-Hex)

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Gain Counts.  
Range: 0 to 65,535.

**Note:** *This command adjusts the gain so that the value applied to the input when the command is issued becomes a full-scale reading.*

---

**SET OFFSET (b)**

---

**449****DESCRIPTION:**

This command sets an offset for an analog input channel. The offset is added to the raw count data before any engineering unit scaling is done.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 449  
*POSITION[0]:* Channel Number 0-15 (00-0F-Hex)  
*DATA[0]:* Offset Counts.  
Range: 0 to 65,535.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**SET GAIN (c)**

---

**450****DESCRIPTION:**

This command is used to set the gain coefficient for the an analog input channel. The gain coefficient must be scaled by 4,096.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 450  
*POSITION[0]:* Channel Number 0-15 (00-0F-Hex)  
*DATA[0]:* Gain Counts.  
Range: 0 to 65,535.  
Example: For a gain of .96,  
Gain Counts =  $.96 * 4,096 = 3,932$ .

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**RAMP OUTPUT TO ENDPOINT (Z)**

---

**451****DESCRIPTION:**

This command is used to ramp an analog output from its current setting to a specified endpoint at a specified ramp rate.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	451
<i>POSITION[0]:</i>	Channel Number 0-15 (00-0F-Hex)
<i>DATA[0]:</i>	Ramp Endpoint. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.
<i>DATA[1]:</i>	Ramp Slope (Engineering Units per Sec). Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit. Slope of 0 is not allowed.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**DUMP CHANNEL DATA ( [ ] )**

---

**452****DESCRIPTION:**

This command is a reserved command used to obtain a raw dump of the I/O unit's channel database for a specified channel. The structure of this data is included in appendix B.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 452  
*POSITION[0]:* Channel Number 0-15 (00-0F-Hex)

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]..*  
*DATA[15]:* 64 bytes of data.



# Analog PID Commands

---

**INITIALIZE PID LOOP (i)**

---

509

**DESCRIPTION:**

This command initializes a PID loop by defining the input and output channels, and the scan rate.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	500
<i>POSITION[0]:</i>	Loop Number 0-7.
<i>DATA[0]:</i>	Input Channel Number 0-15.
<i>DATA[1]:</i>	Setpoint Channel Number 0-15.
<i>DATA[2]:</i>	Output Channel Number 0-15.
<i>DATA[3]:</i>	Scan Rate. Range: 0 to 65,535 in units of 100 mSec (0 - 6,553.5 Sec.)

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

**SET PID LOOP CONTROL OPTIONS ( j )****501****DESCRIPTION:**

This command is used to set the operating options in the loop control word. The Loop Control Word is structured as follows:

Least Significant Byte (LSB) - Control Byte

- bit 0 : 0 = Current Reading  
1 = Average Reading
- bit 1 : 0 = Setpoint From Host  
1 = Setpoint From Channel
- bit 2 : 0 = Process Variable From Channel  
1 = Process Variable From Host
- bit 3 : 0 = Setpoint Track Input In Manual Disabled  
1 = Setpoint Track Input In Manual Enabled
- bit 4 : 0 = Output Track Input In Manual Disabled  
1 = Output Track Input In Manual Enabled
- bit 5 : 0 = Output Disabled  
1 = Output Enabled
- bit 6 : 0 = PID In Manual Mode  
1 = PID In Auto Mode
- bit 7 : 0 = PID In Reset Mode  
1 = PID In Active Mode

Most Significant Byte (MSB) - Flags Byte

- bit 0 : 0 = No Error  
1 = Input Under Range Error
- bit 1 : 0 = No Error  
1 = Minimum Setpoint Exceeded Error
- bit 2 : 0 = No Error  
1 = Maximum Setpoint Exceeded Error
- bits 3-7 : Reserved.

**SEND PARAMETERS:**

- ADDRESS:* Address of I/O Unit
- COMMAND:* 501
- POSITION[0]:* Loop Number 0-7.
- DATA[0]:* Mask Of Control Bits To Set.  
0000 to FFFF Hex (0-65,535)
- DATA[1]:* Mask Of Control Bits To Clear.  
0000 to FFFF Hex (0-65,535)

**RECEIVE PARAMETERS:**

- ERROR:* Driver or I/O Error

---

**SET PID LOOP SETPOINT (k)**

---

**502****DESCRIPTION:**

This command sets the magnitude of a PID loop's setpoint using scaled engineering units.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 502

*POSITION[0]:* Loop Number 0-7.

*DATA[0]:* Setpoint Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of the engineering units.  
The range of values must be the same as the range for  
the input channel.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET PID LOOP GAIN (I)****503**

---

**DESCRIPTION:**

This command sets the PID loop's gain value. A negative loop gain is used to effect a reverse control action.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 503  
*POSITION[0]:* Loop Number 0-7.  
*DATA[0]:* Gain Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647) scaled in increments of 1/65,536.  
Example: For a gain of 2,  
Gain Value =  $2 * 65,536 = 131,072$ .

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**SET PID LOOP INTEGRAL RESET RATE (m)**

---

**504****DESCRIPTION:**

This command sets the PID loop's integral value in repeats per minute.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 504

*POSITION[0]:* Loop Number 0-7.

*DATA[0]:* Integral Value. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) scaled in increments of 1/65,536.

Example: For an integral of 7.5,  
Integral Value =  $7.5 * 65,536 = 491,520$ .

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET PID LOOP DERIVATIVE RATE (n)**

---

**505****DESCRIPTION:**

This command sets the PID loop's derivative value in minutes.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 505  
*POSITION[0]:* Loop Number 0-7.  
*DATA[0]:* Deriv. Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647) scaled  
in increments of 1/65,536.  
Example: For a derivative of .03,  
Derivative Value = .03 \* 65,536 = 1966.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET PID LOOP SETPOINT MIN/MAX LIMITS (o)**

---

**506****DESCRIPTION:**

This command is used to set the minimum and maximum allowable setpoints for the PID Loop. The units must be the same as those specified for the input.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	506
<i>POSITION[0]:</i>	Loop Number 0-7
<i>DATA[0]:</i>	Maximum Setpoint. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.
<i>DATA[1]:</i>	Minimum Setpoint. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

**READ ALL PID LOOP PARAMETERS (T)****507****DESCRIPTION:**

This command reads all PID loop parameters.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 507  
*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Output Value.  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[1]:* Output Value Counts.  
 Range: 16-bit value (0-4095 counts).  
*DATA[2]:* Min. Setpoint Limit.  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[3]:* Max. Setpoint Limit.  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of a engineering unit.  
*DATA[4]:* Loop Derivative Rate (Minutes).  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[5]:* Loop Integral Reset Rate (Repeats per Minutes).  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[6]:* Loop Gain Value.  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[7]:* Setpoint Value.  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[8]:* Input Value.  
 Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
 in increments of 1/65,536 of an engineering unit.  
*DATA[9]:* Input, Output, Setpoint Channel Numbers.  
*DATA[10]:* Loop Control Word and Scan Rate.

---

**READ LOOP CONTROL WORD (t)**

---

**508****DESCRIPTION:**

This command reads the PID loop Control Word. See command 501 for a definition of the Control Word and each bit it contains.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 508

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Loop Control Word.  
Range: 16-bit value, (0-65,535 or 0000-FFFF Hex)

---

**READ SCAN RATE WORD (t)**

---

**509****DESCRIPTION:**

This command reads the PID loop scan rate value. The value is in units of 100 mSec.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 509

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Scan Rate Word.  
Range: 16-bit value (0-65,535), in units of 100 mSec.

---

**READ OUTPUT COUNTS (t)**

---

**510****DESCRIPTION:**

This command reads the value of the PID loop output in counts.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 510

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Output Counts.  
Range: 16-bit value (0-4,095).

---

**READ LOOP CHANNELS (t)****511**

---

**DESCRIPTION:**

This command reads the channel numbers for the PID loop's input, setpoint, and output.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 511

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Output Channel (0-15).

*DATA[1]:* Reserved.

*DATA[2]:* Setpoint Channel (0-15).

*DATA[3]:* Input Channel (0-15).



---

**READ INPUT VALUE (PROCESS VARIABLE) (t)**

---

**512****DESCRIPTION:**

This command reads the value for the PID loop's input channel.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 512

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Input Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ SETPOINT VALUE (t)**

---

**513****DESCRIPTION:**

This command reads the PID loop's setpoint value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 513

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Setpoint Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ OUTPUT VALUE (t)**

---

**514****DESCRIPTION:**

This command reads the PID loop's output value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 514

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Output Value.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ GAIN TERM (t)**

---

**515****DESCRIPTION:**

This command reads the PID loop's Gain Term.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 515

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Gain Term.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ INTEGRAL TERM (t)**

---

**516****DESCRIPTION:**

This command reads the PID loop's Integral Term. This value is in repeats per minute.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 516

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Integral Term (Repeats per Min.).  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ DERIVATIVE TERM (t)**

---

**517****DESCRIPTION:**

This command reads the PID loop's Derivative Term. This value is in minutes.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 517

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Derivative Term (Minutes).  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ MAXIMUM SETPOINT LIMIT (t)**

---

**518****DESCRIPTION:**

This command reads the Maximum Setpoint Limit of the PID loop.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 518

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Max. Setpoint Limit.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.

---

**READ MINIMUM SETPOINT LIMIT (t)**

---

**519****DESCRIPTION:**

This command reads the Minimum Setpoint Limit of the PID loop.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 519

*POSITION[0]:* Loop Number 0-7

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]:* Minute Setpoint Limit.  
Range: 32-bit value (-2,147,483,648 to +2,147,483,647)  
in increments of 1/65,536 of an engineering unit.



---

**SET PID LOOP OUTPUT MIN/MAX LIMITS (p)**

---

**520****DESCRIPTION:**

This command is used to set the minimum and maximum allowable output of the PID Loop.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	520
<i>POSITION[0]:</i>	Loop Number 0-7
<i>DATA[0]:</i>	Maximum Output. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.
<i>DATA[1]:</i>	Minimum Output. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET PID LOOP PROCESS VARIABLE (q)**

---

**521****DESCRIPTION:**

This command sets the PID loop's process variable.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 521  
*POSITION[0]:* Loop Number 0-7  
*DATA[0]:* Process variable. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) scaled in increments of 1/65,536.  
Example: For an integral of 7.5, Integral Value = 7.5\*  
65,536 = 491,520.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

# Digital Event/Reaction Commands

---

**CLEAR EVENT/REACTION TABLE ( \_ )**

---

600

**DESCRIPTION:**

This command is used to clear the entire Event/Reaction table. All event latches and interrupts are also cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 600

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**CLEAR EVENT TABLE ENTRY ( \ )**

---

**601****DESCRIPTION:**

This command is used to clear a single entry in the Event/Reaction table.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 601

*POSITION[0]:* Event Table Entry Number (00-FF-Hex)

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ EVENT ENTRY ENABLE/DISABLE STATUS (v)**

---

**602****DESCRIPTION:**

This command returns 16 status bits representing the status of 16 events starting with the specified event number. Each bit corresponds to the status of one event. If the bit is 1, the event is enabled; if the bit is 0, the event is disabled.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 602  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*DATA[0]:* Status of 16 events.  
Range: 16-bit (0-65,535 or 0000-FFFF Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ ALL EVENT ENTRIES ENABLE/DISABLE STATUS (v)**

---

**603****DESCRIPTION:**

This command returns 255 status bits representing the status of all events in the Event/Reaction Table. Each bit corresponds to the status of one event. If the bit is 1, the event is enabled; if the bit is 0, the event is disabled.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 603

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:*

Status of 16 events.

Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

Data[0] = Events 0-15, and

Data[15] = Events 240-255.

---

**ENABLE EVENT TABLE ENTRY (N)**

---

**604****DESCRIPTION:**

This command is used to enable an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 604

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**DISABLE EVENT TABLE ENTRY (N)**

---

**605****DESCRIPTION:**

This command is used to disable an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 605

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**ENABLE/DISABLE EVENT TABLE GROUP ( { } )**

---

**606****DESCRIPTION:**

This command is used to set the enable/disable status of an entire event table group of 16 entries.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	606
<i>POSITION[0]:</i>	Event Table Group Number (00-FF-Hex).
<i>DATA[0]:</i>	16-bit Mask of events within group to enable. If bit is 1, event is enabled.
<i>DATA[1]:</i>	16-bit Mask of events within group to disable. If bit is 1, event is disabled.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

**READ EVENT TABLE ENTRY (O)****608****DESCRIPTION:**

This command is used to read the contents of an event table entry. The Reaction Command can have the following value:

NULL REACTION (DO NOTHING)	00
SET OUTPUT MODULE STATE	01
START ON PULSE	02
START OFF PULSE	03
ENABLE/DISABLE COUNTER	04
CLEAR COUNTER	05
ENABLE/DISABLE EVENT TABLE ENTRY	06
ENABLE/DISABLE EVENT ENTRY GROUP	07
READ AND HOLD COUNTER VALUE	08

The control byte contains the following information:

**Control Byte**

bit 0	:	0	=	Event Latch-No Match
		1	=	Event Latch-Match
bit 1	:	0	=	Match Latch-No Match
		1	=	Match Latch-Match
bit 2	:	0	=	Null Entry-Not Scanned
		1	=	Valid Entry-Scan Active
bit 3	:	0	=	Watchdog Monitoring Disabled
		1	=	Watchdog Monitoring Enabled
bit 4	:	0	=	Counter/MOMO Compare-No Match
		1	=	Counter/MOMO Compare-Match
bit 5	:	0	=	Not The Last Entry
		1	=	Last Entry
bit 6	:	0	=	Interrupt Disabled
		1	=	Interrupt Enabled
bit 7	:	0	=	Event Scanning Disabled
		1	=	Event Scanning Enabled

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	608
<i>POSITION[0]:</i>	Event Table Entry Number (0-FF-Hex).

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
<i>DATA[0]:</i>	Low Word Reaction MOMO/Delay
<i>DATA[1]:</i>	High Word Reaction MOMO/Delay
<i>DATA[2]:</i>	Low Word Compare MOMO/Counter
<i>DATA[3]:</i>	High Word Compare MOMO/Counter
<i>DATA[4]:</i>	High Byte Bit 0 = Enable/Disable Flag Low Byte = Reserved
<i>DATA[5]:</i>	High Byte = Reaction Command Low Byte = Reaction Channel
<i>DATA[6]:</i>	High Byte = Control Byte Low Byte = Compare Channel

---

**READ EVENT LATCHES (P)**

---

**609****DESCRIPTION:**

This command returns 16 status bits representing the status of 16 event latches starting with the specified event number. Each bit corresponds to the status of one event latch. If the bit is 1, the event latch is set; if the bit is 0, the event latch is cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 609  
*Positions[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Status of 16 event latches.  
Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

---

**READ ALL EVENT LATCHES (P)**

---

**610****DESCRIPTION:**

This command returns 255 status bits representing the status of all event latches in the Event/Reaction Table. Each bit corresponds to the status of one event latch. If the bit is 1, the latch is set; if the bit is 0, the latch is cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 610

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:* Status of 16 latches.

Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

Data[0] = Event Latches 0-15, and

Data[15] = Event Latches 240-255.

---

**READ AND CLEAR EVENT LATCHES (Q)**

---

**611****DESCRIPTION:**

This command returns 16 status bits representing the status of 16 event latches starting with the specified event number. Each bit corresponds to the status of one event latch. If the bit is 1, the event latch is set; if the bit is 0, the latch is cleared. The latch is cleared after it is read.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 611  
*Positions[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Status of 16 event latches.  
Range: 16-bit (0-65,535 or 0000-FFFF Hex).

---

**READ AND CLEAR ALL EVENT LATCHES (Q)**

---

**612****DESCRIPTION:**

This command returns 255 status bits representing the status of all event latches in the Event/Reaction Table. Each bit corresponds to the status of one event latch. If the bit is 1, the latch is set; if the bit is 0, the latch is cleared. The latches are all cleared after they are read.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 612

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:*

Status of 16 latches.

Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

Data[0] = Event Latches 0-15, and

Data[15] = Event Latches 240-255.

---

**ENABLE EVENT INTERRUPT (I)**

---

**613****DESCRIPTION:**

This command is used to enable the interrupt output function of an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 613

*POSITIONS[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**DISABLE EVENT INTERRUPT (I)**

---

**614****DESCRIPTION:**

This command is used to disable the interrupt output function of an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 614

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET EVENT ON COMM LINK WATCHDOG TIMEOUT (y)**

---

**615****DESCRIPTION:**

This command is used to add an event entry to the table that monitors a watchdog timeout condition.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 615

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET EVENT ON MOMO MATCH (K)**

---

**616****DESCRIPTION:**

This command is used to add an event entry to the table that looks for a match of specified patterns of modules which must be on and which must be off.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	616
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>DATA[0]:</i>	Bitmask of Modules which must be ON. Bitmask range is 0000-FFFF-Hex.
<i>DATA[1]:</i>	Bitmask of Modules which must be OFF. Bitmask range is 0000-FFFF-Hex.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET EVENT ON COUNTER GREATER OR EQUAL (L)**

---

**617****DESCRIPTION:**

This command is used to add an event entry to the table that looks for a counter value to be greater than or equal to the specified value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 617  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Counter Channel 0-15 (00-0F-Hex).  
*DATA[0]:* Counter Compare Value;  
Range is 0 to 4,294,967,295 counts.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**CLEAR REACTION (M)**

---

**618****DESCRIPTION:**

This command is used to clear an existing reaction from an event/reaction table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 618

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET OUTPUT STATE REACTION (M)**

---

**619****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which sets the outputs to a specified condition when the event occurs.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	619
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>DATA[0]:</i>	Bitmask of Modules to turn ON. Bitmask range is 0000-FFFF-Hex.
<i>DATA[1]:</i>	Bitmask of Modules to turn OFF. Bitmask range is 0000-FFFF-Hex.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET ON PULSE REACTION (M)**

---

**620****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which generates an ON-Pulse when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 620  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Pulse Channel 0-15 (00-0F-Hex).  
*DATA[0]:* Pulse Duration in units of 100 microseconds.  
Range is 5 to 4,294,967,295 units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET OFF PULSE REACTION (M)**

---

**621****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which generates an OFF-Pulse when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 621  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Pulse Channel 0-15 (00-0F-Hex).  
*DATA[0]:* Pulse Duration in units of 100 microseconds.  
Range is 5 to 4,294,967,295 units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



---

**SET ENABLE/DISABLE COUNTER REACTION (M)**

---

**622****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will enable or disable a counter when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 622  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Counter Channel 0-15 (00-0F-Hex).  
*DATA[0]:* 0 to disable counter, 1 to enable counter.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**CLEAR COUNTER REACTION (M)**

---

**623****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will clear a counter when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 623  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Counter Channel 0-15 (00-0F-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET ENABLE/DISABLE EVENT ENTRY REACTION (M)**

---

**624****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will enable or disable an event entry when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 624  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Event Table Entry Number to be enabled/disabled 0-255 (00-FF-Hex).  
*DATA[0]:* 0 to disable the event entry, 1 to enable the event entry.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET ENABLE/DISABLE EVENT GROUP REACTION (M)**

---

**625****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will enable or disable a group or all event entries when the event occurs. A group consists of sixteen events beginning with the event number in *POSITION[1]*.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	625
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>POSITION[1]:</i>	Event Table Entry Number 0-255 (00-FF-Hex). An entry of 255 will enable/disable an entire group.
<i>DATA[0]:</i>	16-bit Mask of events within group to enable. If bit is 1, event is enabled. Bitmask range is 0000-FFFF-Hex.
<i>DATA[1]:</i>	16-bit Mask of events within group to disable. If bit is 1, event is disabled. Bitmask range is 0000-FFFF-Hex.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**READ AND HOLD COUNTER VALUE REACTION (M)**

---

**626****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will read and store a counter value when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 626  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Counter Channel 0-15 (00-0F-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ EVENT HOLD BUFFER (I)**

---

**627****DESCRIPTION:**

This command is used to read the event hold buffer. It is used in conjunction with Command 626 which sets up a reaction that will place a counter value in an event's hold buffer when an event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 627  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Hold Buffer Value. Range is 0 to 4,294,967,295.

---

**SET EVENT ON COUNTER LESS OR EQUAL (}**

---

**628****DESCRIPTION:**

This command is used to add an event entry to the table that looks for a counter value to be less than or equal to the specified value.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 628  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Counter Channel 0-15 (00-0F-Hex).  
*Data [0]:* Counter Compare Value;  
Range is 0 to 4,294,967,295 counts.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ AND CLEAR EVENT LATCH - SINGLE CHANNEL (zA)**

---

**629****DESCRIPTION:**

This command returns a control byte which contains the state of the event latch and then optionally clears the latch.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 629  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex)  
*DATA[0]:* Any 8-bit value (1-255) other than 0, clears the latch.  
A value of 0 leaves the latch in its current state.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* 8-bit control byte.  
If bit 0 is set, the event occurred.



# Analog Event/Reaction Commands

---

**CLEAR EVENT/REACTION TABLE (-)**

---

700

**DESCRIPTION:**

This command is used to clear the entire Event/Reaction table. All event latches and interrupts are also cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 700

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**CLEAR EVENT TABLE ENTRY (I)**

---

**701****DESCRIPTION:**

This command is used to clear a single entry in the Event/Reaction table.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 701

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ EVENT ENTRY ENABLE/DISABLE STATUS (v)**

---

**702****DESCRIPTION:**

This command returns 16 status bits representing the status of 16 events starting with the specified event number. Each bit corresponds to the status of one event. If the bit is 1, the event is enabled; if the bit is 0, the event is disabled.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 702  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Status of 16 events.  
Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

---

**READ ALL EVENT ENTRIES ENABLE/DISABLE STATUS (v)**

---

**703****DESCRIPTION:**

This command returns 255 status bits representing the status of all events in the Event/Reaction Table. Each bit corresponds to the status of one event. If the bit is 1, the event is enabled; if the bit is 0, the event is disabled.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 703

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:*

Status of 16 events.

Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

Data[0] = Events 0-15, and

Data[15] = Events 240-255

---

**ENABLE EVENT TABLE ENTRY (N)**

---

**704****DESCRIPTION:**

This command is used to enable an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 704

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**DISABLE EVENT TABLE ENTRY (N)**

---

**705****DESCRIPTION:**

This command is used to disable an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 705

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**ENABLE/DISABLE EVENT TABLE GROUP ( { } )**

---

**706****DESCRIPTION:**

This command is used to set the enable/disable status of an entire event table group of 16 entries.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	706
<i>POSITION[0]:</i>	Event Table Group Number (00-FF-Hex).
<i>DATA[0]:</i>	16-bit Mask of events within group to enable. If bit is 1, event is enabled.
<i>DATA[1]:</i>	16-bit Mask of events within group to disable. If bit is 1, event is disabled.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

**READ EVENT TABLE ENTRY (O)****708****DESCRIPTION:**

This command is used to read the contents of an event table entry.  
The Reaction Command can have the following value:

NULL REACTION (DO NOTHING)	00
SET DAC MODULE MAGNITUDE, COUNTS	01
SET DAC MODULE MAGNITUDE, ENG. UNITS	02
RAMP DAC OUTPUT TO ENDPOINT	03
ENABLE/DISABLE PID LOOP	04
SET PID LOOP SETPOINT	05
ENABLE/DISABLE EVENT TABLE ENTRY	06
ENABLE/DISABLE EVENT ENTRY GROUP	07
READ AND HOLD I/O DATA	08
SET PID LOOP MIN-MAX OUTPUT LIMITS	09

The control byte contains the following information:

## Control Byte

bit 0 :	0	=	Event Latch - No Match
	1	=	Event Latch - Match
bit 1 :	0	=	Match Latch - No Match
	1	=	Match Latch - Match
bit 2 :	0	=	Null Entry - Not Scanned
	1	=	Valid Entry - Scan Active
bit 3 :	0	=	Watchdog Monitoring Disabled
	1	=	Watchdog Monitoring Enabled
bit 4 :	0	=	Compare <=
	1	=	Compare >=
bit 5 :	0	=	Not The Last Entry
	1	=	Last Entry
bit 6 :	0	=	Interrupt Disabled
	1	=	Interrupt Enabled
bit 7 :	0	=	Event Scanning Disabled
	1	=	Event Scanning Enabled

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	708
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).



**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
<i>DATA[0]:</i>	Low Word Reaction Ramp Slope
<i>DATA[1]:</i>	High Word Reaction Ramp Slope
<i>DATA[2]:</i>	Low Word Compare Value
<i>DATA[3]:</i>	High Word Compare Value
<i>DATA[4]:</i>	Low Word Reaction DAC Output Or Ramp Endpoint In Counts
<i>DATA[5]:</i>	High Byte = Reaction Command Low Byte = Reaction Channel
<i>DATA[6]:</i>	High Byte = Control Byte Low Byte = Compare Channel

---

**READ EVENT LATCHES (P)**

---

**709****DESCRIPTION:**

This command returns 16 status bits representing the status of 16 event latches starting with the specified event number. Each bit corresponds to the status of one event latch. If the bit is 1, the event latch is set; if the bit is 0, the event latch is cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 709  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Status of 16 event latches.  
Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

---

**READ ALL EVENT LATCHES (P)**

---

**710****DESCRIPTION:**

This command returns 255 status bits representing the status of all event latches in the Event/Reaction Table. Each bit corresponds to the status of one event latch. If the bit is 1, the latch is set; if the bit is 0, the latch is cleared.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 710

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:* Status of 16 latches.

Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

Data[0] = Event Latches 0-15, and

Data[15] = Event Latches 240-255.

---

**READ AND CLEAR EVENT LATCHES (Q)**

---

**711****DESCRIPTION:**

This command returns 16 status bits representing the status of 16 event latches starting with the specified event number. Each bit corresponds to the status of one event latch. If the bit is 1, the event latch is set; if the bit is 0, the latch is cleared. The latch is cleared after it is read.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 711  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Status of 16 event latches.  
Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

---

**READ AND CLEAR ALL EVENT LATCHES (Q)**

---

**712****DESCRIPTION:**

This command returns 255 status bits representing the status of all event latches in the Event/Reaction Table. Each bit corresponds to the status of one event latch. If the bit is 1, the latch is set; if the bit is 0, the latch is cleared. The latches are all cleared after they are read.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 712

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

*DATA[0]..*

*DATA[15]:*

Status of 16 latches.

Range: 16-bit (0-65,535 or 0000-FFFF-Hex).

Data[0]= Event Latches 0-15, and

Data[15]= Event Latches 240-255.

---

**ENABLE EVENT INTERRUPT (I)**

---

**713****DESCRIPTION:**

This command is used to enable the interrupt output function of an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 713

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**DISABLE EVENT INTERRUPT (I)**

---

**714****DESCRIPTION:**

This command is used to disable the interrupt output function of an event table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 714  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET EVENT ON COMM LINK WATCHDOG TIMEOUT (y)**

---

**715****DESCRIPTION:**

This command is used to add an event entry to the table that monitors a watchdog timeout condition.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 715  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error



**SET EVENT ON INPUT/OUTPUT > = SETPOINT (K)****716-725****DESCRIPTION:**

This command is used to add an event entry to the table that monitors an input or an output channel, and compares to a specified value for a greater-than or equal to condition.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 716 = Raw Counts  
 717 = Average Counts  
 718 = Peak Counts  
 719 = Low Counts  
 720 = Totalized Counts  
 721 = Scaled Value (EUI)  
 722 = Average Value (EUI)  
 723 = Peak Value (EUI)  
 724 = Low Value (EUI)  
 725 = Totalized Value (EUI)

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

*POSITION[1]:* I/O Channel Number 0-15 (00-0F-Hex).

*DATA[0]:* Compare Value.

Range:

For commands 716-720, Data[0] is 16-bit (-32768 to 32767).

For commands 721-725, Data[0] is 32-bit (-2,147,483,648 to 2,147,483,647).

32-bit values are in increments of 1/65,536 of the engineering units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

**SET EVENT ON INPUT/OUTPUT <= SETPOINT (L)****726-735****DESCRIPTION:**

This command is used to add an event entry to the table that monitors an input or an output channel and compares to a specified value for a less-than or equal to condition.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	726 = Raw Counts 727 = Average Counts 728 = Peak Counts 729 = Low Counts 730 = Totalized Counts 731 = Scaled Value (EUI) 732 = Average Value (EUI) 733 = Peak Value (EUI) 734 = Low Value (EUI) 735 = Totalized Value (EUI)
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>POSITION[1]:</i>	I/O Channel 0-15 (00-0F-Hex).
<i>DATA[0]:</i>	Compare Value. Range: For commands 716-720, Data[0] is 16-bit (-32768 to 32767). For commands 721-725, Data[0] is 32-bit (-2,147,483,648 to 2,147,483,647). 32-bit values are in increments of 1/65,536 of the engineering units.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**CLEAR REACTION (M)**

---

**736****DESCRIPTION:**

This command is used to clear an existing reaction from an event/reaction table entry.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 736  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET OUTPUT VALUE (COUNTS) REACTION (M)**

---

**737****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which sets an output to a specified count value when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 737  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* I/O Channel Number 0-15 (00-0F-Hex).  
*DATA[0]:* Channel Value.  
Range: 0 to 4095.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET OUTPUT VALUE (ENGINEERING UNITS) REACTION (M)**

---

**738****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which sets an output to a specified value when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit

*COMMAND:* 738

*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

*POSITION[1]:* I/O Channel Number 0-15 (00-0F-Hex).

*DATA[0]:* Channel Value.  
Range: 32-bit (-2,147,483,648 to 2,147,483,647).  
32-bit values are in increments of 1/65,536 of the engineering units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET OUTPUT RAMP TO SETPOINT REACTION (M)**

---

**739****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which causes an output to ramp to a specified setpoint value when the event occurs.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	739
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>POSITION[1]:</i>	I/O Channel Number 0-15 (00-0F-Hex).
<i>DATA[0]:</i>	Ramp Endpoint. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.
<i>DATA[1]:</i>	Ramp Slope (Engineering Units per Sec). Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit. Slope of 0 is not allowed.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET ENABLE/DISABLE EVENT ENTRY REACTION (M)**

---

**740****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will enable or disable an event entry when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 740  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Event Entry Number 0-254 (00-FE-Hex).  
*DATA[0]:* 0 to disable the event entry, 1 to enable the event entry.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET ENABLE/DISABLE EVENT GROUP REACTION (M)**

---

**741****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will enable or disable a group or all event entries when the event occurs.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	741
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>POSITION[1]:</i>	Event Entry Number 0-255 (00-FF-Hex). An entry of 255 will enable/disable an entire group.
<i>DATA[0]:</i>	16-bit Mask of events within group to enable. If bit is 1, event is enabled. Bitmask range is 0000-FFFF-Hex.
<i>DATA[1]:</i>	16-bit Mask of events within group to disable. If bit is 1, event is disabled. Bitmask range is 0000-FFFF-Hex.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------



---

**SET PID SETPOINT VALUE REACTION (M)**

---

**742****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which sets a PID's setpoint to a specified value when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 742  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Loop Number 0-7.  
*DATA[0]:* Setpoint Value.  
Range:  
32-bit (-2,147,483,648 to 2,147,483,647).  
32-bit values are in increments of 1/65,536 of the engineering units.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**SET PID MIN/MAX OUTPUT LIMITS REACTION (M)**

---

**743****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which sets the min/max limits of a PID's output to specified values when the event occurs.

**SEND PARAMETERS:**

<i>ADDRESS:</i>	Address of I/O Unit
<i>COMMAND:</i>	743
<i>POSITION[0]:</i>	Event Table Entry Number (00-FF-Hex).
<i>POSITION[1]:</i>	Loop Number 0-7.
<i>DATA[0]:</i>	Maximum Output. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.
<i>DATA[1]:</i>	Minimum Output. Range: 32-bit value (-2,147,483,648 to +2,147,483,647) in increments of 1/65,536 of an engineering unit.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver or I/O Error
---------------	---------------------

---

**SET PID ENABLE/DISABLE REACTION (M)**

---

**744****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will enable or disable a PID loop when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 744  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* Loop Number 0-7.  
*DATA[0]:* Enable/Disable Value.  
Range: 8-bit  
0= PID Loop Disabled,  
1 = PID Loop Enabled.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ AND HOLD I/O VALUE REACTION (M)**

---

**745****DESCRIPTION:**

This command is used to add a reaction entry to the event/reaction table which will read and store an I/O value when the event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 745  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).  
*POSITION[1]:* I/O Channel Number 0-15 (00-0F-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error

---

**READ EVENT HOLD BUFFER (I)**

---

**746****DESCRIPTION:**

This command is used to read the event hold buffer. It is used in conjunction with Command 745 which sets up a reaction that will place an I/O value in an event's hold buffer when an event occurs.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 746  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex).

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* Hold Buffer Value.  
Range is 32-bit (-2,147,483,648 to 2,147,483,647).  
32-bit values are in increments of 1/65,536 of the engineering units.

---

**READ AND CLEAR EVENT LATCH - SINGLE CHANNEL (zA)**

---

**747****DESCRIPTION:**

This command returns a control byte which contains the state of the event latch and then optionally clears the latch.

**SEND PARAMETERS:**

*ADDRESS:* Address of I/O Unit  
*COMMAND:* 747  
*POSITION[0]:* Event Table Entry Number (00-FF-Hex)  
*DATA[0]:* Any 8-bit value (1-255) other than 0, clears the latch.  
A value of 0 leaves the latch in its current state.

**RECEIVE PARAMETERS:**

*ERROR:* Driver or I/O Error  
*DATA[0]:* 8-bit control byte. If bit 0 is set, the event occurred.

# Driver Commands

---

**SET TURNAROUND DELAY TIME**

---

**901****DESCRIPTION:**

This command sets the delay time the driver will wait before retrying or reporting a timeout error during communications.

**SEND PARAMETERS:**

*COMMAND:* 901  
*DATA[0]:* Delay Time in 10 mSec Units.  
Range: 16-bit, 1 - 65,535 (10 mSec - 655.35 Sec.)  
Default is 300 (3 Sec.).

**RECEIVE PARAMETERS:**

*ERROR:* Driver Error

**DESCRIPTION:**

This command sets the port and baud rate the driver will use for communications.

**SEND PARAMETERS:**

*COMMAND:* 902

*DATA[0]:* Port Number. Range: 1-4

- 1 = COM1 @ 3F8 Hex, IRQ 4
- 2 = COM2 @ 2F8 Hex, IRQ 3
- 3 = COM3 @ 348 Hex, IRQ 2
- 4 = COM4 @ 340 Hex, IRQ 5

*DATA[1]:* Baud Rate. Range: 1-14

- 1 = 300 Baud
- 2 = 600 Baud
- 3 = 1,200 Baud
- 4 = 2,400 Baud
- 5 = 4,800 Baud
- 6 = 9,600 Baud
- 7 = 19,200 Baud
- 8 = 38,400 Baud
- 9 = 57,600 Baud
- 10 = 76,800 Baud
- 11 = 115,200 Baud
- 12 = 138,240 Baud
- 13 = 172,800 Baud
- 14 = 230,400 Baud

**RECEIVE PARAMETERS:**

*ERROR:* Driver Error



---

**SET NUMBER OF RETRIES**

---

**903****DESCRIPTION:**

This command sets the number of retries that the driver will use before reporting an error during communications.

**SEND PARAMETERS:**

*COMMAND:* 903

*DATA[0]:* Number Of Retries.  
Range: 16-bit, 0 - 32,767.  
If entered value is out of range, a value of 0 will be used.

**RECEIVE PARAMETERS:**

*ERROR:* Driver Error

**SET COMMUNICATIONS MODE****904****DESCRIPTION:**

This command sets the mode the driver will use for communications. Three modes are supported; Binary, ASCII, and PASS-THRU. The PASS-THRU mode sets up the driver to work in a pass-thru mode with a Mystic Controller between the host computer and the Mystic I/O Units.

Any command sent after setting mode 2 will contain a preamble which causes the Mystic Controller to pass the command to a multifunction I/O unit, receive the response and pass it back to the host. Mode 3 is used when using Local Simple I/O units connected to the Mystic Controller .

**SEND PARAMETERS:**

<i>COMMAND:</i>	904
<i>DATA[0]:</i>	Mode Value. Range: 0 - 3. 0 = BINARY 1 = ASCII 2 = PASS-THRU (16-bit CRC) Multifunction I/O Units 3 = PASS-THRU (8-bit Checksum) Local, Simple I/O Units. The following entries apply only when Data[0] = 2 or 3.
<i>DATA[1]:</i>	Port on the Mystic Controller which is connected to the Mystic I/O units. Range: 0 - 3 (remotes), 6 (local).
<i>DATA[2]:</i>	Address of Mystic Controller. Range: 1-255.

**RECEIVE PARAMETERS:**

<i>ERROR:</i>	Driver Error
---------------	--------------

---

**SET USER DEFINED PORT PARAMETERS**

---

**905****DESCRIPTION:**

This command sets the port, interrupt level, and baud rate the driver will use for communications. The port address and interrupt level can be specified.

**SEND PARAMETERS:**

*COMMAND:* 905

*DATA[0]:* Port Address. Range: 16-bit (0000 - FFFF Hex).

*Warning:* *Be very careful when specifying this address because the driver will not verify this value. A wrong value may cause the PC to crash or perform erratically.*

*DATA[1]:* Interrupt Line.  
Range: 1-15 Make sure that your communications card uses an interrupt line that is not used by another adapter in the system.

*DATA[2]:* Baud Rate.  
Range: 1-14

- 1 = 300 Baud
- 2 = 600 Baud
- 3 = 1,200 Baud
- 4 = 2,400 Baud
- 5 = 4,800 Baud
- 6 = 9,600 Baud
- 7 = 19,200 Baud
- 8 = 38,400 Baud
- 9 = 57,600 Baud
- 10 = 76,800 Baud
- 11 = 115,200 Baud
- 12 = 138,240 Baud
- 13 = 172,800 Baud
- 14 = 230,400 Baud

**RECEIVE PARAMETERS:**

*ERROR:* Driver Error

---

**READ DRIVER VERSION**

---

**906****DESCRIPTION:**

This command returns the driver version and release date.

**SEND PARAMETERS:**

*COMMAND:* 906

**RECEIVE PARAMETERS:**

*ERROR:* Driver Error  
*DATA[0]:* Revision Level  
*DATA[1]:* Revision Level Fraction 10ths  
*DATA[2]:* Revision Level Fraction 100ths  
*DATA[3]:* Month  
*DATA[4]:* Day  
*DATA[5]:* Year

# Appendix A

## Channel Data Dump Structures

The Mystic I/O driver provides command 452 to do a raw channel dump of an analog input, output, or PID database stored in the I/O unit. Since this raw channel dump is a series of bytes that does not match the RESP\_OBJ structure for returning values to the calling program, an alternate method must be used. This method uses the receive buffer (rbuf[]) directly to transfer the bytes to the appropriate structure variables described below. Several more steps are required to swap the order of the bytes representing long (4-byte) numbers. Examples for transferring the bytes and swapping the orders are also described below.

Command 452 will do a raw channel dump on analog inputs and outputs if you specify channels 0 thru 15. Specifying channels 32 thru 39 will return PID loop data corresponding to loops 0 thru 7.

To access the receive buffer, you must have the following declaration in your program:

```
extern unsigned char rbuf[256];
```

Following are the structure definitions for analog inputs, outputs, and the PID structure:

```
typedef struct ain_data
{
    char          config;          /*MODULE TYPE */
    unsigned char flags;          /*FLAGS */
    int           ceuv;            /*COUNTS TO ENG. UNITS VECTOR */
    int           ceuv2;          /*VECTOR 2 */
    int           cir;            /*CURRENT INPUT READING */
    int           cia;            /*CURRENT INPUT AVERAGE */
    long         cir_eu;          /*CURRENT INPUT READING, ENG. UNITS
*/
    int           caf;            /*CURRENT AVERAGE FRACTION */
    int           asc;            /*AVERAGE SAMPLE COUNT */
    int           cacv;           /*CURRENT ASIC COUNTER VALUE */
    int           civr;           /*CURRENT INPUT RAW */

    READING (NO OFFS/GAIN) */
    int           offset;         /*OFFSET */
    int           gain;           /*GAIN COEFFICIENT */
    int           peak_hi;        /*PEAK COUNTS */
    int           peak_lo;        /*LOWEST COUNTS */
    int           reserved1;      /*RESERVED */
    long         scale_hi;        /*SCALING HI LIMIT */
};
```

## APPENDIX A: CHANNEL DATA DUMP STRUCTURES

```

        long         scale_offs;    /*SCALING OFFSETT */
        long         ceu_gain;      /*COUNTS TO ENG. UNITS GAIN */
        int          reserved2;    /*RESERVED */
        int          reserved3;    /*RESERVED */
        int          reserved4;    /*RESERVED */
        int          total_sr;     /*TOTALIZER SAMPLE RATE */
        int          total_dc;     /*TOTALIZER DOWN COUNTER */
        int          total_cms;    /*TOTALIZER COUNTS MS WORD */
        int          total_cls;    /*TOTALIZER COUNTS LS WORD */
        long         total_eui;    /*TOTALIZER ENG. UNITS */
        int          reserved5;    /*RESERVED */

}      AIN_OBJ,      *AIN_OBJ_PTR;

typedef struct aout_data
{
        char         config;       /*MODULE TYPE */
        unsigned char flags;       /*FLAGS */
        int          ceuv;         /*COUNTS TO ENG. UNITS VECTOR */
        int          ceuv2;       /*VECTOR 2 */
        int          cor;         /*CURRENT OUTPUT READING */
        int          por;         /*PENDING OUTPUT READING */
        long         cor_eu;      /*CURRENT OUTPUT READING ENG. UNITS
*/
        long         por_eu;     /*PENDING OUTPUT READING ENG. UNITS
*/
        int          rampf;       /*RAMPING OR PID OUT FRACTIONAL
REMAINDER */
        int          ramp_end;    /*RAMP ENDPOINT COUNTS */
        long         ramp_eu;     /*RAMP ENG. UNITS */
        int          peak_hi;     /*PEAK COUNTS */
        int          peak_lo;     /*LOWEST COUNTS */
        int          tpo_scale;   /*TPO PRESCALE FOR G4DA9 */
        long         scale_hi;    /*SCALING HI LIMIT */
        long         scale_offs; /*SCALING OFFSETT */
        long         ceu_gain;    /*COUNTS TO ENG. UNITS GAIN */
        long         euc_gain;    /*ENG. UNITS TO COUNTS GAIN */
        int          reserved2;   /*RESERVED */
        int          total_sr;    /*TOTALIZER SAMPLE RATE */
        int          total_dc;    /*TOTALIZER DOWN COUNTER */
        int          total_cms;   /*TOTALIZER COUNTS MS WORD */
        int          total_cls;   /*TOTALIZER COUNTS LS WORD */
        long         total_eui;   /*TOTALIZER ENG. UNITS */
        int          wdog;       /*WATCHDOG VALUE IN COUNTS */
}      AOUT_OBJ, *AOUT_OBJ_PTR;

typedef struct pid_data_raw
{
        unsigned char control;    /*PID CONTROL BYTE */
        unsigned char flags;     /*FLAGS */
        int          reserved1;   /*RESERVED */
        int          in_ptr;     /*INPUT CHANNEL POINTER */
        int          out_ptr;    /*OUTPUT CHANNEL POINTER */
        int          setp_ptr;   /*SETPOINT CHANNEL POINTER */
        long         gain;       /*GAIN COEFFICIENT */
        unsigned long deriv;     /*DERIVATIVE TIME */
        unsigned long integral; /*INTEGRAL - RATES/MIN. */
        long         setpoint;   /*SETPOINT */
        long         p_error;    /*PREVIOUS ERROR */
        long         p2_error;   /*2ND PREVIOUS ERROR */
        long         range_calc; /*256 / INPUT RANGE ENG. UNITS */
        long         setp_max;   /*MAX SETPOINT LIMIT */
}

```

```

        long          setp_min;      /*MIN SETPOINT LIMIT */
        unsigned long intg_scan;    /*INTEGRAL / SCAN */
        unsigned long derv_scan;    /*DERIVATIVE / SCAN */
        int           scan_time;    /*SCAN TIME IN .1 SEC UNITS */
        int           scan_dcnt;    /*SCAN DOWNCOUNTER */
        long          output;       /*OUTPUT COUNTS */
        int           output_hi;    /*OUTPUT COUNTS HIGH LIMIT */
        int           output_lo;    /*OUTPUT COUNTS LOW LIMIT */
        int           reserved2;    /*RESERVED */
        long          reserved3;    /*RESERVED */
        long          reserved4;    /*RESERVED */
        long          reserved5;    /*RESERVED */
    } PID_RAW_OBJ, *PID_RAW_OBJ_PTR;

```

The following are typical variable declarations:

```

AIN_OBJ      ain;
AOUT_OBJ     aout;
PID_OBJ      pid;
PID_RAW_OBJ  pid_raw;

```

The following are the routines to transfer data from the receive buffer to the structured variables:

```

/
*****
*      Function      void swap_long(unsigned long *value)
*      Description   swaps the byte order of a 4 byte long at the
*                   location
*                   pointed at by the variable value.
*****/
void swap_long(unsigned long *value)
{
    unsigned long hi_value;
    unsigned long lo_value;

    hi_value = (*value & 0xFFFF) << 16;
    lo_value = (*value >> 16);

    *value = hi_value | lo_value;
}

/
*****
*      Function      int read_ain_data(unsigned char address, char
*                   channel)
*      Description   reads the raw channel data for an input channel
*                   at the address specified and updates the ain
*                   structure variable.
*****/

*/ int read_ain_data(unsigned char address, char channel)
{

struct SEND_OBJ driver_go;
struct RESP_OBJ driver_arrive;
char *data_ptr;
unsigned char *rbuf_ptr;
int i;

    driver_arrive.error = 0;
    driver_go.command = 452;

```

```

    driver_go.address = address;
    driver_go.position[0] = channel;

    data_ptr = (char *)&ain;          /*point to data struc */

    if ((driver_err = g4driver(&driver_go,&driver_arrive)) == NULL)
    {
        /*get the ain stuff */

        rbuf_ptr = rbuf;              /*point to raw receive
buffer */
        if (msg.type == 0)             /*skip past the length and
error bytes */
            rbuf_ptr += 2;
        else
            rbuf_ptr++;

        /*convert byte for byte straight from receive buffer */

        for (i=0;i<64;i++,data_ptr++)
            rbuf_ptr = convert(rbuf_ptr,(unsigned char
*)data_ptr,0x10,1);

        /* fix all the longs by swapping low and high order
words
*/

        swap_long((unsigned long *)&ain.cir_eu);
        swap_long((unsigned long *)&ain.scale_hi);
        swap_long((unsigned long *)&ain.scale_offs);
        swap_long((unsigned long *)&ain.ceu_gain);
        swap_long((unsigned long *)&ain.total_eui);

    }
    return(driver_arrive.error);

}

/
*****
*      Function      int read_aout_data(unsigned char address,char
*                      channel)
*
*      Description   reads the raw channel data for an output channel
*                      at the address specified and updates the aout
*                      structure variable.
*****/
int read_aout_data(unsigned char address, char channel)
{

struct SEND_OBJ driver_go;
struct RESP_OBJ driver_arrive;
char *data_ptr;
unsigned char *rbuf_ptr;
int i;

```



```

driver_arrive.error = 0;
driver_go.command = 452;
driver_go.address = address;
driver_go.position[0] = channel;

data_ptr = (char *)&aout;          /*point to data struc */

if ((driver_err = g4driver(&driver_go,&driver_arrive)) == NULL)
{
    /*get the aout stuff */
    rbuf_ptr = rbuf;                /*point to raw receive
buffer */
    if (msg.type == 0)                /*skip past the length and
error bytes */
        rbuf_ptr += 2;
    else
        rbuf_ptr++;

    /*convert byte for byte straight from receive buffer */
    for (i=0;i<64;i++,data_ptr++)
        rbuf_ptr = convert(rbuf_ptr,(unsigned char
*)data_ptr,0x10,1);

    /*fix all the longs by swapping low and high order words
*/

    swap_long((unsigned long *)&aout.cor_eu);
    swap_long((unsigned long *)&aout.por_eu);
    swap_long((unsigned long *)&aout.ramp_eu);
    swap_long((unsigned long *)&aout.scale_hi);
    swap_long((unsigned long *)&aout.scale_offs);
    swap_long((unsigned long *)&aout.ceu_gain);
    swap_long((unsigned long *)&aout.euc_gain);
    swap_long((unsigned long *)&aout.total_eui);

}
return(driver_arrive.error);
}

/
*****
*      Function      int read_pid_raw_data(unsigned char
*                  address,char loop)
*
*      Description  reads the raw pid data for a loop at the address
*                  specified and updates the pid_raw structure
*                  variable.
*****/
int read_pid_raw_data(unsigned char address, char loop)
{

struct SEND_OBJ driver_go;
struct RESP_OBJ driver_arrive;
char *data_ptr;
unsigned char *rbuf_ptr;
int i;

```

```

driver_arrive.error = 0;
driver_go.command = 452;
driver_go.address = address;
driver_go.position[0] = 0x20 | loop;

data_ptr = (char *)&pid_raw;          /*point to data struc */

if ((driver_err = g4driver(&driver_go,&driver_arrive)) == NULL)
{
    /*get the ain stuff */

    rbuf_ptr = rbuf;                  /*point to raw receive
buffer */
    if (msg.type == 0)                /*skip past the length and
error bytes */
        rbuf_ptr += 2;
    else
        rbuf_ptr++;

    /*convert byte for byte straight from receive buffer */

    for (i=0;i<80;i++,data_ptr++)
        rbuf_ptr = convert(rbuf_ptr,(unsigned char
*)data_ptr,0x10,1);

    /*fix all the longs by swapping low and high order words
*/

    swap_long((unsigned long *)&pid_raw.gain);
    swap_long((unsigned long *)&pid_raw.deriv);
    swap_long((unsigned long *)&pid_raw.integral);
    swap_long((unsigned long *)&pid_raw.setpoint);
    swap_long((unsigned long *)&pid_raw.p_error);
    swap_long((unsigned long *)&pid_raw.p2_error);
    swap_long((unsigned long *)&pid_raw.range_calc);
    swap_long((unsigned long *)&pid_raw.setp_max);
    swap_long((unsigned long *)&pid_raw.setp_min);
    swap_long((unsigned long *)&pid_raw.intg_scan);
    swap_long((unsigned long *)&pid_raw.derv_scan);
    swap_long((unsigned long *)&pid_raw.output);

}
return(driver_arrive.error);
}

```

The following is an example function for using the data in the PID structure variable as declared earlier:

```

/
*****
*
* Function          void display_pid_raw(void)
*
* Description       displays the pid values using the raw structure
*
*****/
void display_pid_raw(void)
{
    printf (" ----- LOOP %1d EXTENDED PARAMETERS ----- \n",LOOP);
    printf(" CONTROL BYTE (HEX): %-02X \n",pid_raw.control);
}

```

```
printf(" FLAGS BYTE (HEX): %-02X \n",pid_raw.flags);
printf(" SCAN RATE (SEC.) : %-6d \n",pid_raw.scan_time/10);
printf(" SCAN DOWNCOUNTER : %-6d \n",pid_raw.scan_dcnt);
printf(" INPUT CH. PTR : %-4.4X \n",pid_raw.in_ptr);
printf(" SETPOINT CH. PTR : %-4.4X \n",pid_raw.setp_ptr);
printf(" OUTPUT CH. PTR : %-4.4X \n",pid_raw.out_ptr);
printf(" SETPOINT : %-8.4f \n", (float)pid_raw.setpoint/65536.0);
printf(" OUTPUT : %-8.4f \n", (float)pid_raw.output/65536.0);
printf(" OUTPUT HI COUNTS : %-6d \n",pid_raw.output_hi);
printf(" OUTPUT LO COUNTS : %-6d \n",pid_raw.output_lo);
printf(" GAIN : %-8.4f \n", (float)pid_raw.gain/65536.0);
printf(" INTEGRAL : %-8.4f \n", (float)pid_raw.integral/65536.0);
printf(" DERIVATIVE : %-8.4f \n", (float)pid_raw.deriv/65536.0);
printf(" 1ST ERROR TERM : %-8.4f \n", (float)pid_raw.p_error/
65536.0);
printf(" 2ND ERROR TERM: %-8.4f \n", (float)pid_raw.p2_error/
65536.0);
printf(" INTEGRAL/SCAN: %-8.4f \n", (float)pid_raw.intg_scan/
65536.0);
printf(" DERIVATIVE/SCAN: %-8.4f \n", (float)pid_raw.derv_scan/
65536.0);
printf(" RANGE CALC : %-8.4f \n", (float)pid_raw.range_calc/65536.0);
printf(" SETPOINT MAX : %-8.4f \n", (float)pid_raw.setp_max/65536.0);
printf(" SETPOINT MIN : %-8.4f \n", (float)pid_raw.setp_min/65536.0);
printf("\n");
}
```



# Appendix B

## MisticWare Driver for Windows

The MwDriver.DLL allows a Windows application to communicate with:

- Mistic controller
- Mistic I/O or SNAP I/O™ using the SendMIO API.

The driver is implemented as a Windows DLL providing a set of “C” APIs and may be used with any Windows language that supports DLLs such as Visual Basic or C/ C++ compilers.

### Port Locking and Multiple Applications

Port locking is implemented so that multiple applications can share the same port. If an application needs exclusive access to a port to perform multiple commands without interruption, an API is provided to lock and unlock a port.

### Port Types Supported

This driver supports the following Opto 22 adapter cards:

- **AC37** RS-485 buffered coprocessor card capable of either 2-wire or 4-wire RS-485 at up to 115.2 kbaud.
- **AC39** Local bus buffered coprocessor card.
- **AC42** Fiber optic RS-485 buffered coprocessor card.

This driver also supports the use of Standard Windows COM ports (via the Windows API's). This includes the use of the following Opto 22 adapter cards:

- **AC7A** external RS-232 to RS-485 converter (capable of either 2-wire or 4-wire RS-485).
- **AC24AT or AC422AT** RS-485 cards capable of 4-wire RS-485 at up to 38.4 kbaud.

### Handles

MwDriver uses handles to access ports. A handle is provided when a port is opened and thereafter the handle is used to access a port.

# Installation

The file MwDriver.Dll should be copied to either the application directory or the Windows System directory. Windows searches for a DLL in the following sequence: [1] in memory, [2] the current working directory, and [3] Windows System directory.

Header files (MwDriver.H for C and MwDriver.Bas for Basic) should be copied to the directory where the application source code is located.

The file MwDriver.Lib is provided as an import library. This tells the linker that the MwDriver APIs are part of a DLL. If this LIB file is used, the MwDriver APIs do not need to be included in the "imports" section of the application's DEF file. The LIB file is not required for Visual Basic.

# API List

For most applications, only 3 APIs in the library are required as follows:

- Open a port and get a port handle
- Read or write data
- Close the port and release the port handle
- See the code fragment below shows a simple example without error handling.

## Simple Code Fragment Using These APIs

```
// Step [1] - Open a port and get a port handle.
// There's a separate 'open' API for ARCNET, AC37 and a COM port.
iErrorCode = opto22MwdPortOpenXXX( &MwdHandle, ...);

// Step [2a] - For Mystic/SNAP, call SendMIO to interact with I/O.
iErrorCode = SendMIO( MwdHandle, ...);

// Step [2b] - For Mystic controllers, send Commands and get
responses.
iErrorCode = opto22MwdSendReceNoId( MwdHandle, ...);
printf( "\\%s\\", %d chars, Error:%d\\n", ReceStr,iActualLen,iErrorCode
);

// Step [3] Close the port when the application ends.
opto22MwdPortClose( MwdHandle );
```

Notes about APIs:

- The APIs are listed below with the function prototypes and a description.
- Refer to MwDriver.H for actual function prototypes or MwDriver.BAS for function declarations.

- In general, an API that returns an “int” returns an error number where 0 indicates “no error”.

**Each API name starts with “opto22Mwd” except for SendMIO.**

### **opto22MwdGetVersion, opto22MwdGetVersion2**

```
char* FAR PASCAL opto22MwdGetVersion( void );

int opto22MwdGetVersion2(
    char* versionArg,
    UINT  maxLenArg );
```

The “get version” APIs get a version string of the form “1.2.3”. The version string is also in the MwDriver.H file (or MwDriver.BAS for Basic). The purpose of these functions is to allow an application to check the version of the DLL file. **opto22MwdGetVersion** returns a pointer to a string and **opto22MwdGetVersion2** copies the version string to a buffer provided by the caller.

### **opto22MwdSendRece, opto22MwdSendReceNold**

```
int opto22MwdSendRece(
    int    HandleArg,
    UINT   addressArg,
    BYTE*  sendStringArg,
    UINT   sendLength,
    BYTE*  receStringArg,
    UINT   receStringLenMaxArg,
    UINT*  receStringLenActualArg );

int opto22MwdSendReceNoId(
    int    HandleArg,
    UINT   addressArg,
    BYTE*  sendStringArg,
    UINT   sendLength,
    BYTE*  receStringArg,
    UINT   receStringLenMaxArg,
    UINT*  receStringLenActualArg );
```

Does both a send and a receive. The “Nold” does not do sequence ID checking which is faster. Usually, sequence ID checking is required on noisy ARCNET installations. Sequence ID checking cannot be used with mystic commands that have an imbedded “\r” (carriage return). Typically, the “Nold” API is sufficient.

### **SendMIO**

```
int SendMIO(
    int          iHandle,           // Handle provided by 'port open'
    int          iAddress,         // Address of brick
    unsigned int iCommand,        // Command number i.e. 202=set
    output
    unsigned int far* PositionArray, // Position array - 2 elements
    long far*      SendDataArray,   // Send data array - 16 elements
    long far*      ReceDataArray); // Received data array - 16
elements
```

This API is used to access Mystic/SNAP I/O. The command numbers are documented in the *MisticWare User's Guide*.

### opto22MwdPortLock

```
int opto22MwdPortLock(
    int    handle,
    BOOL   bLockState );
```

This API locks and unlocks a port for exclusive access by the specified handle. This is required when multiple commands need to be executed by one application before allowing another application to execute a command. Under normal conditions, this API is not required.

### opto22MwdPortOpen for ARCNET, AC37 and WinApi

```
int opto22MwdPortOpenARCNET(
    int*   handle,
    UINT   ioPort,
    DWORD  memAddr,
    float  timeOut,
    UINT   retry );
```

```
int opto22MwdPortOpenAC37(
    int*   handle,
    UINT   ioPort, // I/O address such as 3F8 (IRQ not required)
    DWORD  Baud,   // Baud rate such as 115200
    float  timeOut,
    UINT   retry,
    int    protocolType,
    int    dataCheckType );
```

```
int opto22MwdPortOpenWinApi(
    int*   handle,
    UINT   comPort, // COM port number. 1 for COM1.
    DWORD  Baud,   // Baud rate up to 38400
    float  timeOut,
    UINT   retry,
    int    protocolType, // Protocol type: ASCII or Binary
    int    dataCheckType ); // Data check type (should be CRC)
```

The "PortOpen" APIs open a port and assign a handle number to be used by the application to access the port.

Parameters common to all "PortOpen" APIs:

**timeOut** is the amount of time to wait, in seconds, for a response. A typical number to use for ARCNET or high speed serial is 0.75 seconds. Larger values are needed for lower baud rates or if several applications are accessing the same port.

**retry** is the quantity of times the driver will retry a command if an error occurs. The driver always tries once but the number of retries depends on this value. A typical number is 1.

**protocolType** should be either **ProtocolTypeBinary** or **ProtocolTypeAscii** which are defined in MwDriver.H. Windows 3.1 on an RS232 port will not support Binary mode. Typically,



Binary is better because twice as many characters need to be sent for ASCII. ASCII may be required if communicating via modem.

**dataCheckType** should be **DataCheckTypeCrc16** which is defined in MwdDriver.H.

### **opto22MwdPortClose**

```
void FAR PASCAL opto22MwdPortClose( int HandleArg );
```

This API closes a port and releases the handle. If this API is not called by an application before exiting, the port handle will not be released until the DLL is released from memory. Visual Basic should call this API when the main form unloads.

### **opto22MwdPortRetrySet , opto22MwdPortDelaySet**

```
int opto22MwdPortRetrySet (
    int HandleArg,
    UINT retryArg );

float FAR PASCAL opto22MwdPortDelaySet (
    int HandleArg,
    float DelayArg );
```

These two APIs set modify the retry and delay parameters that are set in the "PortOpen" APIs. The return value can be used by the application to restore the setting to its previous value. These APIs are normally not required except for Opto22 utilities.

## **Visual Basic Functions**

### **StringAsLong, StringAsFloat**

```
void FAR PASCAL StringAsLong( long* numArg, char* StringArg );
void FAR PASCAL StringAsFloat( float* numArg, char* Stringarg );
```

These two APIs are used by Visual Basic to extract Longs or Floats from a response string that contains binary data. A response from mistic can be ASCII (such as "1.234E12") or binary (which would appear as 4 bytes of garbage characters) depending upon the command. HostWords allows ASCII or Binary mode to be selected. "C" doesn't need these two functions because C can use type casts to convert the data.

## Status or Error Codes

The status codes or error codes returned by the driver will be zero if there are no errors. Error codes are listed in the file Errors.H. Some of the more common errors are listed in the table below.

# Additional Error Codes

## **-100 Invalid Port Error**

This error occurs when a handle number for a port is specified and that port has not been assigned a driver or adapter type.

## **-102 Initialize Error**

This error occurs if the proper AC37 or AC39 adapter could not be found at the location specified in the ConfigureAC37 or ConfigureAC39 functions.

## **-104 Port Lock Error**

This error occurs when a call to the SendMIO() function is made while another command is being processed. Windows allows multiple applications to call the same DLL function. Since the DLL only has one set of global data he must protect himself by using a lock mechanism to ensure that commands get processed one application at a time. If you encounter this error, you might consider having all scanning controlled by one application, and all other applications communicate to the scanner.

## **-105 Driver Configuration Error**

This error occurs when the SendMIO() is called prior to configuring a port with the AssignPortDriver() and Configure functions.



# Appendix C

## Using The Driver with Microsoft Basic/Quick Basic

The MysticWare driver can be called from applications written using Microsoft's Basic Compiler 7.0/7.1 and Microsoft Quick Basic 4.0/4.5.

To call the driver from Basic, the driver **MUST** first be loaded into memory using the program LOADMD.EXE provided on the MysticWare disks. To load the driver, run the program by typing LOADMD followed by the Enter key at the DOS prompt.

Example (assumes LOADMD.EXE is in the current directory):

```
C>LOADMD
```

To unload or remove the driver from memory, type LOADMD quit followed by the Enter key at the DOS prompt.

Example (assumes LOADMD.EXE is in the current directory):

```
C>LOADMD quit
```

The LOADMD program loads the driver into memory where it becomes accessible using software interrupt 61 hex. Prior to the Basic program issuing the interrupt, the CPU AX, BX, CX, and DX registers are set up with the addresses to the send and receive structures used by the application.

Since the MysticWare driver uses a send and a receive structure to pass parameters, these structures must first be declared and initialized prior to any driver call. The Microsoft Basic compilers allow definition of structures using the keyword TYPE. However, a minor difference exists between the Quick Basic 4.0/4.5 compilers and the Basic compiler 7.0/7.1. Quick Basic does not allow declarations of arrays inside of user-defined types, therefore each array element required by the driver must be a standalone variable (integer for POSITIONS and long for INFO). A special function (CALL INTERRUPT) for issuing a software interrupt is also used. This function resides in the external library QB.LIB (QB.QLB) provided with Quick Basic 4.0/4.5 and QBX.LIB (QBX.QLB) provided with the Basic Compiler 7.0/7.1. Standard Basic functions VARPTR and VARSEG are used to setup the CPU registers before the interrupt call.

*NOTE:* The version of Basic called QBasic (which is included with MS-DOS 5.0) cannot be used to call the driver because it does not support the INTERRUPT function and type definitions needed to call the driver.

## Basic Compiler 7.0/7.1

The following are the necessary declarations and functions needed for calling the driver using the Microsoft Basic Compiler Versions 7.0 and 7.1. The advantage of using this compiler over Quick Basic 4.0/4.5 is that the newer version of the Basic Compiler allows arrays to be defined inside of structure definitions, reducing the amount of code necessary. The following lines must be placed at the beginning of your application source code:

```

\
/*****
/
/
/          DECLARE VARIABLES & SUBROUTINES
/
\*****
\
REM $STATIC

TYPE SendRec
    Address AS INTEGER
    Command AS INTEGER
    Position(0 TO 1) AS INTEGER
    Info(0 TO 15) AS LONG
END TYPE

TYPE ReceiveRec
    Error AS INTEGER
    Info(0 TO 15) AS LONG
END TYPE

TYPE RegType
    AX AS INTEGER
    BX AS INTEGER
    CX AS INTEGER
    DX AS INTEGER
    BP AS INTEGER
    SI AS INTEGER
    DI AS INTEGER
    FLAGS AS INTEGER
END TYPE

DIM POSITIONS%(1)           \ DIMENSION TO 2 ELEMENTS
DIM INFO&(15)               \ DIMENSION TO 16 ELEMENTS
DIM Send AS SendRec
DIM Rcv AS ReceiveRec
DIM Regs AS RegType

COMMON SHARED ERRORS%, ADDRESS%, COMMAND%, POSITIONS%(), INFO&()
\

```

```

'*****
' *
' *          CALL THE Mystic DRIVER TSR
' *
'*****
'
mdriver:

ERRORS% = 0

Send.Address      = ADDRESS%
Send.Command      = COMMAND%
Send.Position(0)  = POSITIONS%(0)
Send.Position(1)  = POSITIONS%(1)
FOR I% = 0 TO 15
    Send.Info(I%) = INFO&(I%)
    Rcv.Info(I%) = 0
NEXT

Regs.AX = VARPTR(Send)
Regs.BX = VARSEG(Send)
Regs.CX = VARSEG(Rcv)
Regs.DX = VARPTR(Rcv)

CALL Interrupt(&H61,Regs,Regs)

ERRORS% = Rcv.Error

FOR I% = 0 TO 15
    INFO&(I%) = Rcv.Info(I%)
NEXT

RETURN

```

Before calling the mdriver subroutine, the global parameters ADDRESS%, COMMAND%, POSITIONS%(), and INFO&() must be set with the appropriate values dependent on the command to be issued.

After compiling an application, it is important to link it using the QBX.LIB library that is included with the Basic Compiler. This library contains the code for Basic's INTERRUPT function. The following is an example for the command line used when linking:

```
LINK filename QBX.LIB;
```

where filename is the name of the application program.

Two sample programs are provided on the MysticWare diskettes to illustrate the calling process. They are named MDTSR.BAS and MDTSR1.BAS. The batch files DOTSR.BAT and DOTSR1.BAT are also provided. Those files contain the commands for compiling and linking the respective sample programs.

## Quick Basic 4.0/4.5

The method for calling the driver using Quick Basic 4.0/4.5 is the same as that shown previously for the Basic Compiler, with a minor difference. Quick Basic 4.0/4.5 does not allow arrays to be defined within a user-defined type structure, therefore, the array variables are replaced with individual elements of type INTEGER for Position and LONG for Info.

The following are the necessary declarations and functions needed for calling the driver using the Microsoft Quick Basic Compiler Versions 4.0/4.5:

```
' *****
'
'           DECLARE VARIABLES & SUBROUTINES
'
' *****
' $INCLUDE: 'QB.BI'

REM $STATIC

TYPE SendRec
    Address AS INTEGER
    Command AS INTEGER
    Position0 AS INTEGER
    Position1 AS INTEGER
    Info0 AS LONG
    Info1 AS LONG
    Info2 AS LONG
    Info3 AS LONG
    Info4 AS LONG
    Info5 AS LONG
    Info6 AS LONG
    Info7 AS LONG
    Info8 AS LONG
    Info9 AS LONG
    Info10 AS LONG
    Info11 AS LONG
    Info12 AS LONG
    Info13 AS LONG
    Info14 AS LONG
    Info15 AS LONG
END TYPE

TYPE ReceiveRec
    Errors AS INTEGER
    Info0 AS LONG
    Info1 AS LONG
    Info2 AS LONG
    Info3 AS LONG
    Info4 AS LONG
    Info5 AS LONG
    Info6 AS LONG
    Info7 AS LONG
    Info8 AS LONG

    Info9 AS LONG
```



```

        Info10 AS LONG
        Info11 AS LONG
        Info12 AS LONG
        Info13 AS LONG
        Info14 AS LONG
        Info15 AS LONG
END TYPE

DIM POSITIONS%(1)           \ DIMENSION TO 2 ELEMENTS
DIM INFO&(amp;15)           \ DIMENSION TO 16 ELEMENTS
DIM Send AS SendRec
DIM Rcv AS ReceiveRec
DIM Regs AS RegType

COMMON SHARED ERRORS%, ADDRESS%, COMMAND%, POSITIONS%(), INFO&()

\
/*****
/ *
/ *          CALL THE Mistic DRIVER
/ *
/*****
/

mdriver:

ERRORS% = 0

Send.Address   = ADDRESS%
Send.Command   = COMMAND%
Send.Position0 = POSITIONS%(0)
Send.Position1 = POSITIONS%(1)
Send.Info0     = INFO&(amp;0)
Send.Info1     = INFO&(amp;1)
Send.Info2     = INFO&(amp;2)
Send.Info3     = INFO&(amp;3)
Send.Info4     = INFO&(amp;4)
Send.Info5     = INFO&(amp;5)
Send.Info6     = INFO&(amp;6)
Send.Info7     = INFO&(amp;7)
Send.Info8     = INFO&(amp;8)
Send.Info9     = INFO&(amp;9)
Send.Info10    = INFO&(amp;10)
Send.Info11    = INFO&(amp;11)
Send.Info12    = INFO&(amp;12)
Send.Info13    = INFO&(amp;13)
Send.Info14    = INFO&(amp;14)
Send.Info15    = INFO&(amp;15)

Regs.ax  = VARPTR(Send)
Regs.bx  = VARSEG(Send)
Regs.cx  = VARSEG(Rcv)
Regs.dx  = VARPTR(Rcv)

CALL INTERRUPT(&H61, Regs, Regs)

```

```
ERRORS% = Rcv.Errors

INFO&(0)   = Rcv.Info0
INFO&(1)   = Rcv.Info1
INFO&(2)   = Rcv.Info2
INFO&(3)   = Rcv.Info3
INFO&(4)   = Rcv.Info4
INFO&(5)   = Rcv.Info5
INFO&(6)   = Rcv.Info6
INFO&(7)   = Rcv.Info7
INFO&(8)   = Rcv.Info8
INFO&(9)   = Rcv.Info9
INFO&(10)  = Rcv.Info10
INFO&(11)  = Rcv.Info11
INFO&(12)  = Rcv.Info12
INFO&(13)  = Rcv.Info13
INFO&(14)  = Rcv.Info14
INFO&(15)  = Rcv.Info15

RETURN
```

If compiling the application using the integrated Quick Basic environment, it is necessary to start Quick Basic with the /I command line switch. This switch causes the extended library QB.LIB (which contains the INTERRUPT function) to be loaded. The following is an example for the command line used:

```
QB /I
```

If the command line Basic compiler (versions prior to 7.0/7.1) included with Quick Basic 4.0/4.5 is used instead, then it is necessary to link the application using the QB.LIB library that is included with Quick Basic. The following is an example for the command line used when linking:

```
LINK filename QB.LIB; where filename is the name of the application program.
```

Two sample programs are provided on the MysticWARE diskettes to illustrate the calling process. They are named QBMDTSR.BAS and QBMDTSR1.BAS. The batch files DOQBTSR.BAT and DOQBTSR1.BAT are also provided. They contain the commands for compiling and linking the respective sample programs.

# Appendix D

## Using Opto 22 I/O in 32 Bit Windows

Both Optomux and Mystic I/O may be accessed in Win32 using OptoMwd.DLL. This DLL allows multiple applications to access I/O simultaneously. This DLL provides a set of "C" APIs and may be used with any 32 bit Windows language that supports DLLs such as Visual Basic or C/ C++ compilers.

### Port Locking and Multiple Applications

Port locking is implemented so that multiple applications can share the same port. If an application needs exclusive access to a port to perform multiple commands without interruption, an API is provided to lock and unlock a port.

### Port Types Supported

This driver supports the following Opto 22 adapter cards:

- **AC37** RS-485 buffered coprocessor card capable of either 2-wire or 4-wire RS-485 at up to 115.2 kbaud.
- **AC39** Local bus buffered coprocessor card.
- **AC42** Fiber optic RS-485 buffered coprocessor card.

This driver also supports the use of Standard Windows COM ports (via the Windows API's). This includes the use of the following Opto 22 adapter cards:

- **AC7A** external RS-232 to RS-485 converter (capable of either 2-wire or 4-wire RS-485).
- **AC24AT or AC422AT** RS-485 cards capable of 4-wire RS-485 at up to 38.4 kbaud.

### Handles

OptoMwd.DLL uses handles to access ports. A handle is provided when a port is opened and thereafter the handle is used to access a port.

## Installation

Run the OptoDriver Toolkit installation to install I/O drivers, examples and on-line documentation.

## Examples

Examples are provided in the OptoDriver Toolkit for several languages. These examples are installed when the OptoDriver Toolkit is installed.

## API List

For most applications, only 3 APIs in the library are required as follows:

- Open a port and get a port handle
- Read or write data
- Close the port and release the port handle

See the code fragment below shows a simple example without error handling.

### Simple Code Fragment Using These APIs

```
// Step [1] - Open a port and get a port handle.
// There's a separate 'open' API for Arcnet, AC37 and a COM port.
ErrorCode = opto22MwdPortOpenXXX( &MwdHandle, ...);

// Step [2a] - For Mystic/Snap, call SendMIO to interact with I/O.
ErrorCode = SendMIO( MwdHandle, ...);

// Step [2b] - For Optomux I/O, call SendOptoMux to interact with I/O.
ErrorCode = SendOptoMux( MwdHandle, ...);
printf( "\\%s\\", %d chars, Error:%d\\n", ReceStr, iActualLen, iErrorCode
);

// Step [3] Close the port when the application ends.
opto22MwdPortClose( MwdHandle );
```

Notes about APIs:

- The APIs are listed below with the function prototypes and a description.
- Refer to OptoMwd.H for actual function prototypes or OptoMwd.BAS for function declarations.
- In general, an API that returns an "int" returns an error number where 0 indicates "no error".
- Each API name starts with "opto22Mwd" except for SendMIO.

### opto22MwdGetVersion, opto22MwdGetVersion2

```
char* FAR PASCAL opto22MwdGetVersion( void );

int opto22MwdGetVersion2(
    char* versionArg,
    UINT maxLenArg );
```

The “get version” APIs get a version string of the form “R1.9z”. The purpose of these functions is to allow an application to check the version of the DLL file. **opto22MwdGetVersion** returns a pointer to a string and **opto22MwdGetVersion2** copies the version string to a buffer provided by the caller.

### SendMIO

```
O22_ERROR_CODE SendMIO(
    int             iHandle, // Handle provided by 'port open'
    int             iAddress, // Address of brick
    unsigned int    iCommand, // Command number i.e., 202=set output
    unsigned int far* PositionArray, // Position array - 2 elements
    long far*      SendDataArray, // Send data array - 16 elements
    long far*      ReceDataArray); // Recv data array - 16 elements
```

Sends a command to Mystic I/O and gets the corresponding response. Returns an Opto 22 error code where a value of zero indicates no error.

### SendOptoMux

```
O22_ERROR_CODE SendOptoMux(
    int             iHandle, // Handle provided by 'port open'
    int             iAddress, // Address of brick
    unsigned int    iCommand, // Command number i.e., Max is 79
    long far*      cPosition, // 16 element array
    unsigned int far* ModifierArray, // Modifier array - 2 elements
    long far*      DataArray); // Send Data Array, 16 elements
```

Sends a command to Optomux I/O and gets the corresponding response. Returns an Opto 22 error code where a value of zero indicates no error.

### opto22MwdPortOpen for AC37 and WinApi

```
int opto22MwdPortOpenAC37(
    int* handle,
    UINT ioPort, // I/O address such as 3F8 (IRQ not required)
    DWORD Baud, // Baud rate such as 115200
    float timeOut,
    UINT retry,
    int protocolType,
    int dataCheckType );

int opto22MwdPortOpenWinApi(
    int* handle,
    UINT comPort, // COM port number. 1 for COM1.
    DWORD Baud, // Baud rate up to 38400
    float timeOut,
    UINT retry,
    int protocolType, // Protocol type: ASCII or Binary
    int dataCheckType ); // Data check type (should be CRC)
```

The “PortOpen” APIs open a port and assign a handle number to be used by the application to access the port.

Parameters common to all "PortOpen" APIs:

**timeOut** is the amount of time to wait, in seconds, for a response. A typical number to use for Arcnet or high speed serial is 0.75 seconds. Larger values are needed for lower baud rates or if several applications are accessing the same port.

**retry** is the quantity of times the driver will retry a command if an error occurs. The driver always tries once but the number of retries depends on this value. A typical number is 1.

**protocolType** should be either **ProtocolTypeBinary** or **ProtocolTypeAscii** which are defined in OptoMwd.H. Windows 3.1 on an RS232 port will not support Binary mode. Typically, Binary is better because twice as many characters need to be sent for ASCII. ASCII may be required if communicating via modem.

**dataCheckType** should be **DataCheckTypeCrc16** which is defined in OptoMwd.H.

### opto22MwdPortClose

```
void opto22MwdPortClose( int HandleArg );
```

This API closes a port and releases the handle. If this API is not called by an application before exiting, the port handle will not be released until the DLL is released from memory. Visual Basic should call this API when the main form unloads.

## Visual Basic Functions

### StringAsLong, StringAsFloat

```
void FAR PASCAL StringAsLong( long* numArg, char* StringArg );
void FAR PASCAL StringAsFloat( float* numArg, char* Stringarg );
```

These two APIs are used by Visual Basic to extract Longs or Floats from a response string that contains binary data. A response from mistic can be ASCII (such as "1.234E12") or binary (which would appear as 4 bytes of garbage characters) depending upon the command. HostWords allows ASCII or Binary mode to be selected. "C" doesn't need these two functions because C can use type casts to convert the data.

## Status or Error Codes

Refer to OptoErr.RH for a list of error codes. OptoErr.H and OptoErr.BAS list some APIs that provide an error message given an error code

# Index

## A

AC37, 208, 221  
Arcnet, 207, 208, 221, 222

## C

code fragment, 206, 220

## D

DataCheckTypeCrc16, 209, 222

## E

error codes, 210, 219, 222

## H

HostWords, 209, 222

## I

Installation, 206, 219

## M

MwDriver.Dll, 206

## O

opto22MwdGetVersion, 207, 220, 221  
opto22MwdGetVersion2, 207, 220, 221  
opto22MwdPortClose, 206, 209, 220, 222  
opto22MwdPortDelaySet, 209  
opto22MwdPortLock, 208  
opto22MwdPortOpen, 208, 221  
opto22MwdPortOpenAC37, 208, 221  
opto22MwdPortOpenArcnet, 206, 208, 220  
opto22MwdPortOpenWinApi, 208, 221  
opto22MwdPortRetrySet, 209  
opto22MwdSendRece, 207, 221  
opto22MwdSendReceNold, 206, 207, 220

## P

PortOpen, 208, 209, 222  
ProtocolTypeAscii, 208, 222  
ProtocolTypeBinary, 208, 222

## S

status codes, 210

## V

Visual Basic, 205, 209, 219, 222

