Quad Pak Input Modules

Features

- Each module contains four single-channel I/O circuits.
- Each module can be divided into two pairs with each pair sharing a common connection.
- used for sensing on/off AC voltages.
- Provides up to 4,000 Vrms of optical isolation between field devices and control logic.
- Features zero voltage turn-on and zero current turn-off

Description

Quad Pak modules contain the equivalent of four, single channel I/O circuits in a single high-density package. Each Quad Pak module can be divided into two pairs, with each pair sharing a common connection.

Quad Pak modules are designed to plug into the Quad Pak high-density I/O mounting racks only and cannot be plugged into single-channel racks. Quad Pak modules are designed to work with a 5 VDC logic voltage only and can be used with Optomux, Pamux, and Mistic protocol brain boards and mounting racks, as well as racks using a direct cable connection to a computer.

Quad Pak modules can also be used with a Raspberry Pi, the Digital I/O Carrier Board (part number OPTO-P1-40P), and the PB16HQ mounting rack.

AC input modules are used for sensing ON/OFF AC voltages. All AC input modules are designed with filtering on the input and a hysteresis amplifier for high noise rejection and transient-free "clean" switching. Each module provides up to 4,000 Vrms of optical isolation between field inputs and the logic side of the circuit.

All DC input modules, with the exception of the IDC5BQ, are designed with filtering on the input and a hysteresis amplifier for high noise rejection and transient-free "clean" switching. The IDC5BQ module is a fast-switching input module for signals produced by photoelectric switches, encoders, DC proximity switches, or TTL devices.



Typical uses and applications include sensing the presence or absence of voltage or sensing contact closures from sources such as:

- Proximity Switches
- Limit Switches
- Selector Switches
- Push Buttons
- Toggle Switches
- Thermostats
- Photoelectric switches
- TTL-compatible devices

Part Numbers

Part	Description
IDC5Q	4-Channel DC Input 12–32 VAC, 5 VDC Logic
IDC5BQ	4-Channel DC Input 4-16 VDC, 5 VDC Logic, High Speed
IAC5Q	4-Channel AC Input 90–140 VAC, 5 VDC Logic
IAC5AQ	4-Channel AC Input 180–280 VAC, 5 VDC Logic

DATA SHEET Form 0485-161229 PAGE

1

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2015 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

Ŋ

Ŋ

Quad Pak Input Modules

Specifications

Operating Ambient Temperature	-30 to 70 °C		
Isolation Input-to-Output	4,000 Vrms		
Output Voltage Drop	0.4 volts @ 50 milliamperes		
Output Current	50 milliamperes		
Output Leakage With No Input	100 microamperes maximum @ 30 VDC		
Output Transistor	30 volts breakdown		

	Units	IDC5Q	IDC5BQ	IAC5Q	IAC5AQ
Input Voltage Range	VDC	10–32	4–16	90–140	180–280
Input Current (per channel) @ Maximum Line	mA	29	45	11	6.5
Turn-on Time	msec	5	0.05	20	20
Turn-off Time	msec	5	0.01	20	20
Input Allowed For No Output	mA	1	0.7	3	1.7
	V	3	1	45	80
Logic Supply Voltage - Nomi- nal	VDC	5	5	5	5
Logic Supply Voltage Range	VDC	4.5–6	4.5–6	4.5–6	4.5–6
Logic Supply Current @ Nominal Logic Voltage	mA	12	12	12	12
Input Resistance (R ₁ in Schematic Diagram)	Ohms	1.5K	300	24K	66K
Control Resistance (R ₂ in Schematic Diagram)	Ohms	220	220	220	220

Dimensions

DATA SHEET

PAGE 2





Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2015 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

Quad Pak Input Modules

Schematics



Connections



Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3005 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2015 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

DATA SHEET Form 0485-161229

PAGE

3