


OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.




Form 1946-121212

OPTO 22

SSR-HS Heatsink Assembly

To take advantage of the cooling effect of natural air flow, we recommend mounting SSRs to a vertical surface. Before attaching the SSR, remove the protective film from both sides of the thermal pad, then place the pad on the heatsink making sure to align the holes. Secure the SSR to the heatsink with the screws provided.



Form 1946-121212