OPTO 22


Installing SNAP Rack DIN-Rail Clips

- For long racks, slide a DIN-rail clip (or two, if needed) to a middle position and secure with the provided rivet.
- 2. Insert one edge of the circuit board into the extrusion.
- 3. Push down hard on the other edge to snap it into place.
- 4. Attach one DIN clip to each end cap using slots in the end caps.
- Use provided screws to secure end cap and DINrail clip to each end of the extrusion.



Attaching the Adapter Clip to a DIN Rail

- 1. Hook the DIN-rail clip over the top of the DIN rail.
- 2. Using a screwdriver, pry open the DIN-rail clip flange at the bottom of the clip. Push the clip toward the DIN rail.
- 3. Snap the DIN-rail clip into place.



To remove the clip from the DIN rail, use a screwdriver to push the flange down, then pull the clip away from the DIN rail and unhook from the top.